



AudioCodes RXV200 Microsoft Teams Room on Android Installation Guide

[Home](#) » [AudioCodes](#) » AudioCodes RXV200 Microsoft Teams Room on Android Installation Guide 



AudioCodes RXV200 Microsoft Teams Room on Android™ Quick Installation Guide



Contents

- [1 RXV200 Introduction](#)
- [2 Package Contents](#)
- [3 Wall Mounting RXV200](#)
- [4 Configuring a Bundle](#)
- [5 RXV200 Interface](#)
- [6 Connection Diagram](#)
- [7 Pairing RX-PAD with RXV200](#)
- [8 RX40 Speaker Connection Diagram for RVX200-B40](#)
- [9 Technical Specifications](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)

RXV200 Introduction

Thank you for purchasing AudioCodes RXV200 Microsoft Teams Rooms on Android Compute Unit! This guide shows how to quickly install RXV200. AudioCodes has created a range of Microsoft Teams Rooms bundles based on the RXV200 compute unit and RX-PAD Meeting Room Controller.

RXV200 connects multiple audio and video peripherals, as well as dual screens, and offers support for a wide range of AI capabilities. RX-PAD allows users to seamlessly orchestrate productive meeting experiences.

AudioCodes offers five comprehensive RXV200 bundles:

✓ **RXV200-B05 – for adding Teams to existing rooms**

RXV200 + RX-PAD connecting to 3rd party equipment.

✓ **RXV200-B20 – for small rooms of up to 10 participants**

RXV200 + RX-PAD + RXVCam50M + RX15

✓ **RXV200-B40 – for medium size rooms of 6-12 participants**

RXV200 + RX-PAD + RXVCam50M + RX40 (large room)

✓ **RXV200-B70 – for large rooms of 10-18 participants**

RXV200 + RX-PAD + RXVCam70 + RX40 (large room)

✓ **RXV200-B360 – for small-medium size rooms of 2-8 participants**

RXV200 + RX-PAD + RXVCam360

Package Contents

Make sure you received the following items in the shipped box:


| | | | | |
|--|--|--|--|--|
| RXV200-B05 ✓ RXV200 ✓ RX-PAD ✓ 12V 3A Power Adapter (100-240V) ✓ Ethernet cable | RXV200-B20 ✓ RXV200 ✓ RX15 Speakerphone (2.5m pickup radius) ✓ RX-PAD ✓ RXVCam50 Camera ✓ 12V 3A Power Adapter (100-240V) ✓ USB Type C cable ✓ Ethernet cable | RXV200-B40 ✓ RXV200 ✓ RX40 Soundbar and Satellite Mics (8m pickup radius) ✓ RX-PAD ✓ RXVCam50 Camera ✓ 12V 3A Power Adapter (100-240V) ✓ USB Type C cable ✓ Ethernet cable | RXV200-B70 ✓ RXV200 ✓ RX40 ✓ RXVCam70 ✓ RX-PAD ✓ 12V 3A Power Adapter (100-240V) ✓ USB Type C cable ✓ Ethernet cable | RXV200-B360 ✓ RXV200 ✓ RXVCam360 ✓ RX-PAD ✓ 12V 3A Power Adapter (100-240V) ✓ USB Type C cable ✓ Ethernet cable |
|--|--|--|--|--|

Wall Mounting RXV200


To wall-mount your RXV200, you can purchase a separate orderable wall-mount kit ("RXV-WALLMOUNT") from AudioCodes.

To wall-mount RXV200:


1. Mark the locations on the wall where you want to drill the four wall-mounting holes. You can use the physical wall-mount plate as a template or refer to the dimensions below:




2. Drill holes into the wall according to your markings.
3. Insert the four screw anchors (supplied) into the drilled holes.
4. Attach RXV200 to the wall-mount plate using the four screws (supplied). Make sure that you insert the screws from the back of the plate, as shown below:



5. Mount the plate to the wall using the four wall-mounting screws (supplied):



6. Connect the required cables to RXV200.
7. Run the cables over the rubber cushion of the cable-retention clamp area.
8. Attach the cable-retention clamp cover (which provides cable strain relief and keeps cables secure), by tightening the integrated thumbscrews:




Configuring a Bundle

Customers will receive the RXV200 with the ordered bundle preconfigured. This section shows how to change the preconfigured bundle to another.


To change the preconfigured bundle:

1. Open the Bundle page on the RXV200 (Settings > Bundle).



2. The preceding figure shows RXV200 + RX-PAD as the selected bundle. See the preceding sections for more information about available bundles.


RXV200 Interface




| | Port | Description |
|---|------------------|--|
| 1 | HDMI Input types | HDMI 2.0 Input (including audio) |
| 2 | HDMI Outputs | 2 x HDMI 1.4 Outputs to external screens |
| 3 | USB-C | Connects camera, audio peripherals |
| 4 | USB-A (x4) | Connects camera, audio peripherals |
| 5 | LAN R1-45 | Connects RXV200 to the network |
| 6 | DC IN 12V 3A | Connects to 12V adapter |

Connection Diagram


Connection Diagram for RXV200-B05



Connection Diagram for RXV200-B20




Connection Diagram for RXV200-B40



RX40 Speaker Setup in Section 6

Connection Diagram for RXV200-B70



Connection Diagram for RXV200-B360



Pairing RX-PAD with RXV200

To pair RX-PAD with RXV200, see [here](#).

- ### RX40 Speaker Connection Diagram for RVX200-B40




Notice Information

Information contained in this document is believed to be accurate and reliable at the time of printing. However, due to ongoing product improvements and revisions, AudioCodes cannot guarantee accuracy of printed material after the Date Published nor can it accept responsibility for errors or omissions. Updates to this document can be downloaded from <https://www.audiocodes.com/library/technicaldocuments>. This document is subject to change without notice.

CE

Date Published: Dec-12-2024
Document #: LTRT-18288

Documents / Resources



[AudioCodes RXV200 Microsoft Teams Room on Android](#) [pdf] Installation Guide
RXV200-B360, RXV200-B20, RXV200-B40, RXV200-B70, RXV200 Microsoft Teams Room on Android, RXV200, Microsoft Teams Room on Android, Teams Room on Android, Room on Android, Android

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.