



AudioControl AC-LGD Load Generating Device and Signal Stabilizer for Oem Sound Systems Requiring A Speaker Load Instruction Manual

[Home](#) » [AudioControl](#) » AudioControl AC-LGD Load Generating Device and Signal Stabilizer for Oem Sound Systems Requiring A Speaker Load Instruction Manual 

Contents

- [1 AudioControl AC-LGD Load Generating Device and Signal Stabilizer for Oem Sound Systems Requiring A Speaker Load](#)
- [2 Quick Start](#)
- [3 What's Included](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)




AudioControl AC-LGD Load Generating Device and Signal Stabilizer for Oem Sound Systems Requiring A Speaker Load



PROVIDES STABILITY AND NOISE FILTERING FOR CLASS D AMPLIFIED OEM SOUND SYSTEMS MAXIMUM INPUT 20 VRMS (100 WATTS)

What is a Load Generating Device?

Today's factory systems include more Class D amplifier technology which can mute, distort, or emit damaging frequencies to your after-market audio equipment when the factory speakers are removed. The AC-LGD has been designed to generate load and stabilize signal from the factory system to ensure the best possible audio.



Quick Start

1. Remove one speaker-level input plug from your AudioControl active line output converter (LOC), processor, or amplifier
2. Unplug one end of the AC-LGD then plug the AC-LGD into the LOC
3. Install the plug you removed from the LOC to the open end of the AC-LGD
4. Connect your factory speaker signals to the AC-LGD
5. If you are using a LOC with different style connectors, unscrew the connectors from the AC-LGD wires and


connect the wires accordingly.

Important


- Do not exceed 20 Vrms (100 watts) of input
- Operating Impedance: 2 k Ω (20 Hz to 20 kHz) / 40 Ω (>20 kHz)
- Do not install under carpet or near heat sources

What's Included

One pair of AC-LGDs prewired with EIA color-coded wires




Also makes a charming bracelet!



22410 70th Ave West | Mountlake Terrace, WA 98043 USA
Phone 425-775-8461 | Fax 425-778-3166

Documents / Resources

	AudioControl AC-LGD Load Generating Device and Signal Stabilizer for Oem Sound Systems Requiring A Speaker Load [pdf] Instruction Manual AC-LGD Load Generating Device and Signal Stabilizer for Oem Sound Systems Requiring A Speaker Load, AC-LGD, Load Generating Device and Signal Stabilizer for Oem Sound Systems Requiring A Speaker Load, Load Generating Device and Signal Stabilizer, Device and Signal Stabilizer, Signal Stabilizer, Stabilizer
---	--