

# **AudioControl ACR-3 Remote Level Control User Guide**

Home » AudioControl » AudioControl ACR-3 Remote Level Control User Guide





Making Good Sound Great™





https://www.audiocontrol.com/car-audio/accessories/acr-3/

PRECISE AND TACTILE REMOTE LEVEL CONTROL & FUNCTION SWITCH REMOTE CAN BE FLUSH-MOUNTED FOR CUSTOM INSTALLATIONS

#### **Contents**

- 1 Add volume control to any system
- 2 Bracket Installation
- 3 Custom Installation
- 4 Documents / Resources
  - 4.1 References
- **5 Related Posts**

# Add volume control to any system

The ACR-3 is a remote level control & function switch designed to work with specific AudioControl line output converters and processors. The ACR-3 can be surface or custom-mounted to add level control, or total system volume control, and more to your audio

system. Installation is simple and no power is required.

## **Placement And Mounting of the ACR-3**

The ACR-3 may be mounted under a dash or console using its own bracket or through custom mounting holes in the dash/console. It should be within reach of the driver and in a spot where the LED is plainly visible.

#### **Bracket Installation**


ACR-3 mounts with four screws, which attach to the underside of a dashboard/console. Slide under the dash or console and place the ACR-3 in its mounting position, mark the mounting holes, drill pilot holes, and secure with screws.

#### **Custom Installation**

For that custom, finished look, the ACR-3 can be flush mounted directly on the dash/console panel (or anywhere else). Referencing the drawing right, disassemble the ACR-3. Drill a 9/32" (7 mm) hole in the panel for the control along with a 3/32" (2.3 mm) hole for the lock tab and a 1/8" (3 mm) hole for the LED. Reassemble the ACR-3 components on the dashboard or console.

#### What's Included?

ACR-3 Remote Level Control, 20' Phone Cable (RJ-11)





# 22410 70th Ave West, Mountlake Terrace, WA 98043 USA Phone 425-775-8461

www.audiocontrol.com



©2022 AudioControl. All rights reserved. P/N 912-080-0 Rev A

## **Documents / Resources**



<u>AudioControl ACR-3 Remote Level Control</u> [pdf] User Guide ACR-3 Remote Level Control, ACR-3, Remote Level Control, Level Control

# References

• Mome - AudioControl

Manuals+,