



DVB482 Free View Recorder Instructions

Contents [[hide](#)]

[1 Important Notice Before Purchase](#)

[2 FAQ & Troubleshooting](#)

[3 Documents / Resources](#)

[3.1 References](#)

Important Notice Before Purchase

To ensure the August DVB482 Free view Recorder meets your expectations and is compatible with your setup, please review the following:

Compatibility

- **TV Connection:** This recorder connects via HDMI, RCA, SCART. Please ensure your TV supports at least HDMI 1.3 or has a functional SCART and RCA port.
- **Signal Requirement:** Requires a terrestrial rooftop aerial (not compatible Frees at or satellite dishes).
- **TV Type:** Not compatible with TVs that do not support standard DVB-T (Free view) and DVB-T2 (Free view HD) channels.

Recording Functionality

- **No Series Link:** This device records based on Live TV, Schedule, start time, and end

time. It does not support Series Recording.

- Simultaneous Functions: Allows watching one channel while recording another, as long as both channels are on the same multiplex.
- USB Required: Recording and Time shift require a USB stick or external hard drive (FAT32, NTFS formatted).

EPG (Electronic Programme Guide)

- Selecting a programme from the EPG may tune the box to that channel immediately. This is standard behavior.

Usage Complexity

- Designed for users comfortable with setting recording schedules and navigating digital TV menus.
- If you prefer automatic or smart recording features (like a Sky Q or YouView box), this product may not match your expectations.
- This device is made to process traditional television signals and has no access to apps, catch-up websites or streaming services.

FAQ & Troubleshooting

1. My TV doesn't detect the HDMI signal. What should I do?

- Make sure your TV input is set to the correct HDMI port. Consult your TV manual for instructions on how to set the source of your TV.
- Try another HDMI cable or port if available.
- If HDMI still fails, use the SCART output if your TV supports it.
- Restart both the TV and the DVB482 after connecting.
- Press the Yellow V-Format button on the DVB482 remote and wait 1 minute. Repeat this process a few times.

2: Why does the channel change when I open the EPG?

- The EPG retrieves data from the currently tuned channel. When selecting a channel in EPG, the unit switches a tuner to that channel to fetch programme data -

this is normal behavior.

3: Can I record a whole TV series automatically?

- No. The DVB482 supports manual or single-event recordings only.
- You can set recurring timed recordings by manually selecting the channel, start time, and end time.

4: How do I know if my TV is compatible?

- Your TV must have either an HDMI or SCART input and support Free view DVB-T2 signals.
- If your TV is older or has unique firmware, please consult your manufacturer or test with a Free view aerial first.


5: Recording seems too complicated. Is there a simpler way?

- For one-touch recording, press the REC button during live TV.
- For scheduled recordings, use the EPG to select the programme, then press OK > Record.
- For full control, go to Menu > Record > Timer Record or press the Blue Button

6: My recordings are missing or incomplete.

- Ensure the USB drive is inserted and formatted FAT32 or NTFS.
- Check that the device is powered on during the scheduled recording period.
- Avoid changing channels during the recording unless recording a different channel on the second tuner.

Documents / Resources

	August DVB482 Free View Recorder [pdf] Instructions DVB482, DVB482 Free View Recorder, DVB482, Free View Recorder, View Recorder, Recorder
---	---

References

- [User Manual](#)

📁 August, DVB482, DVB482 Free View Recorder, Free View Recorder, Recorder, View Recorder

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.