



August Wireless Presenter User Manual

[Home](#) » [August](#) » August Wireless Presenter User Manual PDF

August Wireless Presenter



Contents

- [1 Introduction](#)
- [2 Operating System](#)
- [3 Parts & Functions](#)
 - [3.1 Front](#)
 - [3.2 Back](#)
- [4 Battery Installation](#)
- [5 Technical parameters](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)

Introduction

This wireless presenter is suitable for any presentation or PowerPoint occasion. With it, you don't need to stand beside your computer or have an assistant. It is very simple to use, just plug and play, and no driver is required.

The device enables you to control your presentation wirelessly up to 10 meters (32 feet) away, thanks to the advanced Radio Frequency (RF) technology that works through walls.

It combines the functions of a laser pointer and remote control. It is tailored as a convenient tool for presentations, teaching, meetings, speeches and training etc.

Operating System

The device supports Windows 98 /ME/ 2000 / 2003 / XP / Vista /7/ 8 /10, Linux and Mac OS

Parts & Functions

Front



Back

Take out the USB receiver



Once the USB receiver is connected to a computer, it would normally detect the signal sent from the presenter automatically, if however it does not due to interference caused by other devices, press Connect to re-establish the connection.

Battery Installation

- The unit is powered by 1 xAAA battery
- Remove the battery compartment cover
- Insert 1 xAAA battery into the battery holder
- Put the battery compartment cover back in position

Press and slide out the battery cover



Note:

1. Do not insert battery into the presenter in the wrong direction.
2. Do not leave bad or exhausted battery in the presenter.
3. If you do not use the presenter for a long period of time, remove the battery to avoid possible damage from battery corrosion.
4. If the presenter does not function correctly or if the operating range becomes reduced, try to replace the battery with new one.

Technical parameters

Presenter

Technology	Radio Frequency
Frequency	2.4GHz
Control distance	Upto 15m
Laser distance	Upto 300m
Battery	1 x AAA battery
Work voltage	1.5V
Laser wavelength	650nm
Max transmitting power	<1mW
Transmitted power range	0.43-0.95mW
Product size	106 x 39 x26 mm (Lx Wx H)
Weight	29g (without battery)

USB receiver

Operating system	Windows 98 /ME/ 2000 / 2003 / XP /Vista/ 7/8/10, Linux and Mac OS
USB version	USB 1.1 compatible with USB 2.0
Work voltage	4.5-5.5V
Size	29 x 16 x 5 mm (L x W x H)
Weight	2g

Warning:

Laser radiation
 Class 2 laser product
 Do not view directly with optical instruments
 Do not point at people and animals
 Please keep out of reach of children

Note:

Please note this instruction is only intended for reference. August International Ltd reserves rights to revise the product specifications, features and design without notice.

This product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The Declaration of conformity may be consulted on line at
<http://www.augustint.com/en/declaration>.



Documents / Resources

	<p>August Wireless Presenter [pdf] User Manual Wireless Presenter</p>
	<p>August Wireless Presenter [pdf] User Manual Wireless Presenter, WP200</p>

References

- [A augustint.com/en/declaration/](http://augustint.com/en/declaration/)
- [A Portable TV, Portable Freeview Digital TV, Handheld TV, Bluetooth Speakers, Bluetooth Headphones, Bluetooth Receiver, Bluetooth DAB Radio, Clock Radio, TV Aerial](http://augustint.com/en/declaration/)
- [A augustint.com/en/declaration](http://augustint.com/en/declaration/)