Manuals+ — User Manuals Simplified.

Aula Wind T1O2M Gaming Keyboard User Manual

Contents

Aula Wind T1O2M Gaming Keyboard User Manual

Gaming Keyboard

- stylish design, one-piece molded metal panel, not easy to rust.
- Hot-swappable switch
- Keycaps are made of a two-color injection molding process, durable and wear-resistant, not easy to lose color.
- Sensitive key response, trigger stroke 2.0MM.
- Mechanical shaft switch design, 60 million times key life, durability, excellent hand feel.
- Support 6-key and N-key Anti-ghosting, Internet banking password entry is not affected.
- Intelligent hibernation mode: the host goes into hibernation or standby mode, the backlight function is turned off, and the previous mode is restored after the host starts.
- Keyboard humanized design, with Fn to add a series of commonly used shortcut function keys.
- Dual mode (gaming mode) and (office mode) can be switched according to individual needs.
- Please download the software from:**www.aulastar.com**

Specifications

- Connection: USB
- Hot-swappable mechanical Switch design
- Number of keys: 104/105/106
- Button life: 60 million times
- Rated voltage: DC 5V
- Rated current: < 250mA
- Size: 445.0 (L)×180.54(W)*41.75 (H) +0.1mm
- Operating system: WIN XP/WIN7/WIN8/WIN10

Dual mode switching

Long press the mode button to switch modes: game mode (knob indicator light breathing) and office mode (knob indicator light always on)

Game Mode
M1 key = Game Mode 1 WSADCQEZ Shift-L Tab Ctrl-L TBMVF Alt-L NUMBER

KEYS 1-5 On
M2 key = Game Mode 2 @WERDF Numeric keys 1-6 B ESC ASMCGY Space H

Tab On

- M3 key = Game Mode 3 WASDERQ Numeric Keys 1-4 Shift-L Ctrl-L Space Tab
- Enter ESC Home End PGUP INS DEL F1 On

### Short press mode button to cycle through 20 light effects

- Knob clockwise (brightness+)
- Knob counterclockwise (light brightness-)

Office Mode

- M1 key = multimedia function (previous song)
- M2 key = multimedia function (play/pause)
- M3 key = multimedia function (next song)
- Short press on the mode key = multimedia function (mute)
- Clockwise knob = multimedia function (volume+)
- Counter-clockwise knob = multimedia function (volume-)

Custom mode keystroke recording storage

In the game mode state

- Press the M1 key to enter the corresponding custom mode
- Press and hold the M1 key (indicator light blinking) to enter the custom point color recording state.
- Press any key that needs to light up or go out to the specified state, after completing the setting, press the M1 key to store it.
- Press the M2 key to enter the corresponding customized mode.
- Press and hold the M2 key (the indicator light is flashing) to enter the customized spot color recording state.
- Press any key that needs to be lit up or extinguished to the specified state, after completing the setting, press the M2 key to the store.
- Press the M3 key to enter the corresponding customized mode after
- Press and hold the M3 key (the indicator light is flashing) to enter the customized spot color recording state.
- Press any key that needs to light up or go out to the specified state, after completing the setting, press the M3 key to store it.
- Press FN+ESC to clear the light recording and restore the factory default constant light mode.

Fn+	F1	F2	F3	F4
shortcut	Computer	Search	Calculator	CD
Fn+	F5	F6	F7	F8
shortcut	Prev Track	Next Track	Play/Pause	Stop
Fn+	F9	F10	F11	F12
shortcut	Mute	Volume-	Volume+	Lock/unlock full keyboard
Fn+	WIN-L	→	←	PRTSE
shortcut	Lock WIN+APP	Speed+	Speed-	6 keys anti-ghosting
Fn+	SCRLK	INS	ESC	↑
shortcut	N keys anti-ghosting	Switching light effects	restore the default	Brightness+
Fn+	↓			
shortcut	Brightness-			

Download PDF: Aula Wind T1O2M Gaming Keyboard User Manual

References

- **User Manual**