



AURA LIGHT PipeLED High-quality Pipe Luminaire Instruction Manual

[Home](#) » [AURA LIGHT](#) » AURA LIGHT PipeLED High-quality Pipe Luminaire Instruction Manual 

AURA LIGHT PipeLED High-quality Pipe Luminaire



Contents

[1 Installation Instructions](#)

[1.1 Ceiling installation](#)

[1.2 Maintaince hints](#)



[2 Documents / Resources](#)

[2.1 References](#)

[3 Related Posts](#)

Installation Instructions


1



10-12 mm

1. Used for cable e, 0,75-1,5 mm² (AWG 18#)
2. Solid cable end
3. Wire stripping 10-12 mm


2



Extra breather need to be paid additionally.


3

	DALI	ON/OFF	
Brown	L1	L1	1
Green/yellow	⊕	⊕	2
Blue	N	N	3
Black	DIM+/DA+	-	4
Grey	DIM-/DA	-	5



Ceiling installation

Step 1



SPARE PARTS	QUANTITY	
PipeLED	1	1
Clips	2	2
Self-tapping screws	2	3
Rubber washers	2	4
Expansion plastic screws	2	5

Step 2



Disconnect the power, then connect wires on the end caps.


Step 3

Install the suspension fixed bushings.





Step 4

Install PipeLED light and adjust beam angle.




Maintenance hints

 Non-replaceable light source.	 Replaceable control gear by a professional.
--	---

Aura Light AB, Sweden
Phone customer service +46 (0)20 32 30 30
info@auralight.com, www.auralight.com



Documents / Resources

	AURA LIGHT PipeLED High-quality Pipe Luminaire [pdf] Instruction Manual PipeLED, High-quality Pipe Luminaire, Pipe Luminaire, High-quality Luminaire, Luminaire, Pipe LED
--	---

References

- [Hållbar & innovativ belysning | Aura Light International](#)