



Autovent System AV–RS001 Rain Sensor User Guide

[Home](#) » [Autovent System](#) » Autovent System AV–RS001 Rain Sensor User Guide 

Contents

- [1 Autovent System AV–RS001 Rain Sensor](#)
- [2 Wiring](#)
 - [2.1 AV-RS001 Rain Sensor](#)
 - [2.2 AV-WLR001 Rain/Wind Sensor](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)




Autovent System AV–RS001 Rain Sensor




Wiring

AV-RS001 Rain Sensor




Controller	RS001
Terminal	Cable
24V	White
COM	Blue+Black
WRD	Brown

AV-WLR001 Rain/Wind Sensor



Controller	WLR001
Terminal	Cable
12V	White
COM	Blue
WRD	Brown

Documents / Resources



[Autovent System AV--RS001 Rain Sensor](#) [pdf] User Guide
AV--RS001 Rain Sensor, AV--RS001, Rain Sensor, Sensor