



AV Access U2EX50 USB Extender User Manual

[Home](#) » [AV Access](#) » AV Access U2EX50 USB Extender User Manual 

Contents

- [1 AV Access U2EX50 USB Extender](#)
- [2 Troubleshooting](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)



AV Access U2EX50 USB Extender



Troubleshooting

U2EX50

1. What can I do if the USB connection can't work?

- Check if you have plugged in the receiver with the included power adapter.
- Try connecting the transmitter to another USB port on your PC.
- Check if the “Power” and the “Status” LED indicators (on both the transmitter and the receiver) are in normal status (solid on/blinking). If not, please check if you have connected the Cat cable properly.
- Try connecting the USB devices to the PC directly without using the USB extender. Then check if the USB connection works.

2. What can I do if the USB connection suddenly stops working?

- Try re-plugging the USB cable between the transmitter and your PC.
- Try re-plugging in the receiver with the included power adapter.
- Try connecting the USB devices to the PC directly without using the USB extender. Then check if the USB connection works.

3. What can I do if the “status” LED indicator is off?

- Use a new Cat cable, or check if your cable meets the standard. It is recommended to use a Cat5E/6/6A/7 cable, instead of Cat5 or flat cable.
- Check if the total length of your cable is within 80m/260ft.
- Check if the connectors at both ends of the cable meet the IEEE T568B standard.
- Try crimping your Cat cable connectors according to the IEEE T568B standard.
- If you need to use patch cables at both ends, the length should be as short as possible, no more than 5m/16ft. Please note that the total
- length of the patch cables and the Cat cable should not be over 80m/260ft.

Problem Not Fixed?We're here for help

- **Call**
+1-866-629-3923
- **Email**
support@avaccess.com
- **Message**
Send the message

Documents / Resources

The thumbnail shows the first page of a user manual. It has a red header with the AV Access logo and the word 'Troubleshooting' in bold. Below the header, there are three numbered steps for troubleshooting. At the bottom, there is a section titled 'Problems Not Fixed?' with a sub-header 'What to Do Next?' and three icons representing different actions: 'Check', 'Reset', and 'Contact Us'.

[AV Access U2EX50 USB Extender](#) [pdf] User Manual

U2EX50, USB Extender, U2EX50 USB Extender, U2EX50 Extender, Extender

References

-  [AV Access | Quality & Budget Assured Pro AV Product Manufacturer](#)