

Avant-Garde Labs ACID Mini Archive Apocalypse



Avant-Garde Labs ACID Mini Archive Apocalypse User Guide

[Home](#) » [Avant-Garde Labs](#) » Avant-Garde Labs ACID Mini Archive Apocalypse User Guide 

Contents

- [1 Avant-Garde Labs ACID Mini Archive Apocalypse](#)
- [2 Product Usage Instructions](#)
- [3 FAQ](#)
- [4 Powering On](#)
- [5 Use](#)
- [6 Powering Off](#)
- [7 Status LED Legend](#)
- [8 Charging](#)
- [9 Specifications](#)
- [10 Troubleshooting](#)
- [11 Documents / Resources](#)
 - [11.1 References](#)



Avant-Garde Labs ACID Mini Archive Apocalypse



Specifications:

- Case: PLA Plastic (IP3X rated) L 3.2 x W 1.8 x H 1.2 Weight: 100 grams/3.5 oz
- Battery Life: 4+ Hours
- Battery: 1,000 mAh
- CPU Cores: 4
- CPU Speed: 1 GHz
- Storage: 256GB (Full)
- Ram: 512MB
- Charging Port: Micro USB @ 5V

Product Usage Instructions

Powering On and Off:

To power on, flip the power switch to the I symbol on the case. A small green light on top will illuminate flashing to indicate processor activity. To power off, flip the switch to the O position; all lights should be powered off.

Status LED Legend:

- Battery Between 100-75%: Before Using
- Battery Between 74-50%: After the animated white light stops breathing, 7 blue blinks will indicate the device is fully booted and ready for use.
- Battery Between 49-25%
- Battery Between 24-10%

- Battery Below 10%: Resources Are Still Initializing, Hotspot is Ready

Charging:

Use the Micro USB connector to charge the internal battery. Charging usually takes about 1 hour. When the red LED near the port is off, the battery has finished charging.

Connecting and Using:

1. Use any Wi-Fi enabled device to connect to the ACID Mini Wi-Fi network.
2. Enter the password 'acidhotspot'.
3. Follow the automatic prompt or type the URL of <https://acidmini.hotspot> into a browser.
4. Click 'Go to acid-mini.hotspot' and access the desired resource.

NOTE: Some browsers may have compatibility issues. Please use the FireFox browser for the best experience.

FAQ

Troubleshooting

- **Gateway Error message.**
 - This message is due to the device not being fully initialized and booted. Exit out of this page, then wait 10-15s and try again. If the error continues, try a reboot.
- **My device isn't opening resources anymore.**
 - Reboot the device by switching it off and switching it back on.
- **The video is blocky and/or blurry or stutters.**
 - Content on this device is highly compressed. This will leave artifacts in the video and is completely normal.
- **My video is not working.**
 - Be patient, videos are a large file. If the selected video doesn't play after 15s of attempting, reboot the device.
- **Everything feels sluggish.**
 - If large items like Wikipedia load within 10s, this is normal. This is a low-power device to extend battery life. Certain actions can be sluggish as a result.
- **No audio on the smartphone.**
 - Switch off the ringer silence setting.

Powering On

Flip the power switch to the "I" symbol on the case. A small green light on top will illuminate flashing to processor activity.

Before Using:

After the animated white light stops breathing, 7 blue blinks will indicate the device is fully booted and ready for use.

Use

Use any Wi-Fi-enabled device to connect to the “ACID Mini” Wi-Fi network. Next enter the password “acid-hotspot”, then follow the automatic prompt or type the URL of <https://acid-mini.hotspot> into a browser. Click “Go to acid-mini. hotspot” and click on the desired resource.








NOTE: Some browsers may have compatibility issues. Please use the Firefox browser for the best experience.

Powering Off



Flip the switch to the “ O ”position all lights should be powered off


Status LED Legend

-  Battery is Between 100-75%
-  Battery is Between 74-50%
-  Battery is Between is 49-25%
-  Battery is Between 24-10%
-  Battery is Below 10%
-  Resources Are Still Initializing
-  Hotspot is Ready



Charging

Use the Micro USB connector to charge the internal battery. Charging usually takes about 1 hour. When the red LED near the port is off the battery has finished charging.




Specifications

- Case: PLA Plastic (IP3X rated) L 3.2" x W 1.8" x H 1.2"
- Weight: 100 grams/3.5 oz
- Battery Life: 4+ Hours
- Battery: 1,000 mAh
- CPU Cores: 4
- CPU Speed: 1 GHz
- Storage: 256GB (Full)
- Ram: 512MB
- Charging Port: Micro USB @ 5V

Troubleshooting

- **“Gateway Error” message.**
 - This message is due to the device not being fully initialized and booted. Exit out of this page, then wait 10-15s and try again. If the error continues try a reboot.
- **My device isn’t opening resources anymore.**
 - Reboot the device by switching it off and switching it back on.
- **The video is blocky and/or blurry or stutters.**
 - Content on this device is highly compressed. This will leave artifacts in the video and is completely normal.
- **My video is not working.**
 - Be patient, videos are a large file. If the selected video doesn’t play after 15s of attempting, reboot the device.
- **Everything feels sluggish.**
 - If large items like Wikipedia load within this is normal. This is a low-power device in order to extend battery life. Certain actions can be sluggish as a result.
- **No audio on the smartphone.**
 - Switch off the ringer silence setting.

Documents / Resources

 Using Your Device Powering On: Press and hold the power button for 10 seconds to power on the device. Getting Started Guide Safe to Unplug: Press the power button for 10 seconds to power off the device. User: Press the power button for 10 seconds to power on the device. Powering Off: Press and hold the power button for 10 seconds to power off the device. Powering On: Press and hold the power button for 10 seconds to power on the device. Powering Off: Press and hold the power button for 10 seconds to power off the device.	Avant-Garde Labs ACID Mini Archive Apocalypse [pdf] User Guide ACID Mini Archive Apocalypse, ACID Mini, Archive Apocalypse, Apocalypse
---	---

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.