



AVATIME 914LDT100M Extra Large Display Digital Timer Instructions

[Home](#) » [AVATIME](#) » AVATIME 914LDT100M Extra Large Display Digital Timer Instructions 

Contents

- [1 AVATIME 914LDT100M Extra Large Display Digital Timer](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 INSTRUCTIONS](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)



AVATIME 914LDT100M Extra Large Display Digital Timer



Product Information

The Extra Large Display Digital Timer (Model No. 914LDT100M) is a versatile timer that can be used for various purposes like cooking, workouts, meetings, and more. It has an extra-large LCD display that shows the time remaining in minutes and seconds. The timer has both count-up and count-down functions and can be set up to 99 minutes and 59 seconds.

Product Usage Instructions

Before using the timer, carefully remove the plastic strip from the battery compartment to start the battery life. Also, remove the film from the LCD display before use. The timer should be hand-washed only and should not be immersed in water or put in the dishwasher.

Count Down:

1. Press the MIN and SEC buttons to set the desired time. You can press and hold each button for fast advance.
2. Press the START/STOP button to start the countdown.
3. Press the START/STOP button again to pause or resume the countdown.
4. When the timer counts down to 0, press the START/STOP button to turn off the alarm and recall the last time setting.
5. To clear the time, press MIN and SEC simultaneously.

Count Up:

1. Press the START/STOP button to start the count-up.
2. Press the START/STOP button again to pause or resume the count-up.
3. To clear the time, press MIN and SEC simultaneously.

It is recommended to keep the timer away from extreme heat or cold environments and avoid dropping it as it may cause damage.

With its easy-to-use functions, you can now keep track of your tasks with ease and precision.

INSTRUCTIONS

Before Use: Carefully remove plastic strip from battery compartment. This is included to preserve battery life. Remove film from LCD display.

Cleaning and Care: Hand wash only. Do not immerse in water or put in the dishwasher.

Count down:

1. Press MIN and SEC to set desired time. Press and hold each button for fast advance.
2. Press START/STOP to start the countdown.
3. Press START/STOP to pause and resume the countdown.
4. When timer counts down to 0, press START/STOP to turn off the alarm and recall last time setting.
5. Press MIN and SEC simultaneously to clear the time.

Note: Set desired time in minutes and seconds up to 99 minutes and 59 seconds.

Count up:

- 1. Press START/STOP to start the count up.
- 2. Press START/STOP to pause and resume the count up.
- 3. Press MIN and SEC simultaneously to clear the time.

Note: The timer will count up to 99 minutes and 59 seconds.

Documents / Resources

 <p>AVATIME Extra Large Display Digital Timer INSTRUCTIONS</p> <p>Before the counting timer is used, please read the instructions carefully to ensure the correct use of the timer.</p> <p>Count down</p> <ol style="list-style-type: none">1. Press the ON/OFF button to turn on the timer. The display will show 00:00.2. Press the MIN button to set the minutes. The display will show the minutes.3. Press the SEC button to set the seconds. The display will show the seconds.4. Press the START/STOP button to start the counting. The display will show the counting time. <p>Count up</p> <ol style="list-style-type: none">1. Press the ON/OFF button to turn on the timer. The display will show 00:00.2. Press the MIN button to set the minutes. The display will show the minutes.3. Press the SEC button to set the seconds. The display will show the seconds. <p>Note: The timer will count up to 99 minutes and 59 seconds.</p>	<p>AVATIME 914LDT100M Extra Large Display Digital Timer [pdf] Instructions</p> <p>914LDT100M Extra Large Display Digital Timer, 914LDT100M, Extra Large Display Digital Timer, Large Display Digital Timer, Display Digital Timer, Digital Timer, Timer</p>
---	---