



# AXESS PR3206 AM/FM Radio with Media Player Instruction Manual

[Home](#) » [Axess](#) » AXESS PR3206 AM/FM Radio with Media Player Instruction Manual 

## AXESS PR3206 AM/FM Radio with Media Player Instruction Manual



### Contents

- [1 Product Overview](#)
- [2 Operation Instructions](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

### Product Overview

- Telescope Antenna
- Playing Indicator

3. Tuning Control
4. Tuning Frequency Indicating Window
5. Function Switch/Band Selector
6. Hand Belt
7. Battery Slot (Back)
8. Earphone Jack
9. Volume Control



## Operation Instructions

1. Put two AA 1.5V batteries into Battery Slot (7) with correct polarity, and close the lid of the battery slot.
2. Move the function switch (5) to the position of FM or AM to receive FM or AM station program.
3. Turn the Tuning Control(3), and watch the Tuning frequency Indicating Window(4) and dial pointer select the program which you want to receive.
4. The Playing Indicator (2) will light up, when the correct station is received and the station signal is sufficiently strong.
5. Turn the Volume Control to your desired function..
6. When you receive FM station, please pull out the Telescopic Antenna (1) to get the best reception by changing its length and angle.
7. Receiving AM by using the internal magnetic antenna, and you can get the best reception by rotating the direction of the radio.
8. In order not to affect others, please insert the earphones in the Earphone Jack (8) (the speaker inside the radio disconnects automatically),you can listen to the radio by earphones.
9. When you would not like to listen to the radio, please move the Function Switch (5) to the position of OFF to turn off the power.

### 1. Frequency Range:

AM 530-1600 KHZ

FM 88108 MHZ

### 2. Power: DC 3V, two AA1.5V batteries

### 3. Size: 134\*72\*37mm

**Axess Products Corporation**  
6639 Valjean Ave., Van Nuys, CA 91406,  
USA **Tel:** 818-785-4000 • **Fax:** 818-785-5081  
email: [infogaxessusa.com](mailto:infogaxessusa.com)  
Questions? Comments?  
Please Contact us at [support@axessusa.com](mailto:support@axessusa.com)

Copyright 2014 Axess Products Corporation. All Rights Reserved



## Documents / Resources

 The image shows the front of the AXESS PR3206 radio. It has a silver and black design. A list of features is printed on the left side of the image: 1. Telescopic Antenna, 2. Power Indicator, 3. Tuning Control, 4. Tuning Frequency Indicating Window, 5. Function Switch/Band Selector, 6. Headset, 7. Battery Slot (Back), 8. Earphone Jack, 9. Volume Control.	<p><a href="#">AXESS AXESS PR3206 AM/FM Radio with Media Player</a> [pdf] Instruction Manual AXESS, PR3206, AM, FM, Radio, with, Media Player</p>
--	---

Manuals+.