



AXESS MPBT7501P Portable Bluetooth Speaker User Manual

[Home](#) » [Axess](#) » AXESS MPBT7501P Portable Bluetooth Speaker User Manual 

AXESS MPBT7501P Portable Bluetooth Speaker



To ensure correct operation and avoid damage, please read this user manual carefully before using this product.

Contents

- [1 Features](#)
- [2 Specifications](#)
- [3 Package Contents:](#)
- [4 Product Description](#)
- [5 Power On/Off](#)
- [6 Bluetooth](#)
- [7 TWS Function](#)
- [8 FM Radio](#)
- [9 Playing music from USB disk](#)
- [10 AUX-IN](#)
- [11 RGB Light](#)
- [12 Reset Functionality](#)
- [13 More Remarks](#)
- [14 How to charge](#)
- [15 Warning](#)
- [16 Documents / Resources](#)
 - [16.1 References](#)
- [17 Related Posts](#)

Features

- 2.1CH portable Bluetooth speaker
- Dedicated button for TWS function, achieve true wireless Bluetooth playing with double enhanced stereo sound
- USB support
- Three different modes of RGB Lighting
- With A2DP Bluetooth, wireless stream music from any Bluetooth-enabled device
- FM radio support
- Line-in function, suitable for PC, MID, TV and other audio devices
- Built-in lithium rechargeable battery 3000mAh
- Strong carry handle, easy to take out


Specifications

- Bluetooth version: V5.1+BR+EDR
- Horn Size: 2 inch
- Subwoofer Size: 3 inch*2
- RMS Power Output: 20W
- Peak Power Output: 40W
- Battery Capacity: 3.7V, 3000mAh
- Play time: 2 hours at maximum volume
- Frequency Response: 70Hz-18kHz
- Bluetooth connecting range: 10m
- Product size: 356(L) *134(W) * 178 (H) mm

Package Contents:

- 1 x Portable Bluetooth Speaker
- 1 x Charging cable
- 1 x Audio cable
- 1 x User Manual

Product Description



1. Power On / Off
2. TWS Button
3. Mode Button (Bluetooth / FM Radio / USB / AUX)
4. Play / Pause
5. RGB Light
6. Forward / Volume Up
7. Backward / Volume Down
8. Battery Indicator
9. USB Port
10. Type-C Charging Jack
11. AUX Input
12. Reset Jack

Power On/Off

Long-press the Power button to turn the speaker on and off.

Bluetooth

- Turn the power button to “ON”, the speaker enter Bluetooth mode automatically.
- Activate Bluetooth of mobile phone and search for device name “AXESS MPBT7501P” then connect it.

- Play the music from your mobile phone and enjoy.
- Long-press Forward or Backward button on the device or operate on Mobile phone to select songs you like.
- Short-press Forward or Backward button to adjust volume up and down. Or adjust the mobile phones' volume.
- Short-press Play/Pause button on the device or operate on Mobile phones to play/pause the music.
- Long-press TWS button to disconnect the Bluetooth connection with the mobile device.

TWS Function

- Turn on two identical speakers you want to pair, both under BT mode. Only need to set one of the two units.
- Short-press the "TWS" button to pair, the TWS button will keep lighting after paired successfully.
- Make Bluetooth connection with your mobile phone to play music by the two paired Speakers to create more powerful surround sound effect.
- Short-press the "TWS" button again to exit TWS mode.

FM Radio

- Turn the power button to "ON", press the "MODE" button to FM state.
- Short press "Play/Pause" button to mute the speaker, long press "Play/Pause" button to auto search the FM Channel and store it automatically.
- Long press Forward or Backward button to change the stored FM channel.
- Short press Forward or Backward button to adjust the volume.

Playing music from USB disk

- Turn the Power button to "ON".
- Insert USB flash disk into slot, the music will be played automatically.
- Long press Forward or Backward button to select songs you like, short press to adjust the volume up and down.
- Press Play/Pause to play or pause.

Notes: Under any playing mode, when you insert a USB disk to the speaker, it will switch to play the USB disk.
EN

AUX-IN

- For other compatible music devices or your MP3/MP4 players, use the supplied audio line cable to connect from the device's "Line Out" to the "Aux In" of this device, then enjoy...
- Under any playing mode, when you use the audio cable to connect the device, it will auto-switch to the AUX mode.
- When using an external device, all functions can be controlled by the external device.

RGB Light

The RGB light is on when speaker powered on, user can short-press the RGB Light button to turn the three different light modes and turn it off.

Reset Functionality

If the speaker does not turn off or respond, user can short-press the Reset jack with a small round pin to reset the speaker.

More Remarks

- Default volume is at 50% status of max volume.
- Play time may vary depending on volume level and music style.

How to charge

- The charger is not included in the package, please charge the speaker via a standard 5V/1-2A charger or via a PC.
- Charge time is about 5 hours. After full charging, the 4 LEDs is off when speaker off.

IMPORTANT:

When playing music during charging, please put the volume to middle, because for some music with heavy bass, the charger may not be able to afford the high current temporarily under the maximum volume.

Warning

- Don't use/store this speaker in extreme temperatures.
- Please store it in cool and dry area, keep away from anything that generates heat, such as radiators, stoves, etc.
- In order to have hearing protection and an extended speaker life, avoid listening to songs on maximum volume.
- When cleaning this speaker, use a soft dry cloth. For more severe stains, please dampen the cloth with water only. Anything else has the chance of dissolving the paint or damaging the plastic.



9135 Alabama Ave., unit F, Chatsworth, CA 91311 Tel: (818) 785.4000 www.AxessUSA.com
admin@montagela.com



Documents / Resources



[AXESS MPBT7501P Portable Bluetooth Speaker](#) [pdf] User Manual
MPBT7501P Portable Bluetooth Speaker, MPBT7501P, Portable Bluetooth Speaker

References

- [AXESS Products USA - High Quality Audio Video Accessories](#)

Manuals+.