



AXIOM AX16CL Floor Stand High Power Passive Portable Line Array Element Instruction Manual

[Home](#) » [AXiom](#) » AXIOM AX16CL Floor Stand High Power Passive Portable Line Array Element Instruction Manual 

Contents


- [1 AXIOM AX16CL Floor Stand High Power Passive Portable Line Array Element](#)
- [2 SUPPLIED MATERIALS](#)
 - [2.1 ASSEMBLY SEQUENCE](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)



AXIOM AX16CL Floor Stand High Power Passive Portable Line Array Element




SUPPLIED MATERIALS




Check AX16CL/AX8CL

User's Manual for additional instructions and installation examples.


1. Remove the knob (A) from column and screw it in the base, loosen the knob (E).
2. Place the first column (B).
3. Insert the front pin (C).
4. Insert the rear pin (D) in the desired aiming position.
5. Tighten the knobs (A) and (E).



6. Loosen the knobs (H) and (L).
7. Place the second column (I).
8. Insert the front pin (F). 9 – Insert the rear pin (G) in the desired aiming position.
9. Tighten the knobs (H) and (L).



ASSEMBLY SEQUENCE



CONDITIONS OF USE


Proel do not accept any liability for damage caused to third parties due to improper installation, use of non-original spare parts, lack of maintenance, tampering or improper use of this product, including disregard of acceptable and applicable safety standards. Proel strongly recommends that this loudspeaker cabinet be suspended taking into consideration all current National, Federal, State and Local regulations. The product must be installed by qualified personnel only. Please contact the manufacturer for further information.

WARNINGS:

- The ground where the KPSTANDAX16CL floor stand is placed needs to be stable and compact.
- Adjust the feet so to put the KPSTANDAX16CL perfectly horizontal. Use a spirit level to obtain the best result.
- Always secure ground stacked setups against movement and possible tipping over.
- A maximum of 2 x AX16CL or 4 x AX8CL or 1x AX16CL + 2x AX8CL speakers are allowed to be installed over a KPSTANDAX16CL serving as ground support.
- When 2 column units are stacked both must be setup with 0° aiming.

PROEL S.p.A. – Via alla Ruenia 37/43 – 64027 Sant’Omero (Te) – ITALY Tel: +39 0861 81241
www.axiomproaudio.com

Documents / Resources



[AXIOM AX16CL Floor Stand High Power Passive Portable Line Array Element](#) [pdf] Instruction Manual
AX16CL, AX8CL, AX16CL Floor Stand High Power Passive Portable Line Array Element, AX16CL, Floor Stand High Power Passive Portable Line Array Element, Passive Portable Line Array Element, Portable Line Array Element, Line Array Element, Array Element, Element

References

- [Axiom Pro Audio](#)