

axis APS401W 12/24V Wireless 4 Sensor Instruction Manual

Home » AXIS » axis APS401W 12/24V Wireless 4 Sensor Instruction Manual





APS401W 12124V Wireless Parking Sensor System


Contents


- 1 WIRING DIAGRAM
- **2 TECHNICAL SPECIFICATION**
- **3 DETECTION ZONES**
- **4 SENSOR**
- **5 UNDER MOUNTS**
- **6 DISPLAY**
- **7 FEATURES**
- **8 TROUBLE-SHOOTING**

GUIDE


- **9 SPECIAL NOTES**
- **10 SPECIFICATIONS**
- 11 WARRANTY
- 12 Documents / Resources
 - 12.1 References
- 13 Related Posts

WIRING DIAGRAM





The two outer sensors start detecting at Zone B.



Switch 1: OFF- Standard ON- Display distance less 20cm than actual.

Switch 2: Sensor sensitivity

TECHNICAL SPECIFICATION


DESCRIPTION	MIN	SPEC	MAX
Power voltage (V DC)	10		35
Operating current (mA)			150
Operating temperature °C	-20		80
Operating frequency (kHz)	39.3		40.7
Horizontal detection angle		120°	
Vertical detection angle		60°	
Distance detection accuracy (cm)		10	
Detection range (m)	0.05		2.5
Buzzer sound volume (dB)	75		105

DETECTION ZONES

DISPLAY	SOUND
ZONE A: 1.5 – 2.5m	ZONE A: 1.5 – 2.5m
Number Only	None
ZONE B: 1 – 1.5m	ZONE B: 1.2 – 1.5m
Green	2 beeps per second
ZONE C: 0.5 – 1m	ZONE C: 0.9 – 1.2m
Amber	3 beeps per second
ZONE D: 0 – 0.5m	ZONE D: 0.6 – 0.9m
Red	4 beeps per second
	ZONE E: 0.3 – 0.6m
	5 beeps per second
	ZONE F: 0 – 0.3m
	Constant tone

SENSOR

18.8mm Rubber Angled Sensor




UNDER MOUNTS

Under-Mount Brackets and Spacers



DISPLAY



99 x 20H x 28Dmm


FEATURES

- 1. Wireless range up to 30m.
- 2. Towbar / Spare Wheel detection zone.
- 3. Suitable for flush mounting into metal bumpers and underbody/tray mounting.
- 4. System Self-Checking Function On start-up, the system will beep twice; If there is any faulty sensor, the system will beep once.
- 5. IP69K Control Box & IP68 Sensors and Connectors.
- 6. E-Mark certified.

TROUBLE-SHOOTING GUIDE

PROBLEM	CAUSE	SOLUTION
The system fails to start when the rev	Wrong connection of power lead	Check the power lead
erse gear is engaged	Wrong jack connection	Check the connectors
The system always detects the same distance	The sensor detects the ground	Check and adjust the vertical s ensor angle
The system fails to detect the obstacl es	Wrong sensors connection	Check and reset the system
False alarm	The sensor detects the ground	Check and adjust the vertical s ensor angle

SPECIAL NOTES



SPECIFICATIONS

GENERAL	
- Detection Range:	0.05- 2.5m
- Rated Voltage:	12/24V DC
- Operating Range:	9-32V DC

#NAME? Visual Direction & Indicators - Audiable Buzzer: Yes - Mute Function: Yes - Buzzer Cable Length: 1.5m - Dimensions: 99Wx 20H x 28Dmm #NAME? IP69K - Wireless Range: Wireless Range: Up to 30m - Ignore Function: Towbar / Spare Wheel - Power Leads: 1.4m #SENSORS - Sensor Type: Angled Rubber - Sensor Size: 18.8mm - Sensor Dimensions: 26W x 26H x 24.5Dmm - Sensor Cable Length: 2.5m - Sensor Installation: Under Mount or In-Bumper Mount - Detecting Distance: 0.05-2.5m - Ultrasonic Frequency: 40KHz - Working Temperature: -20° to +80C #NAME? IP68 - Under Mount Dimensions: 65W x 30H x 24.5Dmm INCLUDES Control Box 4 x Bracket with Pads 4 x 2.5 Sensor Cable Wireless Display Drill Bit	- Operating Current:	150mA@ 12V		
- Audiable Buzzer: Yes - Mute Function: Yes - Buzzer Cable Length: 1.5m - Dimensions: 99Wx 20H x 28Dmm CONTROL BOX #NAME? IP69K - Wireless Range: Wireless Range: Up to 30m - Ignore Function: Towbar / Spare Wheel - Power Leads: 1.4m SENSORS - Sensor Type: Angled Rubber - Sensor Size: 18.8mm - Sensor Dimensions: 26W x 26H x 24.5Dmm - Sensor Cable Length: 2.5m - Detecting Distance: 0.05-2.5m - Ultrasonic Frequency: 40KHz - Working Temperature: -20° to +80C #NAME? IP68 - Control Box 4 x 8-ascket with Pads 4 x 2.5 Sensor Cable Wireless Display	LED DISPLAY			
- Mute Function: Yes	#NAME?	Visual Direction & Indicators		
Buzzer Cable Length: 1.5m 99Wx 20H x 28Dmm	- Audiable Buzzer:	Yes		
Dimensions: 99Wx 20H x 28Dmm	- Mute Function:	Yes		
#NAME? IP69K #Wireless Range: Wireless Range: Up to 30m - Ignore Function: Towbar / Spare Wheel - Power Leads: 1.4m #ENAMES SENSORS - Sensor Type: Angled Rubber - Sensor Size: 18.8mm - Sensor Dimensions: 26W x 26H x 24.5Dmm - Sensor Cable Length: 2.5m - Sensor Installation: Under Mount or In-Bumper Mount - Detecting Distance: 0.05-2.5m - Ultrasonic Frequency: 40KHz - Working Temperature: -20° to +80C #NAME? IP68 - Under Mount Dimensions: 65W x 30H x 24.5Dmm INCLUDES Control Box 4 x 2.5 Sensor Cable Wireless Display	- Buzzer Cable Length:	1.5m		
#NAME? IP69K - Wireless Range: Wireless Range: Up to 30m - Ignore Function: Towbar / Spare Wheel - Power Leads: 1.4m	- Dimensions:	99Wx 20H x 28Dmm		
− Wireless Range: Wireless Range: Up to 30m − Ignore Function: Towbar / Spare Wheel − Power Leads: 1.4m SENSORS − Sensor Type: Angled Rubber − Sensor Size: 18.8mm − Sensor Dimensions: 26W x 26H x 24.5Dmm − Sensor Cable Length: 2.5m − Sensor Installation: Under Mount or In-Bumper Mount − Detecting Distance: 0.05-2.5m − Ultrasonic Frequency: 40KHz − Working Temperature: -20° to +80C #NAME? IP68 − Under Mount Dimensions: 65W x 30H x 24.5Dmm INCLUDES Control Box 4 x Sensors 4 x Bracket with Pads 4 x 2.5 Sensor Cable Wireless Display	CO	NTROL BOX		
- Ignore Function: - Power Leads: 1.4m SENSORS - Sensor Type: - Sensor Size: 18.8mm - Sensor Dimensions: 26W x 26H x 24.5Dmm - Sensor Cable Length: - Sensor Installation: Under Mount or In-Bumper Mount - Detecting Distance: - Ultrasonic Frequency: - Working Temperature: - 20° to +80C #NAME? - Under Mount Dimensions: INCLUDES Control Box 4 x Bracket with Pads 4 x 2.5 Sensor Cable Wireless Display	#NAME?	IP69K		
Power Leads: 1.4m	– Wireless Range:	Wireless Range: Up to 30m		
SENSORS - Sensor Type: Angled Rubber - Sensor Size: 18.8mm - Sensor Dimensions: 26W x 26H x 24.5Dmm - Sensor Cable Length: 2.5m - Sensor Installation: Under Mount or In-Bumper Mount - Detecting Distance: 0.05-2.5m - Ultrasonic Frequency: 40KHz - Working Temperature: -20° to +80C #NAME? IP68 - Under Mount Dimensions: 65W x 30H x 24.5Dmm INCLUDES Control Box 4 x Bracket with Pads 4 x 2.5 Sensor Cable Wireless Display	- Ignore Function:	Towbar / Spare Wheel		
- Sensor Type: - Sensor Size: - Sensor Dimensions: - Sensor Dimensions: - Sensor Cable Length: - Sensor Installation: - Detecting Distance: - Ultrasonic Frequency: - Working Temperature: - 20° to +80C #NAME? - Under Mount Dimensions: - Detecting Distance: - Control Box 4 x Bracket with Pads 4 x 2.5 Sensor Cable Wireless Display	- Power Leads:	1.4m		
- Sensor Size: 18.8mm - Sensor Dimensions: 26W x 26H x 24.5Dmm - Sensor Cable Length: 2.5m - Sensor Installation: Under Mount or In-Bumper Mount - Detecting Distance: 0.05-2.5m - Ultrasonic Frequency: 40KHz - Working Temperature: -20° to +80C #NAME? IP68 - Under Mount Dimensions: 65W x 30H x 24.5Dmm INCLUDES Control Box 4 x Bracket with Pads 4 x 2.5 Sensor Cable Wireless Display	SENSORS			
- Sensor Dimensions: 26W x 26H x 24.5Dmm - Sensor Cable Length: 2.5m - Sensor Installation: Under Mount or In-Bumper Mount - Detecting Distance: 0.05-2.5m - Ultrasonic Frequency: 40KHz - Working Temperature: -20° to +80C #NAME? IP68 - Under Mount Dimensions: 65W x 30H x 24.5Dmm INCLUDES Control Box 4 x Sensors 4 x Bracket with Pads 4 x 2.5 Sensor Cable Wireless Display	– Sensor Type:	Angled Rubber		
- Sensor Cable Length: - Sensor Installation: - Detecting Distance: - Ultrasonic Frequency: - Working Temperature: #NAME? - Under Mount Dimensions: Detecting Distance: Control Box Detecting Distance: Sensor Cable - Under Mount Dimensions: Detecting Distance: Control Box - Under Mount Dimensions: Detecting Distance: Detecting Distance:	– Sensor Size:	18.8mm		
- Sensor Installation: Under Mount or In-Bumper Mount - Detecting Distance: - Ultrasonic Frequency: - Working Temperature: - 20° to +80C #NAME? Under Mount Dimensions: Feba Feba	– Sensor Dimensions:	26W x 26H x 24.5Dmm		
- Detecting Distance: - Ultrasonic Frequency: - Working Temperature: - 20° to +80C #NAME? - Under Mount Dimensions: IP68 - Under Mount Dimensions: INCLUDES	- Sensor Cable Length:	2.5m		
- Ultrasonic Frequency: - Working Temperature: -20° to +80C #NAME? IP68 - Under Mount Dimensions: 65W x 30H x 24.5Dmm INCLUDES Control Box 4 x Sensors 4 x Bracket with Pads 4 x 2.5 Sensor Cable Wireless Display	- Sensor Installation:	Under Mount or In-Bumper Mount		
- Working Temperature: -20° to +80C #NAME? IP68 - Under Mount Dimensions: 65W x 30H x 24.5Dmm INCLUDES Control Box 4xSensors 4 x Bracket with Pads 4 x 2.5 Sensor Cable Wireless Display	- Detecting Distance:	0.05-2.5m		
#NAME? IP68 - Under Mount Dimensions: 65W x 30H x 24.5Dmm INCLUDES Control Box 4xSensors 4 x Bracket with Pads 4 x 2.5 Sensor Cable Wireless Display	- Ultrasonic Frequency:	40KHz		
- Under Mount Dimensions: INCLUDES Control Box 4xSensors 4 x Bracket with Pads 4 x 2.5 Sensor Cable Wireless Display	- Working Temperature:	-20° to +80C		
INCLUDES Control Box 4xSensors 4 x Bracket with Pads 4 x 2.5 Sensor Cable Wireless Display	#NAME?	IP68		
Control Box 4xSensors 4 x Bracket with Pads 4 x 2.5 Sensor Cable Wireless Display	- Under Mount Dimensions:	65W x 30H x 24.5Dmm		
4xSensors 4 x Bracket with Pads 4 x 2.5 Sensor Cable Wireless Display	INCLUDES			
4 x Bracket with Pads 4 x 2.5 Sensor Cable Wireless Display	Control Box			
4 x 2.5 Sensor Cable Wireless Display	4xSensors			
Wireless Display	4 x Bracket with Pads			
	4 x 2.5 Sensor Cable			
Drill Bit	Wireless Display			

WARRANTY

Congratulations on your purchase of a quality Mobile Safety System! You're joining thousands of satisfied customers who enjoy & experience the benefits of the products we distribute. In the unlikely event that some technical difficulty arises with your purchase, be assured that we are most anxious to see that the problem is quickly rectified to your satisfaction. Please familiarise yourself with the following simple conditions of our warranty.

This warranty covers faults through component failure or failure of the product to operate in accordance with published specifications. Product failure as a result of reasonable environmental conditions, accident, misuse, improper installation, unauthorized repair, vehicle electrical or wiring faults or neglect etc, will not be covered by this

warranty. Removal and installation costs, if any, would be paid by the owner as well as any freight or postage costs of transporting the product to AudioXtra. AudioXtra shall not be liable or responsible for any loss or use of this product or any form of consequential loss.

CONSUMER WARRANTY

This product is warranted by AudioXtra Pty Ltd to be free from defects in materials and workmanship under **NORMAL USE** for a period of **TWENTY FOUR MONTHS** from the date of purchase.

WITHIN 30 DAYS OF PURCHASE DATE:

Please return the unit for a replacement to our National Service Centre or the Retailer from where you made the purchase. All accessories must be included. Proof of purchase date **must** accompany the products.

AFTER 30 DAYS OF PURCHASE DATE:

Warranty repair and service is carried out by our National Service Centre. Repair and service will be carried out at no cost to the owner if proof of ownership and the date of purchase can be verified to the satisfaction of the authorized center concerned with this repair. This proof should take the form of either:

- a) The warranty card accompanying this product, stamped and dated by the dealer.
- b) A Tax Invoice or Receipt showing full details of the original vendor, purchaser, model number, and serial number.

COMMERCIAL WARRANTY

A product used in or associated with a commercial application will carry a limited SIX MONTH warranty. An abnormal commercial application is one where usage, dust, vibration, heat/cold, and other environmental conditions exist at an extreme level.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Please complete the details below in the event of warranty service being required.

Purchaser's Name:		
Purchaser's Address:		
Model Number:		APS401W
Dealer Name:		
Serial Number:		
Date of Purchase		
Dealer Address:		
Invoice/Sales Docket no:		
General Hints: To expedite service and prompt return of the equipment, please:		
a) Clearly describe the fault in detail c) Include your return address	b) Safely and securely pack the unit for transport d) Provide proof of purchase date as outlined above	

National Service Centre:

10 STODDART ROAD, PROSPECT, SYDNEY NSW 2148 Australia

Telephone: (02) 8841 9000 Fax: (02) 9636 1204

email: services@audioxtra.com.au



PTY LT D audioxtra.com.au



axis APS401W 12/24V Wireless 4 Sensor [pdf] Instruction Manual APS401W, 12 24V Wireless 4 Sensor

References

• Audioxtra – Australian importer and distributor of Axis, Blaupunkt, Dynamat, HEMA Maps, Midland and Uniden

Manuals+,