



AXTON AT-25Y 530'-Range Essential Infrared Illuminator with Day/Night Sensor User Guide


[Home](#) » [AXTON](#) » AXTON AT-25Y 530'-Range Essential Infrared Illuminator with Day/Night Sensor User Guide

Contents

- [1 AXTON AT-25Y 530'-Range Essential Infrared Illuminator with Day/Night Sensor](#)
- [2 WIRING](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)




AXTON AT-25Y 530'-Range Essential Infrared Illuminator with Day/Night Sensor



WIRING


OPTION 1 Constant ON

AXTON Illuminators have been designed and tested to run 24/7 continuously both indoors and outdoors.




OPTION 2 Automatic

Illuminator will trigger ON/OFF using the built-in ambient light sensor which has been pre-set to a threshold of 5-15 lux. ON will trigger immediately while OFF will trigger after a 12-18 second delay.



OPTION 3 External Controller (e.g. Camera)

You will need to log into the camera via the computer and program the I/O ports to trigger when IR illumination is desired.



Make all electrical connections BEFORE applying power.

Voltage Input

Applying voltage other than the required range may cause permanent damage and VOID WARRANTY.

WARNING! Infrared light is not visible.

Do not view directly with optical instruments (magnifiers) or stare directly into the illuminator at a close distance.

Do not attempt to open or modify the light as this will void the warranty.

If you need a modification, electric or physical, contact us directly. We will let you know if it can be done. All changes MUST be made at our factory.

QUESTIONS ? (801) 519-0500 or support@axtontech.com | axtontech.com

801 Robinson Drive, Suite 500, North Salt Lake, UT 84054 sales@axtontech.com



