



AzureWave AW-XH323-SUR Wi-Fi Bluetooth 5.2 Combo SIP Module User Guide

[Home](#) » [AzureWave](#) » AzureWave AW-XH323-SUR Wi-Fi Bluetooth 5.2 Combo SIP Module User Guide 



AW-XH323-SUR
IEEE 802.11 a/b/g/n/ac/ax Wi-Fi + Bluetooth 5.2 Combo SIP Module
Reference Design Guide
Rev. 01
(For Standard)

Contents


[1 Revision History](#)

[2 Documents / Resources](#)


[2.1 References](#)

Revision History

Version	Revision Date	Description	Initials	Approved
1	2023/02/06	• Initial Version	Barry Tsai	N.C. Chen



BT_REG_ON must be connected to an external GPIO control pin.



The information contained herein is the exclusive property of AzureWave and shall not be distributed, reproduced, or disclosed in whole or in part without prior written permission of AzureWave.

Documents / Resources

	AzureWave AW-XH323-SUR Wi-Fi Bluetooth 5.2 Combo SIP Module [pdf] User Guide AW-XH323-SUR Wi-Fi Bluetooth 5.2 Combo SIP Module, AW-XH323-SUR, Wi-Fi Bluetooth 5.2 Combo SIP Module, Bluetooth 5.2 Combo SIP Module, Combo SIP Module, SIP Module, Module
---	---

References

- [User Manual](#)