



## b m 373379 Mini Vlogging Tripod Instructions

[Home](#) » [b m](#) » b m 373379 Mini Vlogging Tripod Instructions 

### Contents

- [1 b m 373379 Mini Vlogging Tripod](#)
- [2 Instructions for use](#)
- [3 Safety Instructions](#)
- [4 Product View](#)
- [5 INSTRUCTIONS FOR USE](#)
- [6 Cleaning and Maintenance](#)
- [7 Specifications](#)
- [8 EC Declaration](#)
- [9 Documents / Resources](#)
- [10 Related Posts](#)



**b m 373379 Mini Vlogging Tripod**



## Instructions for use

Please read these instructions thoroughly before use and retain for future reference.

### Getting started

Remove the Mini Vlogging Tripod from the box.

Remove any packaging from the product.

Place the packaging inside the box and store for safekeeping.

### In the box

Mini Vlogging Tripod

Instruction Manual

## Safety Instructions

Please read all instructions carefully before using the item and retain them for future reference. If you pass the item onto another person ensure that you also pass these instructions too.


When using this unit, basic safety precautions should always be followed:

- Ensure all parts are correctly assembled and the product is placed on a level surface.
- This unit is not a toy.
- This unit contains no user-serviceable parts. If the unit and any of its accessories are malfunctioning or it has been dropped or damaged, only a qualified person should carry out repairs. Improper repairs may place the user at risk of harm.
- Keep the unit out of reach of children.
- Keep the unit away from heat or sharp edges that could cause damage.
- Keep the unit away from heat sources, direct sunlight, humidity, water, and any other liquid.
- Keep the unit free from dust, lint, etc.
- Do not operate the unit in water or any other liquid.
- Do not operate the unit with wet hands.
- Do not operate the unit if it has been exposed to water, moisture, or any other liquid, to prevent electric shock, explosion, and/or injury to yourself and damage to the unit.
- Do not use the unit for anything then its intended use.
- Do not store the unit in direct sunlight or in high humidity conditions.
- Do not put objects into any of the openings.

- Do not short-circuit.
- Do not stack up with another electrical or electronic device (s) to avoid overheating.
- Do not overload the unit.
- This unit is intended for domestic use only. It should not be used for commercial purposes.
- Don't expose to extreme temperatures of hot or cold. For example, do not leave it in a parked car where it could get very cold in winter or very hot in summer.

**Warning: Keep the unit away from flammable materials.**

**Product View**



1	<ul style="list-style-type: none"> <li>• LED Selfie Light</li> </ul>	Used for lighting.
2	ON/OFF Button	To turn the LED selfie light on / off.
3	Adjustable Phone Holder	To grip the phone securely.
4	Nut	Tighten at the desired angle.
5	Tripod	Adjustable tripod legs for stability.
6	Battery Compartment	2 x AAA battery to supply power (AAA batteries not included.).

**INSTRUCTIONS FOR USE**

## **Install the Phone Clips**

- Open the package and take out the main body and phone clips.
- Unscrew the nut and fit the phone clips in, tighten the nut clockwise.

## **Selfie Light**

- Place 2 X AAA batteries(not included) into the rear compartment of the item. Extend all 3 legs to stand the tripod up.
- Place your device in the cradle in the horizontal position.
- Adjust the tripod legs as desired.
- Press the power button 3 times to adjust brightness and 4 times to turn the light completely off.

## **Cleaning and Maintenance**

**If necessary, please use a soft cloth to clean the item.**

- Do not expose the item to liquid, moisture or humidity.
- Do not use any abrasive cleaning solvents to clean the item, as this can cause damage.
- Do not expose the item to sharp objects, which may cause damage.
- Do not expose the item to extremely high or low temperatures.
- Do not drop the item.
- Do not attempt to disassemble the item, as this may cause damage to the unit.
- Do not dispose of the item in the fire.

## **Storage**

Before storing the item, ensure that it is clean and dry. Store in a cool and dry place. Please remove the batteries when the item is not in use.

## **Do's and Don'ts**

Read the following recommendations before using the item. Following these, you will be able to enjoy the product for many years.

- Avoid direct spray of liquids. Do not immerse in any liquids.
- Don't use abrasive cleaning solvents to clean the item.
- Do not expose the item to extremely high or low temperatures as this will shorten the life of electronic devices, distort certain plastic parts.
- Don't dispose of the item in a fire as it will result in an explosion.
- Don't expose the item to contact with sharp objects as this will cause scratches and damage.
- Don't let the item drop onto the floor. The internal circuitry might get damaged.
- Don't attempt to disassemble the item as it may get damaged if you are not professional.
- Do not expose the item to heat or fire. Avoid storage in direct sunlight.
- Do not subject the item to mechanical shock.
- Do not add any fluids or solids to your item.
- Do not use the product if it has been damaged in any way.

## Specifications

Model Number	373379
Battery Type	2xAAA Batteries (not included)
Input	3.0V
LED Light Power	2.4W
Lumens	25lumens
Color Temperature	6500-7000K
Phone Tongs Dimension	52mm-83mm
Weight	99g

## EC Declaration

This product is intended for use within UK

This product complies with the below listed EU Directives

2014/30/EU Electromagnetic Compatibility Directive

2011/65/EU Restriction of Hazardous Substances

2001/95/EC General Product Safety Directive

The complete declaration of conformity is available upon request for relevant inquiries.

### Information on Waste Disposal for Consumers of Electrical & Electronic Equipment

This mark on a product and/or accompanying documents indicates that when it is to be disposed of, it must be treated as Waste Electrical & Electronic Equipment (WEEE).


Any WEEE marked waste products must not be mixed with general household waste, but kept separate for the treatment, recovery and recycling of the materials used.

For proper treatment, recovery and recycling; please take all WEEE marked waste to your Local Authority Civic waste site, where it will be accepted free of charge. If all consumers dispose of Waste Electrical & Electronic Equipment correctly, they will be helping to save valuable resources and preventing any potential negative effects upon human health and the environment, of any hazardous materials that the waste may contain.

Made in China

B&M Retail Limited, Dakota Drive, Speke, Liverpool, L24 8RJ, UK Centz Stores 7 Limited, 5 Old Dublin Road, Dublin, A94 K1H5, Ireland

## Documents / Resources

	<a href="#">b m 373379 Mini Vlogging Tripod</a> [pdf] Instructions 373379, Mini Vlogging Tripod
---	--