



B O W HW315 Ergonomic Keyboard User Manual

[Home](#) » [B O W](#) » B O W HW315 Ergonomic Keyboard User Manual 

Contents

- [1 BOW HW315 Ergonomic Keyboard](#)
- [2 Package Content](#)
- [3 System](#)
- [4 Illustration](#)
- [5 The Keyboard Function](#)
- [6 Instruction](#)
- [7 FCC](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)

B.O.W[®]

BOW HW315 Ergonomic Keyboard



Package Content

- keyboard
- Manual 1
- Built-in Lithium Battery






















System

Windows/ Mac/ Android / 10S

Illustration



The Keyboard Function

| Icon | Bluetooth (IOS) | Bluetooth (MAC) | Bluetooth (Windows/Android) | Icon | Bluetooth (IOS) | Bluetooth (MAC) | Bluetooth (Windows/Android) |
|---|-------------------|-------------------|-----------------------------|---|-----------------|-----------------------------|----------------------------------|
|  | Brightness - | Brightness - | Brightness - |  | Brightness + | Brightness + | Brightness + |
|  | Windows | Windows Preview | Windows |  | Recent Windows | Application Shift (Win+Tab) | Windows Preview(Not for Android) |
|  | Non-function | Desktop | Desktop |  | Search | Search | Search |
|  | Previous | Previous | Previous |  | Volume + | Volume + | Volume + |
|  | Next | Next | Next |  | Volume - | Volume - | Volume - |
|  | Play/Pause | Play/Pause | Play/Pause |  | Select All | Select All | Select All |
|  | Copy | Copy | Copy |  | Paste | Paste | Paste |
|  | Cut | Cut | Cut |  | Mute | Mute | Mute |
|  | F1-F12 Lock | F1-F12 Lock | F1-F12 Lock |  | Home | Non-function | Home |
|  | Screen Shot | Screen Shot | Screen Shot |  | Lock Screen | Lock Screen | Lock Screen |
|  | Backlight Control | Backlight Control | Backlight Control | | | | |
| | | | | | | | |
| All Functions can work by single key as default; F1-F12, tap any one can be locked. | | | | | | | |

Instruction




Charge Mode

Connected the keyboard to the USB port with cable for charging. Indicator light turns red when charging, Indicator light turns green when full charged.

Device Switch

Turn on the keyboard, tap the device button (1.2.3) can switch device connection.

The upper right corner on the keyboard:

-  Device 1 (2.4G receiver mode)
-  Device 2 (Bluetooth mode 1)
-  Device 3 (Bluetooth mode 2)

Code Matching Mode

Device 1: Tap device 1 and plug the receiver into USB port[2.4g mode has matched before delivery). You can set




as following if it doesn't work. Plug the receiver into USB port and press ESC+ 3s, then you can match the code. Device 2: Tap device 2, the corresponding light flashes, then press device 2 (about 3s), the indicator light

flashes faster. The keyboard “BT4.0+2.4G KB” can be searched in your device. You can use the keyboard when connected successfully. Device 3: Tap device 3, the corresponding light flashes, then press device 3 (about 3s), and the indicator light flashes faster. The keyboard “BT4.0+2.4G KB” can be searched in your device. You can use the keyboard when connected successfully.

Backlight ON/OFF



Tap  can turn on/off the light and control the brightness.

Battery Detection

“Please charge in time when the battery voltage is less than 3.2V (indicator light flashes red).”

FCC

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference
2. this device must accept any interference received, including interference that may cause undesired operation.

Documents / Resources



[B O W HW315 Ergonomic Keyboard](#) [pdf] User Manual

HW315, 2AKHJ-HW315, 2AKHJHW315, Ergonomic Keyboard, HW315 Ergonomic Keyboard, Keyboard