



## BaByliss AS774E Multi Styles Hydro Fusion User Manual

[Home](#) » [BaByliss](#) » BaByliss AS774E Multi Styles Hydro Fusion User Manual 

**BaByliss AS774E Multi Styles Hydro Fusion**



## Contents

- 1 INSTRUCTIONS FOR USE
- 2 Changing the Attachments
- 3 Large Oval Volumising & Shaping Brush Attachment
- 4 Drying Nozzle Attachment
- 5 Straightening Brush Attachment
- 6 Smoothing Cushion Brush Attachment
- 7 Heat Settings
- 8 Advanced Plasma Technology with Dual Ionic System
- 9 CARE & MAINTENANCE
- 10 Cleaning the Rear Filter
- 11 Documents / Resources
- 12 Related Posts

## INSTRUCTIONS FOR USE

- Ensure the hair is 80% dry and combed through to remove any tangles. Divide the hair into sections ready for styling.
- Secure the selected attachment onto the handle. To interchange between the attachments, refer to the 'Changing the Attachments' section.
- Slide the switch to the heat setting suitable for your hair type to turn the appliance on. Please note: The blue LED light will illuminate to indicate the ionic feature is activated.
- After use, slide the switch to the '0' position to switch off and unplug the appliance.
- Allow the appliance to cool before storing away.

## **Changing the Attachments**

- Place the attachment onto the handle and line up the two indents with the buttons on the handle.
- Push the attachment onto the handle until it clicks into place.
- To remove an attachment, press and hold the two buttons on the side of the appliance and pull the attachment away from the handle.

## **Large Oval Volumising & Shaping Brush Attachment**

- Place the brush head underneath a section of hair, close to the scalp and hold for a few seconds to boost volume at the roots.
- Use the brush head to lift the hair at the roots as you dry.
- Slowly move the brush head down through the hair, as you reach the end of the hair section, rotate the airstyler slightly towards your face to curl the ends under.
- For a lasting style, select the cool setting '\*\*' on warm hair whilst holding the brush head at the roots.
- Repeat for each section of hair.

## **Drying Nozzle Attachment**

- Use the drying nozzle attachment to remove excess moisture prestyling by directing the airflow onto the hair and moving the airflow around the head.

## **Straightening Brush Attachment**

- Place the brush head under a section of hair, close to the scalp with the firm bristles pointing upwards.
- Use your other hand to pull the hair section taut against the brush head until the firm bristles penetrate through the hair.
- Gently glide the brush head through the section creating tension and control through the hair to straighten the section.
- As the brush head nears the end of the hair section, turn the brush head under to give shape at the ends of the hair.
- For added control, place your other hand over the brush head as you glide down the hair

## **Smoothing Cushion Brush Attachment**

- Place the brush head under a section of hair, close to the scalp with the soft flexible bristles pointing upwards.
- Use your other hand to pull the hair section taut against the brush head until the bristles penetrate through the hair.
- Gently glide the brush head through the section of hair to remove knots and curls and smooth as you dry.
- For added control, place your other hand over the brush head as you glide down the hair section.
- To finish your style and smooth the top of the hair, place the brush on the top of the hair section and brush as normal.
- Repeat for each section of hair.

## Heat Settings

There are 2 heat settings plus a cool setting. Use the cool setting on warm hair to set your style. Slide the switch to the first position to select the cool setting ‘\*’, the second position for the low heat ‘I’, and the third position for the high heat ‘II’.

If you have delicate, fine, bleached or coloured hair, use the lower heat setting. For thicker hair, use the higher heat setting.

## Advanced Plasma Technology with Dual Ionic System

The moisture balancing dual ionic system combines both positive and negative ions, that work together to hydrate the hair and to eliminate frizz as you dry

## CARE & MAINTENANCE

To help keep your appliance in the best possible condition, follow the steps below:

- Ensure the appliance is switched off, unplugged and cool. To clean the outside of the appliance, wipe with a damp cloth. Make sure that no water enters the appliance and it is completely dry before use
- Do not wrap the lead around the appliance, instead coil the lead loosely by the side of the appliance.
- Do not use the appliance at a stretch from the power point.
- Always unplug after use

## Cleaning the Rear Filter

- Ensure the appliance is switched off, unplugged and cool.
- Using a soft brush, clean any hair and other debris from the filter.



BABYLISS SARL  
ZI du Val de Calvigny  
59141 Iwuy  
France

[www.babyliss.com](http://www.babyliss.com)

FAC 2022/07  
Made in China

Fabriqué en Chine  
AS774E – B79a

# *BaByliss*®

## Documents / Resources



[BaByliss AS774E Multi Styles Hydro Fusion](#) [pdf] User Manual

AS774E Multi Styles Hydro Fusion, AS774E, Multi Styles Hydro Fusion, Multi Styles Fusion, Hydro Fusion, Fusion

[Manuals+](#)