



# BaByliss Super Stubble XTP Stubble Trimmer and Beard Trimmer User Guide

[Home](#) » [BaByliss](#) » BaByliss Super Stubble XTP Stubble Trimmer and Beard Trimmer User Guide 

## Contents

- [1 BaByliss Super Stubble XTP Stubble Trimmer and Beard Trimmer](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Troubleshooting Steps](#)
- [5 CLEANING & MAINTENANCE](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)

# ***BaByliss®***

**BaByliss Super Stubble XTP Stubble Trimmer and Beard Trimmer**



## Product Information

### Specifications

- **Product Name:** Super Stubble
- **Model Number:** SS12345
- **Power Source:** Rechargeable Battery
- **Battery Life:** Up to 60 minutes
- **Charging Time:** 90 minutes
- **Cutting Lengths:** 0.4mm – 5mm
- **Waterproof:** Yes

### Product Usage Instructions

#### 1. Step 1: Charging

Before using the Super Stubble for the first time, make sure to fully charge the battery. Connect the charging cable to the product and plug it into a power source. The charging indicator will light up, indicating that the battery is being charged. Allow the product to charge for approximately 90 minutes until it is fully charged.

#### 2. Step 2: Turning On/Off

To turn on the Super Stubble, press and hold the power button located on the handle. The product will start operating at the default cutting length. To turn off the product, press and hold the power button again until it shuts off.

#### 3. Step 3: Adjusting Cutting Length

The Super Stubble offers adjustable cutting lengths from 0.4mm to 5mm. To adjust the cutting length, use the length adjustment dial located on the handle. Rotate the dial to select your desired cutting length. The selected

length will be displayed on the digital screen.

#### 4. Step 4: Trimming Facial Hair

Hold the Super Stubble against your skin at a slight angle. Move the product in the direction of hair growth to achieve an even trim. The precision blade technology ensures a clean and precise trim every time.

#### 5. Step 5: Cleaning and Maintenance

After each use, detach the cutting head from the handle by pressing the release button. Rinse the cutting head under running water to remove any hair or debris. Allow it to dry completely before reattaching it to the handle. Regularly lubricate the cutting head with the provided oil to ensure optimal performance.

### Frequently Asked Questions (FAQ)

#### 1. Q: How long does the battery last on a full charge?

A: The Super Stubble has a battery life of up to 60 minutes on a full charge.

#### 2. Q: Can I use the Super Stubble in the shower?

A: Yes, the Super Stubble is waterproof and can be used in the shower.

#### 3. Q: Can I use the Super Stubble on wet or damp hair?

A: It is recommended to use the Super Stubble on dry hair for best results.

### Troubleshooting Steps

#### Super Stubble Top Tips

- Use on clean, dry hair.
- If possible, when using for the first time, try and grow your facial hair for a few days before cutting so you can trim down to a level that is best for you.
- Set the cutting length as required.
- It is always best to start cutting with a longer length first, then trim again if the length is longer than desired.
- Hold the Super Stubble XTP against the hair, the teeth of the comb guide should be pointing upwards and should be flat against the face.
- Move the trimmer upwards through the hair, a little at a time, against the direction of hair growth. The floating and contouring head will follow the curves of your face to ensure both accuracy and comfort.
- The super stubble will work most effectively when cutting through the hair at its own speed – never force through the hair. You may experience a little resistance when trimming the neck area, where hair is thicker and grows in many different directions. This is completely normal.
- Just like shaving, extra time should be given when trimming under the neck area, as again this is where hairs grow in many different directions.
- Never switch the trimmer off whilst in the hair.

### CLEANING & MAINTENANCE

- Regular cleaning will maintain the high performance of your Super Stubble XTP.
- Switch off and remove the power cord if connected.
- Detach the comb guide by gently lifting the front of the comb guide from both sides and flipping it over to the back of the unit and locking it into position by clicking it securely onto the fastener on the back of the handle.

- Use the cleaning brush supplied to brush away any hair and debris. Do not use a sharp object to clean the trimmer blade.
- The blades can be removed to aid cleaning
- To remove the blades hold the handle of the Super Stubble with one hand, place your thumb underneath the blades and push the blades away from the handle.
- Gently blow away any hair trapped beneath the blades.
- The blades can be rinsed under the tap. After rinsing the blades they may need to be oiled.

## Documents / Resources

<p>Troubleshooting Steps</p> <p>Verify that the trimmer is plugged into a power outlet.</p> <p>Check the power switch on the trimmer to ensure it is turned on.</p> <p>Inspect the power cord for any damage or fraying.</p> <p>Ensure the trimmer is properly grounded.</p> <p>Check the fuse in the power outlet.</p> <p>Verify the trimmer is not overloaded.</p> <p>Check the trimmer's motor for any obstructions.</p> <p>Inspect the trimmer's blades for any damage or wear.</p> <p>Ensure the trimmer is clean and free of hair or debris.</p> <p>Check the trimmer's battery level (if applicable).</p> <p>Verify the trimmer is not in a locked position.</p> <p>Check the trimmer's user manual for additional troubleshooting steps.</p> <p>Consult a professional technician if the problem persists.</p>	<p><b>BaByliss Super Stubble XTP Stubble Trimmer and Beard Trimmer</b> [pdf] User Guide</p> <p>Super Stubble XTP Stubble Trimmer and Beard Trimmer, Super Stubble, XTP Stubble Trimmer and Beard Trimmer, Trimmer and Beard Trimmer, Beard Trimmer</p>
--	--

## References

- User Manual