



BadZwo Baader Steeltrack Zwo EAF Halter Bracket Instruction Manual

[Home](#) » [BadZwo](#) » BadZwo Baader Steeltrack Zwo EAF Halter Bracket Instruction Manual 

Contents

- [1 BadZwo Baader Steeltrack Zwo EAF Halter Bracket](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Installation instructions](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)

BadZwo

BadZwo Baader Steeltrack Zwo EAF Halter Bracket



Product Information


Product Name: BadZwo – Baader Steeltrack Zwo EAF Halter/Bracket

Product Usage Instructions


1. Mount the 5 to 7mm flexible coupling with two set screws. Make sure not to tighten this one.
2. Turn the motor into the correct position by using the focuser knob on the right side.
3. Push the bracket a little bit against the motor and tighten (with a bit of force!) the three M6 screws including washers.
4. Use the M4 screws (Orig. EAF) including washers to tighten the motor (with a bit of force!).
5. The assembly is now complete.

Installation instructions


- Remove the three slotted set screws; Remove the thumb screw; Remove the focuser knob on the left side (two set screws 90° position)




- Mount the 5 to 7mm flexible coupling with two set screws




- Mount the bracket with M6 screws and washers (do not tighten) incl. the thumb screw (do not tighten this one)




- Mount the motor with the flexible coupling (two set screws 90° position), use the focuser knob on the right side to turn the motor, if necessary



- Turn the motor into the correct position while using the focuser knob on the right side



- Push the bracket a little bit against the motor and tighten (a bit of force!) the three M6 screws incl. washers; Use the M4 screws (Orig. EAF) incl. washers to tighten the motor (a bit of force!)



Documents / Resources

	BadZwo Baader Steeltrack Zwo EAF Halter Bracket [pdf] Instruction Manual Baader Steeltrack Zwo EAF Halter Bracket, Baader Steeltrack, Zwo EAF Halter Bracket, Halter Bracket, Bracket
--	--

References

- [User Manual](#)