



# Bakker Elkhuisen HQ48DI UltraBoard 950 Compact Keyboard User Manual

[Home](#) » [BAKKER ELKHUIZEN](#) » Bakker Elkhuisen HQ48DI UltraBoard 950 Compact Keyboard User Manual 

## Contents

- [1 Bakker Elkhuisen HQ48DI UltraBoard 950 Compact Keyboard](#)
- [2 PRODUCT OVERVIEW](#)
- [3 Overview UltraBoard 950](#)
- [4 Getting Started](#)
- [5 How to use Fn key with numpad & multimedia keys](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)



## Bakker Elkhuisen HQ48DI UltraBoard 950 Compact Keyboard



## PRODUCT OVERVIEW



Qwerty




The UltraBoard 950 in short Thank you for purchasing the Ultraboard 950 Compact Keyboard. This space-saving keyboard is designed for Windows based PC's. We sincerely hope you will enjoy using the Ultraboard 950. This quick-start guide will help you configure and use your new keyboard. Here are a few features of the UltraBoard 950:

- Space-saving compact design.
- Wired keyboard
- Connect peripheral devices via the 2 port USB hub.
- Scissor action keys with a finger friendly surface for high comfort and reduced tiredness when typing.
- Ultra-thin and height adjustable for enhanced comfort.
- 4 shortcut keys, Home, Mail, PrtScr and NumLock for fast working.
- Integrated multimedia keys.

To extend the life of the UltraBoard 950, we recommend that you use the supplied case when you store your UltraBoard 950.

### Overview UltraBoard 950

1. Hotkeys
2. Status LEDs
3. Integrated NumLock keys
4. Multimedia keys
5. Height adjustable feet
6. USB Hub



## Getting Started

1. Connect the Ultraboard Compact keyboard to your PC with the integrated USB plug.
2. This keyboard is “plug & play” so wait for a few seconds for your computer to detect the device and then you’re free to start typing. (Please note that the first time you connect your new keyboard, your operating system automatically installs the required driver. This process can take a few seconds.)

## How to use Fn key with numpad & multimedia keys

### Numpad

Ensuring NumLock is ON holding the Fn key will activate the small light blue numbered keys for use.



### Multimedia toetsen

Function keys of F7, F8, F9, F10, F11, F12 keys support Windows for multimedia use. Hold the Fn key and press F7 to F12 to use these functions.

- F7 Previous Track
- F8 Play/ Pause
- F9 Next Track
- F10 Mute
- F11 Volume Down

### LED indication



#### LED (Green)

Power on – LED in solid green when Keyboard is active

#### LED 1 (Green)

NumLock – LED in solid green when NumLock is active

#### LED A (Green)


CapsLock – LED in solid green when CapsLock is active

### BakkerElkhuizen

Taalstraat 151  
5261 BC Vught  
The Netherlands  
tel. +31 36 546 7265  
email. [info@bakkerelkhuizen.com](mailto:info@bakkerelkhuizen.com)

All rights reserved. All trade names are registered trademarks of the respective manufacturers. All specifications are subject to subject to change without notice.

**Documents / Resources**

	<p><a href="#">Bakker Elkhuisen HQ48DI UltraBoard 950 Compact Keyboard</a> [pdf] User Manual HQ48DI UltraBoard 950 Compact Keyboard, HQ48DI, UltraBoard 950 Compact Keyboard, 950 Compact Keyboard, Compact Keyboard, Keyboard</p>
---	--