



BALINGTECH 9Is25 Garbage Basket Automatic Sensor Instruction Manual


[Home](#) » [BALINGTECH](#) » BALINGTECH 9Is25 Garbage Basket Automatic Sensor Instruction Manual 

BALINGTECH

Thanks for purchasing a Sensor Bin!
**CARE AND USE
INSTRUCTIONS**



Please read carefully



Contents

- [1 CARE&USE](#)
- [2 OPERATING INSTRUCTIONS](#)
- [3 INDICATOR LIGHTS](#)
- [4 BATTERIES](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

CARE&USE

Do not apply any external power to the lid when it is in use.

Do not press the lid when it is opening.

Do not manually open the lid as it may damage it.

ONLY use type AA batteries and remove them once they have run out to prevent leakage. If the bin fails to operate normally it may mean the Batteries are running low or need replacing. Please avoid mixing brands or using old batteries. Please recycle used batteries responsibly.

Avoid staying in sensing mode for an unduly long time to prolong the life of the motor and batteries.

Do Not use water to rinse the bin lid or battery compartment. You can wipe it with a slightly damp cleaning cloth when the power is off.

DO NOT IMMERSE IN WATER.

Do not use harsh abrasive detergents or scouring pads to clean the main body. Avoid using the bin in a moist or steamy environment. Keep the lid sensor away from direct sunlight or lamplight.

Do not place the bin close to high-Frequency electronic products i.e: microwave ovens, energy saving lamps, or remote controls, etc.

Avoid placing the bin in a contained space and ensure that any obstacles don't block the lid sensor within a 2-meter distance.

OPERATING INSTRUCTIONS



Open the cover of the battery case at the bottom of the bin lid and insert 2xAA batteries(not included) . Ensure the batteries are inserted correctly(+/-) as indicated. Replace the battery cover



Push the retaining ring onto the bin body, making sure the liner edges are tucked inside the bin and are neatly concealed and secure It in position.

Turn on the power switch next to the battery compartment. The red indicator light will be



To open the bin, hold your hand 5-15cm in front of the lid and it will automatically open within half a second. Once your hand is removed from the sensor area, it will automatically close within 5-6 seconds.


INDICATOR LIGHTS

The indicator light flashes red (every seventeen seconds) .
When the lid opens, the indicator light shows red.
When the lid closes, the indicator light shows red.
Keeping your hand within the sensor area will keep the lid open.
Keeping your hand within the sensor area will keep the lid open.

BATTERIES

The batteries can last 3.6months based on the bin lid opening and closing 20 times a day.

Documents / Resources

	BALINGTECH 9Is25 Garbage Basket Automatic Sensor [pdf] Instruction Manual 9Is25, Garbage Basket Automatic Sensor, 9Is25 Garbage Basket Automatic Sensor, Basket Automatic Sensor, Automatic Sensor, Sensor
---	---

[Manuals+.](#)