

BAM Tablet Computer Series



BAM Tablet Computer Series User Manual

[Home](#) » [BAM](#) » BAM Tablet Computer Series User Manual 

Contents

- 1 [BAM Tablet Computer Series](#)
- 2 [Product Information](#)
- 3 [Product Usage Instructions](#)
- 4 [Application](#)
- 5 [Apps Install and manage](#)
- 6 [Problem solution](#)
- 7 [Documents / Resources](#)
 - 7.1 [References](#)
- 8 [Related Posts](#)

BAM

BAM Tablet Computer Series



Product Information

Specifications:

- **Input:** DC 5.0V/2000mA
- **FCC ID:** 2BGOA-TABLETQ8
- **FCC Compliance:** Part 15 of FCC Rules
- **SAR Limit:** 1.6W/kg

Product Usage Instructions

Charging the Device:

To charge the device, connect the provided DC charger with an output of DC 5.0V/2000mA to the device's charging port.

Powering On/Off:

To power on the device, press and hold the power button for a few seconds until the device starts up. To power off, press and hold the power button again and follow the on-screen prompts.

Wireless Connectivity:

To enable wireless connectivity, navigate to the device's settings menu and turn on the Wi-Fi or Bluetooth feature as needed. Follow the on-screen instructions to connect to available networks or devices.

Compliance Information:

Ensure that any modifications or changes to the device are approved by the relevant authorities to maintain compliance with FCC regulations regarding interference and radiation exposure.

FAQ

- **Q: What should I do if the device does not power on?**
 - **A:** Make sure the device is adequately charged by connecting it to a power source using the provided charger. If the issue persists, contact customer support for assistance.
- **Q: How can I check the device's FCC compliance?**
 - **A:** You can verify FCC compliance by checking the device's ID mentioned in the product information section. Ensure that any modifications are approved to maintain compliance.

Attention:

This handbook contains important security measures and the correct use of the product information, in order to avoid accidents. Please make sure to read the manual carefully before use the device.

- Please don't be in high-temperature moisture or very dusty place
- Please don't be in high temperatures, Especially in summer don't put the device in the car when Windows closes.
- Avoid fall or Violent collisions of the device, and don't make the TFT display screen were violent tremor, This could cause TFT display screen abnormal or damaged.
- Please choose the appropriate volume, Use headphones that should not be too big volume, If feel tinnitus, Lower the volume or stop using it
- please charge In the following condition.

A. The battery power ICONS shows has no power

B. The system automatically shut off, startup after power off soon Operation buttons no response

C. Operation buttons no response

D. The machine that the top right corner shows red icons


- When the device in the format or ongoing upload and download file, please don't suddenly disconnect This could cause an application error.
- For those who because of damage to the product repair, or other causes of erased the memory, The Company shall not be liable for any responsibility, please follow the user manual for the standardized operation to use the device
- Don't disassemble the product, ct, don't use alcohol, Thinner or benzene to scrub products
- Don't use the device one of the places prohibited to use of electronic equipment in the region (such as the plane)
- Please don't use the Tablet PC when you in driving or walking down the street.
- USS just only be used for data transmission

The company reserves the right to improve the product, product specification and design have any change. The information is subject to changes without prior notice.

(This tablet is no waterproof function)

[Remark] All pictures in this manual is just for your reference. products specification and design have any change, The information is subject to changes without prior notice.

DESK



Touch panel

Capacitive touch panel: In The Operation, to click, drag on the touch panel

POWER

startup: Long Press and hold the power button, and the system will enter the main interface

shutdown: In the main menu interface, Press the power button for about 5 seconds to shut down, The system can hint "power off" option, and click "OK". you can safely shut down.

Lock screen: Short press the Power button to lock the screen or unlock the screen.

Remark

1. When power is empty, the system will shut down automatically.
2. Illegal turn off the device, restart will scan and restore the disk, it may take longer time to enter into the system

BACK

Short Press the BACK button will return the last interface.

MIC

Recording

Volume+, Volume- the buttons on top Volume+, Volume- achieve changes in the volume.
6 earphone jack. 5 mm standard earphone jack

Video output interface

HDMI output interface

TF card

TF-CARD slot: external T-FLASH card

Mini USB

MiniUSB jack: you can use it to connect the computer for data transmission, charging and external connection USB flash drive

DC Adapter

For charging. your tablet battery

Recovery

When the Tablet is under the condition of a crash, upgrade firmware.

First use

Battery management and charge

Before first use, please set the device's battery is fully charged Just need to connect the adaptor or USB interface, then you can charge

The first two times charging please keep about 6 hours, after that, you just need 4 hours to charge.

choose standard adaptor: A 20/50/62 Car 0 34 0 bit:

0.3A. Output:

DC5.0/2000mA), this device does not supply DC charging, USB interface can charge, Choose the USB interface to charge

During the charging, the battery icon will scroll

When finished charging, the battery icon will become green and stop rolling


In order to prolong the service life of the machine, suggest using battery power before charging it [Remark

1. If you long time don't to use this Tablet, in order to avoid power consumption caused damage, pls charge/play the battery once a month
2. After low battery shut down. connect DC adaptor, device will remain low battery, charging, need to wait some

time until the battery is enough power to enter into main menu.

3. Device charging should be in standby status for reach normal charging time. Because with device and screen consumption, it may cause longer charging. time.

Connection with PC




Use a USB cable to connect the device to the PC, the device will pop up the USB connection window, click Turn on USB storage to connect to the PC

Into the load mode, you can copy, or delete the file on the device and the file on the memory card.

Equipment operation interface


The main interface describe



After startup will enter the main interface


In the main interface, you can:

Management main interface software LONS long press the icons 3 seconds. after the icons will bigger, then you can drag them anywhere in the interface.



Delete icons: long press the icons 3 seconds, and drag the icons to the Recycle Bin icon. once it becomes red, Loosen your hand, after that, you can delete the icon

You touch the screen keep a time, appear the dialog box "Add yo Home screen" as shown below:



status bar describe



- The status bar above of the screen

Top left display main interface software, T-Flash card, USB connection status, and so on

The top right displays the battery, battery charge icons, current time, set time, Settings Menu, and ESC button.

Use touch panel

Device equipped touch screen. Following. The main touch screen area is described and describes some of the tips for how to use the touch screen.

No matter which interface you are on the screen can go back to the main screen by pressing the soft key



on the bottom right corner of the main screen. [Attention] The main screen soft key



functions as the

machine back key |



In different applications, by tapping the back soft key




on the bottom right corner on the touch screen you can return to is interface on the up floor.



In different applications, by tapping the menu key on the upper right corner of the touch screen, the screen will appear the operation setting interface as follows.




[Remark I The main screen soft key functions as the machine manu





In the main interface, you can touch the icon to open the APPs In different browsers (file, music, video, pictures), You shift and drag the scroll bar, so that the file list can up or down to roll.


Equipment basic set



Setting: Click setting icons , enter the setting interface



Silent mode, Volume, Notification ringtone, Audible selection, Screen lock sounds



Application

Manage applications



Unknown sources: Click "Unknown Sources", then click "Ok"


Manage application: Manager and uninstall the Application

[Remark] : when you Firmware Upgrade, pls close the USB connect

How to uninstall?




1. enter "setting" > "Application" > "Manage application" And then there will be installed the program list
2. Click you want to uninstall icons, will enter the following interface
3. Click Uninstall, then you can felete the application




Privacy

Factory data reset



Storage

Remove TF card, view of the available storage space



(Remark) : pls touch the option"delete SD card", so that can safety to remove SD card

Language & keyboard

Setting: (Language),text input and automatic error correction options;



Select Language:54 kinds of national languages are available.

Remark: The Android system can support 54 kinds of language, now menu interface just supports 14 languages.

Android keyboard: Android keyboard setting

Sound on Key-press


Auto-capitalisation

Show suggestions: Display suggested words while typing

Auto-complete: Specebar and punctuation automatically insert the highlighted word


Date & time setting

Set date, set time, Select time zone, and select date format




Developer options

Choose USB work pattern: OTG/HOST/SLAVE.....



About tablet



Apps Install and manage

App installer

This Table can support Android apps in the market by third parties, most Apps can be installed in the network, can be copied to NAND FLASH or SD card. Click the Appinstaller icon, will appear Install, manage, Exit options.

Install: Click install, and enter the APK install interface Separately for the Internal Memory disk and SD Card disk. Select the APK you would like to install, click it to install, go back to the main menu, will display the installed app you just selected.

Remark: Some 3" Apps must be installed properly by a memory card, downloaded 3" third-party app may not install properly on the device.

Manage: click manage, enter third party interface Click the install icon, will enter the Action interface

Problem solution

The device can't to open

1. Check the battery power
2. Connect the adaptor first, then check again
3. After charging then can't to open, pls contact with the supplier

After startup the screen or the opening picture appears, and the device appears shut

1. Power is not enough, please charge the Headset can't hear the voice
2. Pls check the volume whether set to 0
3. Check the music file whether damaged. Try playing other music, if the file have damaged may lead to serious noise or hop sounds.

Can copy file or play music and so on

1. Pls check between the computer and device is the correct connection
2. check the memory storage space is already full
3. check the USB cable is good or not
4. USB connection is disconnected



With call function

The company reserves the right to vary the product design Product pictures and content are for reference only, and specifications of the right, then without prior notice. Specifications appearance please to sales kind prevail.

Federal Communication Commission Interference Statement

FCC ID: 2BGOA-TABLETQ8

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential

installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Radiation Exposure Statement:

This device meets the government's requirements for exposure to radio waves, This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless devices employs a unit of measurement known as the Specific Absorption Rate or SAR. The SAR limit set by the FCC is 1.6W/kg. Tests for SAR are conducted using standard operating positions (0mm) | accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands.

Documents / Resources

 The image shows the cover of the BAM Tablet Computer Series User Manual. It features a stylized illustration of a tablet computer and a manual. The text on the cover includes 'Tablet computer series', 'The user manual', and the BAM logo with the tagline 'culture of connection'.	<p>BAM Tablet Computer Series [pdf] User Manual 2BGOA-TABLETQ8, 2BGOATABLETQ8, tabletq8, Tablet Computer Series, Tablet Computer, Tablet, Computer</p>
--	---

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.