



## BARSKA 10×30 WP Floatmaster Binoculars Instructions

[Home](#) » [BARSKA](#) » BARSKA 10×30 WP Floatmaster Binoculars Instructions 

### Contents

- [1 BARSKA 10×30 WP Floatmaster Binoculars](#)
- [2 Parts Of The Binocular](#)
- [3 Eye Adjustments](#)
- [4 Instructions For Care](#)
- [5 Cleaning](#)
- [6 LIMITED LIFETIME WARRANTY](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)



### BARSKA 10×30 WP Floatmaster Binoculars



## Parts Of The Binocular



- Right Eye Diopter
- Eyepiece
- Center Focus
- Objective Lens
- Tripod Adaptable Fitting

DO NOT use this optical product to view the Sun or any light source.

**CAUTION:** Viewing the Sun can cause permanent eye damage.

This binocular is a precision instrument designed to provide many years of pleasurable viewing. This booklet will help you achieve optimum performance by explaining how you can adjust the binoculars to your eyes, and how to care for this instrument. Read the instructions carefully before using your binoculars.

## Eye Adjustments

Fig.1 INTERPUPILLARY DISTANCE ADJUSTMENT



### HOW TO ADJUST FOR THE DISTANCE BETWEEN YOUR EYES

The distance between the eyes, called “interpupillary distance” (IPD), varies from person to person. To achieve perfect alignment of the lens to the eye, follow these simple steps.

1. Hold your binoculars in the normal viewing position.
2. Grasp each barrel firmly. Move the barrels closer together or further apart until you see a single circular field.

Always re-set your binoculars to this position before using them.

## **HOW TO ADJUST FOR INDIVIDUAL EYE STRENGTH**

Human eyes are as individual as fingerprints. This binocular has a feature that allows you to adjust the binocular to your vision. Follow the focusing instructions for your binocular style.

### **Focusing**

CENTER FOCUS has a central focusing wheel between the barrels.

1. Adjust interpupillary distance (Figure 1)
2. Keep both eyes “open” at all times.
3. Using a lens cover or your hand, cover the objective (front) the lens of the side with the “diopter setting”
4. Using the centre focus wheel, focus on the distance the object is being viewed.
5. Cover the other objective lens, then view the same object as explained above. Using the “diopter setting” adjustment ring, focus on the same object being viewed.
6. Caution should be used as over-turning or forcing the diopter eyepiece can damage or cause the eyepiece to break away from the chassis.
7. Your binocular should be adjusted for your eyes Focus at both far and near distances can now be attained simply by turning the centre focus wheel.

### **Waterproof / Fog-Proof**

Your binoculars may be designed and built utilizing the latest waterproof and fog-proof technology. This binocular is O-ring sealed for complete protection. Fog-proof protection is achieved by dry nitrogen purging to remove all internal moisture.

## **Instructions For Care**

If handled with care, this binocular will provide years of trouble-free service. Like any fine optical instrument, your binoculars should be given sensible care. Non-waterproof models should not be exposed to excessive moisture.

1. Keep the lens covers (that comes with your binoculars, except for compact models) on the lenses when binoculars are not in use.
2. Avoid banging and dropping.
3. Store in a cool, dry place.
4. Looking directly at the sun with your binoculars may be very harmful to your eyes.

### **Cleaning**

1. Blow away any dust or debris on the lens (or use a soft lens brush)
2. To remove dirt or fingerprints, clean with a soft cotton cloth rubbing in a circular motion.
3. The use of coarse cloth or unnecessary rubbing may scratch the lens surface and eventually cause permanent damage.
4. For a more thorough cleaning, photographic lens tissue and photographic-type lens cleaning fluid or isopropyl alcohol may be used. Always apply the fluid to the cleaning cloth-never directly on the lens.

### **VERY IMPORTANT**

Never attempt to clean your binoculars internally or try to take them apart.

## LIMITED LIFETIME WARRANTY

BARSKA® Optics, as manufacturer, warrants this new precision optical product to be free of original defects in materials and/or workmanship for the length of time specified by this warranty. This warranty does not include damage caused by abuse, improper handling, installation, maintenance, normal wear-and-tear, unauthorized repairs or modifications or tampering in any way. This warranty is limited to the original purchaser and is not transferable. This warranty applies only to products purchased in the United States of America.

In the event of a defect within 30 days, the consumer must return the defective unit to the BARSKA dealer (the place of purchase) at his/her own expense. Beyond 30 days, BARSKA products should be sent to the following address for warranty repairs. Products must be packed carefully and sturdily to prevent damage in transit, and returned freight prepaid to:

### **BARSKA OPTICS**

Repair Department  
855 Towne Center Drive  
Pomona, CA 91767

For additional and updated information

please visit our website at [www.barska.com](http://www.barska.com)

Please email [info@barska.com](mailto:info@barska.com) or call 1.888.666.6769 for the Return Merchandise Number (RMA#) before any returns.

### **NOTE**

All merchandise received without a valid RMA # will be returned to the shipper at his/her own expense. Please include all of the following when returning BARSKA products for service and/or replacement:


1. Please write your complete details (Name, Address, Telephone #, E-mail address, RMA#, etc.)
2. Purchase receipt or Proof of Purchase.
3. A brief explanation of the defect.
4. A Check/Money Order of \$20.00 to cover inspection, shipping and handling. Please allow 6-8 weeks for delivery.

This product will either be replaced or repaired at the discretion of the warrantor. If it's a discontinued item, we will replace the product with an equivalent product. Should the repair not be covered by this warranty, an estimate will be sent for your approval. Non-warranty repairs or refurbishing of your optical products are always provided at a reasonable cost.

BARSKA Optics shall not be liable for any consequential, incidental and/or contingent damages whatsoever. We will not pay shipping, insurance or transportation charges from you to us, or any import fees, duties and or taxes. This warranty supersedes all previous BARSKA® Optics warranties.

---

## Documents / Resources



[BARSKA 10x30 WP Floatmaster Binoculars](#) [pdf] Instructions  
10x30 WP Floatmaster Binoculars, 10x30 WP, Floatmaster Binoculars, Binoculars

## References

-  [Barska - Your Ultimate Source for Premium Safes and Outdoor Gear](#)
- [User Manual](#)

Manuals+.