



BARSKA BC445 Winbest Selfie Stick with Built In Bluetooth Shutter Button Instructions

[Home](#) » [BARSKA](#) » **BARSKA BC445 Winbest Selfie Stick with Built In Bluetooth Shutter Button Instructions** 

Contents

- [1 BARSKA BC445 Winbest Selfie Stick with Built In Bluetooth Shutter Button](#)
- [2 Notes Before Use](#)
- [3 Bluetooth Pairing](#)
- [4 Capture Images](#)
- [5 Internal Battery Indicator Light](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)



BARSKA BC445 Winbest Selfie Stick with Built In Bluetooth Shutter Button



Notes Before Use


- Read the instructions before use.
- Based on HID wireless communication technology, compatible with operating systems iOS4.0 and Android 4.0 or later.
- Turn off any other nearby bluetooth devices to avoid signal interference.
- Do not dismantle the product.
- Do not use corrosive solvents to clean the product.
- Do not charge the product in high-temperature environments or under strong light.
- Do not get the product wet or use it in damp weather conditions.
- Do not throw the product into the fire.
- Please do not drop.



Bluetooth Pairing

1. Press and hold the Bluetooth shutter button for 3 seconds, to turn the product on, the Blue LED light will flash quickly.
2. Turn on the mobile device's Bluetooth.
3. Search for the Bluetooth device named " XD-10 Selfie Stick ".
4. Click " XD-10 Selfie Stick " to pair the Bluetooth devices. No password is needed, and the LED light will flash slowly, indicating a successful pairing.

Note: The product automatically goes to standby mode within 2 minutes of activation.



Capture Images

1. After a successful pairing.
2. Carefully mount the mobile device into the cradle.
3. Activate the camera on the mobile device.
4. Extend the selfie stick to the desired length.
5. Press the Bluetooth shutter button to capture the image.
6. Press and hold the Bluetooth shutter button for 3 seconds, to turn the product off, LED light will turn off.


Internal Battery Indicator Light

When the internal battery indicator light is red this indicates that the battery is low. Place smaller end of the USB cord into the charging port and the other end to a USB power source. When fully charged the internal battery indicator light will be blue.

Working Environment Temperature	-10°C – +40°C
Working Environment Relative Humidity	10% – 90%
Charging Voltage	DC 5.0v
Charging Time	1 hour
Standby Time	100 hours

2015 BARSKA® 855 Towne Center Drive | Pomona, CA 91767 | (t) 888.666.6769 | (f) 909.445.8169 | www.barska.com

Documents / Resources

	<p>BARSKA BC445 Winbest Selfie Stick with Built In Bluetooth Shutter Button [pdf] Instructions</p> <p>BC445 Winbest Selfie Stick with Built In Bluetooth Shutter Button, BC445, Winbest Selfie Stick with Built In Bluetooth Shutter Button, Built In Bluetooth Shutter Button, Bluetooth Shutter Button, Shutter Button</p>
---	--

References

- [Barska - Your Ultimate Source for Premium Safes and Outdoor Gear](#)
- [User Manual](#)