


# **BASI ZR 319 Folding Lock with Combination Lock Instructions**

Home » BASI » BASI ZR 319 Folding Lock with Combination Lock Instructions



**BASI ZR 319 Folding Lock with Combination Lock** 




#### **Contents**


- 1 Setting The 4-digit Combination Code
- 2 Dimension
- **3 Customer Support**
- 4 Documents / Resources
  - 4.1 References
- **5 Related Posts**

# **Setting The 4-digit Combination Code**

- 1. Set the combination wheels to the basic setting 0000.
- 2. Press the red button and open the lock.
- 3. Turn the reset knob on the side 90 degrees clockwise.
- 4. Set the combination wheels to the desired combination and make a note of your new combination.
- 5. After selecting the number combination, turn the reset knob anticlockwise back to the original position. The new combination is now set.

#### **Dimension**





# **Customer Support**

BASI GmbH Germany info@basi.eu www.basi.eu



## **Documents / Resources**



BASI ZR 319 Folding Lock with Combination Lock [pdf] Instructions ZR 319 Folding Lock with Combination Lock, ZR 319, Folding Lock with Combination Lock, Lock with Combination Lock, with Combination Lock, Combination Lock

## References

- Spezialisten für Sicherheitstechnik und Schließanlagen
- User Manual

### Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.