

BASS JAXX Print LED Wireless Speaker Instruction Manual

Home » BASS JAXX » BASS JAXX Print LED Wireless Speaker Instruction Manual



Contents


- 1 BASS JAXX Print LED Wireless Speaker
- **2 Product Overview**
- 3 Pair Wireless speaker with your mobile device
- 4 Technical specification
- 5 FAQ
- **6 FCC STATEMENT**
- 7 Documents / Resources
- **8 Related Posts**



BASS JAXX Print LED Wireless Speaker



Product Overview



Package Contents

- Print LEO Wireless Speaker x 1 pc
- Micro USB Charging Cable x 1 pc
- Instruction Manual x 1pc

Power On/Off

Power on

Slide the ON/OFF switch to the "ON" position.

Power off

Slide the ON/OFF switch to the "OFF• position.

Note: Always slide the Power switch to "OFF" position when not in use.

Pair Wireless speaker with your mobile device

- 1. Keep the distance between your wireless speaker and mobile phone (or other devices) within 32.8 Feet.
- 2. Power on the wireless speaker.
- 3. Activate the Bluetooth function on your phone within range and select "BT PRT LED SPKR" from the list shown.
- 4. You will hear a beep sound when pairing Is successful.

Reconnect Wireless speaker to your mobile device

When powered on, the wireless speaker will automatically connect with the last successfully paired device.

Charging your Wireless speaker

For your safety, please always use appropriate 5V input charger/Adapter to charge the product. DO NOT USE Quick Charging USS Adapter to charge the product, as it might damage the product.

- 1. Use the Micro USB cable provided with this whreless speaker.
- 2. Connect the Micro USB plug to Micro USB charging port on the speaker, then connect the USB plug to a USB port on a computer or wall adapter to begin charging.
- 3. The light will turn red while charging and will turn off once fully charged.NOTE:
 - You must select a qualified charger from a regular manufacturer.
 - You must charge the Wireless speaker if it has been not used for more than 12 months.



Technical specification

• Driver Diameter: 45mm x2

• Impedance: 4 Ohms

• Power Supply: LI-Ion Battery 3. 7V 300 mAh Play Time: 1.5 Hours

• Charging Time: 1.5-2 Hours

• Bluetooth Range: 32.8 Feet Micro USB Cable Included

FAQ

• If the Wireless speaker cannot be paired with your device, please try the following:

Ensure that your speaker is in pairing mode or reconnection mode.

Ensure that Bluetooth search function of your mobile device is activated.

If the Wireless speaker cannot be recharged:

If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered.

Safety instructions for the lithium battery and charging the product

- The input voltage to the product is DC 5V 1A
- In order to charge the product in safe manner and reliable oonclitlons, please only adopt certified appropriate charger/ adapter for charging the product.
- Only charge the product at ambient temperatures between 10 deg "Cl 50 deg "F and 40 deg "C/104 deg "F.
- Do not heat above 70 deg "C/158 deg °F, eg. Do not expose to sunlight or throw into fire. -s,...;tch off the product after use.
- Please note that we INOfl't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this
 may result In severe Injury or loss of property, and we cannot control the operating process during the time the
 user using this product.
- In extreme cases, abuse or misuse of lithium battery pack can lead to explosion, heat generation, fire development or smoke development

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause hamiful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not Installed and used In accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause hannful interference to radio or television reception, which can be detennined by b.Jming the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement.

FCC ID: 2ADMS-SP-0908

Keep all relevant Information for future reference

Documents / Resources



BASS JAXX Print LED Wireless Speaker [pdf] Instruction Manual SP-0908, SP0908, 2ADM5-SP-0908, 2ADM5SP0908, Print LED Wireless Speaker

Manuals+,