

# **BASS JAXX Unify Multi Connection Bluetooth Speaker Instruction Manual**

Home » BASS JAXX » BASS JAXX Unify Multi Connection Bluetooth Speaker Instruction Manual



## **Contents**


- 1 BASS JAXX Unify Multi Connection Bluetooth
- **Speaker**
- **2 Product Overview**
- **3 POWER**
- 4 Multi-Connection
- **5 Technical specification**
- 6 FAQ
- **7 FCC STATEMENT**
- 8 Documents / Resources
- 9 Related Posts



# **BASS JAXX Unify Multi Connection Bluetooth Speaker**



## **Product Overview**



# **Package Contents**

#### Includes:

- 1(One) Speaker 3.5in. x 7.1in. x 3.5in. (8.9cm x 18cm x 8.9cm)
- 1(One) Charging Cable 19.7in. (50cm)
- 1(One) Instruction Manual

## **POWER**

#### Power on

Switch on the Power Button.

#### Power off

Switch off the Power Button.

**Note:** Always power off the speaker when not in use.


# Pair Wireless speaker with your mobile device

- 1. Keep the distance between your wireless speaker and mobile phone (or other devices) within 32.8 Feet.
- 2. Power on the wireless speaker.
- 3. Activate the Bluetooth function on your phone within range and select "BT UNIFY SPEAKER" from the list shown.
- 4. You will hear a beep sound when pairing is successful.

# Reconnect Wireless speaker to your mobile device

When powered on, the wireless speaker will automatically connect with the last successfully paired device.

#### **Multi-Connection**



(Need more than 1pc Unify Multi-Connection Bluetooth Speaker to perform this function.)

- 1. Make sure all Unify Multi-Connection Bluetooth Speaker are unpaired from Bluetooth devices
- 2. Turn off all Unify Multi-Connection Bluetooth Speaker.
- 3. Turn on 1pc and pair with your Bluetooth device as Host Speaker.
- 4. After the first speaker is connected to your Bluetooth device, turn on other Unify Multi-Connection Bluetooth Speakers as Branch Speaker.
- 5. Start playing music from the connected Bluetooth device, the Branch Speaker will automatically connected with the Host speaker. The LED on the Branch speakers will turns to green.
- 6. Host Speaker and Branch Speaker will start playing the music.
  Remark: for this Multi-Connection, please note only 1 Host Speaker connect with Bluetooth device. Pair both Host and Branch speakers to Bluetooth devices may cause the multi-connection function failure.

## **Charging your Wireless speaker**

For your safety, please always use appropriate 5V input charger/Adapter to charge the product. DO NOT USE Quick Charging USB Adapter to charge the product, as it might damage the product.

1. Use the Micro USB charging cable provided with this wireless speaker.

- 2. Connect the Micro USB plug to Micro USB charging port on the speaker, then connect the USB plug to a USB port on a computer or wall adapter to begin charging.
- 3. The LED Indicator will turn red while charging and will turn off once fully charged.

#### NOTE:

- You must select a qualified charger from a regular manufacturer.
- You must charge the Wireless speaker if it has been not used for more than 6 months.



# **Technical specification**

• Driver Diameter: 52 mm

• Impedance: 4 Ohms

· Power Supply:

· Li-ion Battery 3.7V 1200 mAh

• Playtime: 1.5-2 Hours

• Charging Time: 3 Hours

• Bluetooth Range: 32.8 Feet

Charging Method: USB Charging

Micro USB Charging Cable Included

# **FAQ**

## If the Wireless speaker cannot be paired with your device, please try the following:

Ensure that your speaker is in pairing mode or reconnection mode.

Ensure that Bluetooth search function of your mobile device is activated.

# If the Wireless speaker cannot be recharged:

If you use a power outlet, ensure that the power supply is connected securely and the outlet works. If you use a computer, ensure that it is connected and the USB port is powered

Safety instructions for the lithium battery and charging the product

- The input voltage to the product is DC 5V 1A.
- In order to charge the product in safe manner and reliable conditions, please only adopt certified appropriate charger/ adapter for charging the product.
- Only charge the product at ambient temperatures between 10 deg °C/ 50 deg °F and 40 deg °C/104 deg °F.
- Do not heat above 70 deg °C/158 deg °F, eg. Do not expose to sunlight or throw into fire.
- Switch off the product after use.
- Please note that we won't take any responsibility for any wrong operation (eg. Voltage higher than 5V) as this
  may result in severe injury or loss of prop control the operating process during the time the user using this
  product.

 In extreme cases, abuse or misuse of Lithium battery pack can lead to explosion, heat generation, fire development or smoke development.

### **FCC STATEMENT**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference.
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### RF warning statement:

The device has been evaluated to meet general RF exposure requirement. This equipment should be installed and operated with minimum distance 20cm between the radiator& your body.

FCC ID: 2ADM5-SP-0207B

Keep All Relevant Information For Future Reference

## **Documents / Resources**



BASS JAXX Unify Multi Connection Bluetooth Speaker [pdf] Instruction Manual SP-0207B, SP0207B, 2ADM5-SP-0207B, 2ADM5SP0207B, Unify Multi Connection Bluetooth S peaker, Unify Bluetooth Speaker, Multi Connection Bluetooth Speaker, Bluetooth Speaker, Unify Speaker, Speaker

Manuals+