



BAUHN 712239 Foldable Bluetooth Keyboard Instruction Manual

[Home](#) » [BAUHN](#) » BAUHN 712239 Foldable Bluetooth Keyboard Instruction Manual 


BAUHN® User Manual FOLDABLE BLUETOOTH® KEYBOARD TECLADO BLUETOOTH® PLEGABLE





Contents

- [1 712239 Foldable Bluetooth Keyboard](#)
- [2 Parameter specifications](#)
- [3 Product features](#)
- [4 System Switch](#)
- [5 FCC Statement](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)

712239 Foldable Bluetooth Keyboard



BUTTON

| | |
|---|--|
| OFF/ON  OFF/ON | Switch the power button to the ON position to turn on the keyboard. The red light will illuminate for 3 seconds and then turn off. Switch the power button to the OFF position to turn off the keyboard. |
| CONNE CT  Connect | Bluetooth® Connection Key: Press the key once to make the blue light blink continuously, indicating that the keyboard has entered Bluetooth® pairing mode. Once the device detects the Bluetooth® keyboard, you can proceed with the pairing connection. |

SLEEPING

If there is no key action for 10 minutes, the PCBA will enter sleep mode. After sleep mode, if a key is pressed, Bluetooth® will automatically reconnect to the previously connected host. If the host disconnects the Bluetooth® connection, the PCBA will also automatically enter sleep mode.

Once the device is successfully paired with the keyboard, the blue light will stop blinking.

Parameter specifications

Keyboard size:

open: 295 x 92 x 7.5 mm

fold: 147 x 92 x 15 mm

Sleep Mode: If there is no key input for 10 minutes, Bluetooth® will enter sleep mode and the connection will be disconnected. Wake-up from Sleep: Press any key to wake up.

Bluetooth® Version: 5.0 Operating Voltage: 3.2-4.2V

Power Supply: Lithium Polymer Battery

Continuous Working Time: 28 hours

Operating Temperature: 5°C-50°C

Charging Time: 2 hours

Working Distance: > 10m

Pairing Distance: <5m

Data Rate: 1 Mbps

Key Count: 66 keys

Compatible System








































Win /iOS /Android

Three system switching languages

iOS: control+Space key switch language


Windows: Alt+Shift switch language

Product features

| iOS/Android | | Windows | | Windows | |
|--|------------------------|--|------------------------|--|------------------------|
| Fn+ | Corresponding function | Fn+Shift | Corresponding function | Fn+ | Corresponding function |
|  `Esc | Return to Desk |  `Esc | Home Page |  `Esc | Esc |
|  1 F1 | Search |  1 F1 | Search |  1 F1 | F1 |
|  2 F2 | Select |  2 F2 | Select |  2 F2 | F2 |
|  3 F3 | Copy |  3 F3 | Copy |  3 F3 | F3 |
|  4 F4 | Stick |  4 F4 | Stick |  4 F4 | F4 |
|  5 F5 | Cut |  5 F5 | Cut |  5 F5 | F5 |
|  6 F6 | Pre-Track |  6 F6 | Pre-Track |  6 F6 | F6 |
|  7 F7 | Play/Pause |  7 F7 | Play/Pause |  7 F7 | F7 |
|  8 F8 | Next |  8 F8 | Next |  8 F8 | F8 |
|  9 F9 | Volume- |  9 F9 | Volume- |  9 F9 | F9 |
|  0 F10 | Volume+ |  0 F10 | Volume+ |  0 F10 | F10 |
|  — F11 | |  — F11 | |  — F11 | F11 |
|  + = F12 | |  + = F12 | |  + = F12 | F12 |

Tips

1. If you want the bluetooth® keyboard to match a laptop or desk computer, they should have bluetooth® device.
2. If you want to match a smart phone, it is the same way as tablet to match.
3. When you turn on the bluetooth® keyboard, no need to match again.
4. The letter? should be the same color as Fn, when you want to get Fn+? function.



1. Once the device is successfully paired with the keyboard, the blue light will stop blinking.
2. There is a tip for connecting successfully , you can use your keyboard comfortably

System Switch

Press FN+S to switch to Android system and use the Android keyboard function. The blue LED will flash three times to indicate a successful switch.

Press FN+D to switch to Windows system and use the Windows keyboard function. The blue LED will flash three times to indicate a successful switch.

Press FN+A to switch to iOS system and use the iOS keyboard function. The blue LED will flash three times to indicate a successful switch.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Made in China

DIST. & SOLD EXCLUSIVELY BY:
ALDI
BATAVIA, IL 60510
AFTER SALES SUPPORT SERVICIO POSVENTA
712239
  866-235-5029
 info@customercareusa.com
MODEL: HT720
07/2024
1
YEARS WARRANTY

Documents / Resources

| | |
|--|--|
|  | <p>BAUHN 712239 Foldable Bluetooth Keyboard [pdf] Instruction Manual 712239 Foldable Bluetooth Keyboard, 712239, Foldable Bluetooth Keyboard, Bluetooth Keyboard, Keyboard</p> |
|--|--|

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.