



# BAUHN ASPP8-0723-W 8-Way Surge Protection Power Board with USB A and C User Guide

[Home](#) » [BAUHN](#) » BAUHN ASPP8-0723-W 8-Way Surge Protection Power Board with USB A and C User Guide 

## Contents

- [1 BAUHN ASPP8-0723-W 8-Way Surge Protection Power Board with USB A and C](#)
- [2 Product Information](#)
- [3 Specifications](#)
- [4 Product Usage Instructions](#)
- [5 Have you got everything?](#)
- [6 Product Overview](#)
- [7 Troubleshooting](#)
- [8 Specifications](#)
- [9 General Safety Warnings](#)
- [10 Documents / Resources](#)
- [11 Related Posts](#)



## BAUHN ASPP8-0723-W 8-Way Surge Protection Power Board with USB A and C



## Product Information

The ASPP8-0723-W/ASPP8-0723-B is an 8-Way Surge Protection Power Board with USB A & C. It comes with a power on/off switch, active power LED indicator, surge protected LED indicator, USB-C and USB charging ports, overload circuit breaker, AC sockets, and TV line protection. The power board is designed to provide surge protection for connected devices and has a maximum energy rating of 1050J. It also features a resettable overload circuit breaker to protect against current overload at 10 amps. The power board is covered by a 1-year warranty.

## Specifications

- **Input:** AC 240V, 50Hz, 10A
- **Total Loading:** Max 10A 2400W
- **Maximum Energy:** 1050J
- **Surge Protection** Limit: 30,000A
- **USB Output:** DC 5V, 4A Total
- **Power Cable:** 1.1m
- **Mass:** 568g
- **Dimensions (W x H x D):** 310 x 120 x 33 mm


## Product Usage Instructions

1. Unpack the box and ensure that the following items are included:
  - A. 8-Way Surge Protection Power Board with USB A & C
  - B. User Guide
  - C. Warranty Certificate
2. Connect the power board to an AC power source using the provided power cable.
3. Press the power on/off switch to supply or cut off power to the outlets.
4. Check the active power LED indicator. A lit green light indicates that the power board is active and ready for use.
5. Connect your devices to the surge-protected AC sockets. All 8 sockets are interchangeable and provide surge protection.
6. Use the USB-C and USB charging ports to charge phones, tablets, or other devices.
7. If there is no power output from any of the sockets, troubleshoot the issue by contacting the After Sales Support at 1300 002 534.
8. If there is no output from the USB ports, check the connected devices and cables. Ensure that they are compatible and functioning properly.
9. In case the power board is not turning on, verify the connection to the AC power source and ensure that the power switch is in the “on” position.
10. If you have connected a TV line, ensure that it is protected against power surges using the TV line protection feature.
11. Ensure not to exceed the maximum load of 2400W and 10A. If exceeded, unplug some devices and press the overload reset button.
  - If you have any further questions or need assistance, contact the After Sales Support during operating hours: Monday-Friday, 8:30am-6pm; Saturday, 9am-6pm AEST.
  - Remember to responsibly dispose of the product and packaging at certified recycling centers to protect the environment and human health.

- Enjoy using your ASPP8-0723-W/ASPP8-0723-B 8-Way Surge Protection Power Board with USB A & C!

## Have you got everything?


**Note:** only one power board (white/black) is supplied.



Unpack the box and make sure all of these items are there:

- A. 8-Way Surge Protection Power Board with USB A & C
- B. User Guide
- C. Warranty Certificate

## Product Overview



#### 1. **Power On/Off Switches**

Press to supply/cut off power to the outlets.

#### 2. **Active Power LED Indicator**

When lit, the green light indicates that the power board is active and ready for use.

#### 3. **Surge Protected LED Indicator**

When lit, the green light indicates that all connected devices are surge protected.

#### 4. **USB-C and USB Charging Ports**

For charging phones, tablets or other devices.

#### 5. **Overload Circuit Breaker (Resettable)**

Protects against current overload at 10 amps.

#### 6. **AC Sockets**

All 8 sockets are the same protected sockets and can be used interchangeably.

#### 7. **TV Line Protection**

Protects the TV line against power surges.

### Troubleshooting

No power output from one of the sockets	<ul style="list-style-type: none"> <li>Try other sockets. If the other sockets have power output, it's probably the contact of one faulty socket that is loose or not connected; avoid using that socket.</li> </ul>
No power output from any of the sockets	<ul style="list-style-type: none"> <li>Check that the power switch is turned on (you can try to turn it on and off a few times to make sure it's switched on) and that the Active Power LED Indicator is lit green.</li> <li>Check the overload circuit breaker button to see whether it's tripping, push it down to reset the circuit breaker.</li> <li>Make sure the input socket for the power board has power output.</li> </ul>
No output from the USB ports	<ul style="list-style-type: none"> <li>Check that the USB cable is connected securely to the USB port and/or try a different USB port.</li> <li>The total output current for the USB ports are 2.1A. Remove devices using the other USB ports.</li> <li>Use another USB cable.</li> </ul>
Power board is not turning on	<ul style="list-style-type: none"> <li>Check that there is no visible damage to the plug or cord.</li> <li>Ensure that the devices connected do not exceed the total maximum load (2400W, 10A). If exceeded, unplug the devices and press the overload reset button.</li> </ul>
The TV cable signal is weak, or there is no signal at all	<ul style="list-style-type: none"> <li>Check the two cable connectors are firmly connected to the ANT-IN and ANT-OUT ports (located on underside of power board); you can try unplugging them and then plugging them back in; also turn the cable connector clockwise or counterclockwise to help make better contact for the connectors.</li> <li>Disconnect the cable and connect your TV directly to the wall ANT socket to make sure it's not an issue with the source signal.</li> </ul>

## Specifications

Input	AC 240V, 50Hz, 10A
Total Loading	Max 10A 2400W
Maximum Energy	1050J
Surge Protection Limit	30,000A
USB Output	DC 5V, 4A Total
Power Cable	1.1m
Mass	568g
Dimensions (W x H x D)	310 x 120 x 33 mm

## General Safety Warnings

- For the safety of yourself and others, follow all instructions and take notice of all the warnings. When adhered

to, these safety precautions can reduce the risk of fire, electric shock and injury.

- This product complies with Australian Safety standard AS/NZS 3105, AS/NZS 62368.1 to ensure the safety of the product.
- The RCM is a visible indication of a product's compliance with all applicable ACMA regulatory arrangements, including all technical and record-keeping requirements.

## **IMPORTANT**

- **Damage:** If the power board or cord is damaged, contact the After Sales Support line for advice. Do not attempt to open the board or replace the cord. The cord must be replaced by appropriately qualified personnel.
- **Repair:** If the power board requires repair, contact the After Sales Support line; never disassemble or modify the power board or attempt to service it yourself.
- Run the power supply cord in such a way that there will be no risk of anyone pulling it inadvertently or tripping over it.
- If power supply cord is damaged, it must be replaced by an authorised service agent or similarly qualified person to avoid a hazard.
- The power board is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction by a person responsible for their safety.
- Young children should be supervised to ensure they do not play with the power board. Close supervision is always necessary when any appliance is used by or near children.
- The product is not suitable for use in locations where children are likely to be present.
- The surge power board is designed for indoor use in dry places only.
- Do not exceed a maximum loading of 2400 watts.
- For safety reasons, always use earth connections.
- Only use the power board with the power supply cord fully unwound.
- Before installing the power board, make sure to place it away from: heat sources, radiators or other products that produce heat; areas with high temperatures, high humidity or direct sunlight; excess dirt and dust; open windows and any place where water may get to the unit.
- Do not immerse the cord, plug or the surge power board in water or other liquid, or expose the electrical connections to water or other liquid.
- Unpack the power board and keep the original packaging carton and materials in a safe place. It will help prevent any damage if the power board needs to be transported in the future, and you can use it to store the power board when it is not in use.
- The power board should always be repacked in its original packaging whenever transporting to prevent any possible damage to the product.
- **When not in use:** Disconnect from the power source and store in a cool, dry and well ventilated location out of direct sunlight, and not subject to humidity.
- **Warning:** The socket outlet should be located near the equipment and should be easily accessible.

## **Responsible disposal of the product**

At the end of its working life, do not throw this product out with your household rubbish. An environmentally friendly method of disposal will ensure that valuable raw materials can be recycled. Contact your local authority for

your nearest recycling centre. Electrical and electronic items contain materials and substances which, if handled or disposed of incorrectly, could potentially be hazardous to the environment and human health.

**Responsible disposal of the packaging**

The packaging of the product has been selected from environmentally friendly materials and can usually be recycled. Please ensure these are disposed of correctly. Plastic wrapping can be a suffocation hazard for babies and young children, please ensure all packaging materials are out of reach and are safely disposed of. Please ensure they are offered for recycling rather than throwing these materials away.

**Cleaning the product**

Only use a soft, dry cloth for cleaning the product; do not use a damp cloth. Never clean with industrial strength polish, wax, benzene, paint thinner, air freshener, lubricant, detergent or other chemicals. Wipe off any moisture, dirt or dust on the power sockets and plug pins with a clean, dry cloth.


**Give us a call**

- What? You mean this User Guide didn't have ALL the answers?
- Speak to us! We'd love to help you get up and running as quickly as possible.
- Call our After Sales Support on 1300 002 534.
- Operating hours: Monday-Friday, 8:30am-6pm; Saturday, 9am-6pm AEST

**Enjoy using your power board!**

Well done, you made it.  
Now sit back and relax... your power board is automatically covered by a 1-year warranty.  
How nice!

**Documents / Resources**



[BAUHN ASPP8-0723-W 8-Way Surge Protection Power Board with USB A and C](#) [pdf] User Guide

ASPP8-0723-W, ASPP8-0723-B, ASPP8-0723-W 8-Way Surge Protection Power Board with U SB A and C, ASPP8-0723-W, 8-Way Surge Protection Power Board with USB A and, 8-Way Su rge Protection Power Board, Surge Protection Power Board, Protection Power Board, Power B oard, Board