



## BAUHN LSX2 Wireless USB-C to HDMI Transmitter and Receiver Instruction Manual

[Home](#) » [BAUHN](#) » BAUHN LSX2 Wireless USB-C to HDMI Transmitter and Receiver Instruction Manual 

# BAUHN®


MANUAL  
PORTABLE BLUETOOTH® BOOMBOX



### Contents

- [1 Key Description](#)
- [2 Instructions for use](#)
- [3 Technical specifications](#)
- [4 Documents / Resources](#)
  - [4.1 References](#)

### Key Description



1. Long press to switch to the next track, Short press to increase volume
2. Short press pause/play
3. Short press the mode switch, and when both speakers are turned on, long press to enter/exit TWS mode to use both speakers simultaneously
4. Long press to turn on/off
5. Short press to switch between three sound effects
6. Long press to turn off/on the lights, short press to switch to light mode
7. Long press to switch to the previous track, Short press to reduce volume

## Instructions for use

### 1. Bluetooth® connectivity

After the product is turned on, it defaults to Bluetooth® mode and enters Bluetooth® pairing status. Turn on the Bluetooth® function of your phone to search for Bluetooth® devices Name: "LS-X2". Click on the connection to pair successfully and proceed with the music play.

### 2. USB drive, TF card

Insert the TF card/USB drive into the device and the device will automatically play the music in the TF card and the USB drive; supports playing MP3/WAV format music; supports playing MP3/WAV format music up to 64G.

### 3. Charge

Connect the standard charging cable to the charger for charging, then the red light will be on constantly and it will be out after it's fully charged.

### 4. TWS mode

TWS connection: Two machines are turned on simultaneously and both are in Bluetooth® mode when at Bluetooth® state, long press the M key on one of the machines, and the machine will automatically pair. After

successful connection, a TWS connection prompt sound will be emitted.

TWS disconnection: When two machines are in TWS connection state, long press M key on one of machine; will automatically disconnect TWS and emit TWS disconnect the prompt sound.

**Caution:** Changes or modifications of this product is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**FCC RF Radiation Exposure Statement Caution:** To maintain compliance with the FCC's RF exposure guidelines, place the product at least 20cm from nearby person.

## Technical specifications

Bluetooth® standards: 5.4

Distance 10 meters

Play time 4-6 hours

Speaker 78mm\*2

Input power supply 5V  1A

Maximum current consumption 1A




### Warning

Please remove the USB flash drive to extend working hours when not in use or turned off

- Please try not to use this machine in particularly cold, hot, dusty or humid environments. Do not open the lithium battery that comes with this machine and place it in a fire.
- Batteries should not allow metal products to come into contact or short-circuit the electrodes.
- Avoid placing in damp, corrosive or overheated environments (>60 ° C).
- Do not expose to prolonged sunlight to avoid lithium battery failure and shell damage caused by high temperatures, fading or discoloration.
- If the battery is not replaced properly, there is a risk of explosion, and only the same type or equivalent type can be used to replace the battery.

Made in China  
DIST. & SOLD  
EXCLUSIVELY BY: ALDI  
BATAVIA, IL 60510  
**AFTER SALES SUPPORT SERVICIO POSVENTA**  
714597  
  [866-235-5029](tel:866-235-5029)  
 [info@customercareusa.com](mailto:info@customercareusa.com)  
MODEL: LS-X2  
06/2025  
**3 YEAR WARRANTY**

## Documents / Resources

	<a href="#">BAUHN LSX2 Wireless USB-C to HDMI Transmitter and Receiver</a> [pdf] Instruction Manual LSX2, LSX2 Wireless USB-C to HDMI Transmitter and Receiver, Wireless USB-C to HDMI Transmitter and Receiver, USB-C to HDMI Transmitter and Receiver, HDMI Transmitter and Receiver, Transmitter and Receiver, Receiver
---	---

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.