



[Home](#) » [Support](#) » **Beanify Led Display Electric Razor User Manual** 

Contents [[hide](#)]

- [1 Beautify LED Display Electric Razor](#)
- [2 INTRODUCTION](#)
- [3 SPECIFICATIONS](#)
- [4 WHAT'S IN THE BOX](#)
- [5 FEATURES](#)
- [6 SETUP GUIDE](#)
- [7 CARE & MAINTENANCE](#)
- [8 TROUBLESHOOTING](#)
- [9 PROS & CONS](#)
- [10 WARRANTY](#)
- [11 FREQUENTLY ASKED QUESTIONS](#)
- [12 References](#)

BEANIFY

Beautify LED Display Electric Razor



INTRODUCTION

The Beanify LED Display Electric Razor is a multipurpose grooming tool made for contemporary consumers looking for accuracy, comfort, and convenience. This 4-in-1 rechargeable razor was introduced in 2025 and is reasonably priced at **\$21.99** for both men and women. It provides painless hair removal for the face, legs, bikini line, underarms, and even the nose and eyebrows. The razor, which is made by Beanify, is a multipurpose travel or daily care tool because it has replaceable trimmer heads, each of which is designed to meet different grooming requirements. Cleaning is made simple by its IPX7 waterproof construction, which allows for both wet and dry use, and its LED battery display, which informs you of power levels. Its ergonomic grip and premium

stainless steel blades guarantee easy operation without irritating the skin. The Beanify razor is a dependable self-care necessity that is lightweight, fashionable, and comes in a high-end gift box.

SPECIFICATIONS

Product Name	Beautify LED Display Electric Razor
Model Name	Beanify
Brand	Beanify
Price	\$21.99
Recommended Uses	Beard, Lip, Ear, Nose Hair, Armpit, Face, Eyebrow, Leg, Bikini, Arm
Special Features	LED Display, Skin Protection System, Fast Charging, Lightweight, Ergonomic Design, Waterproof
Power Source	Battery Powered
Design	Slim, Stylish, Portable, Ergonomic
Usage Type	4-in-1 Wet & Dry Electric Shaver and Facial Hair Remover
Attachments	4 Interchangeable Heads (Shaver, Eyebrow Trimmer, Nose Hair Trimmer, Hair Cutter)
Blade Quality	High-quality stainless steel blades
Skin Suitability	Suitable for sensitive skin, safe and painless shaving
Water Resistance	IPX7 Waterproof – usable on wet/dry skin, easy to rinse under water

Battery Indicator	LED Battery Display
Charging	Fast Charging
Portability	Travel-friendly, fits in a purse or handbag
Gift Suitability	Packaged in a gift box – ideal for birthdays, Mother's Day, Valentine's Day, etc.
Dimension	5.91in H, 1.26in W



WHAT'S IN THE BOX

- LED Display Electric Razor
- User Manual


FEATURES

- **All-in-One Grooming Tool:** Comes with 4 interchangeable heads for shaving, eyebrow trimming, nose hair trimming, and facial hair removal.
- **Multi-Area Use:** Perfect for removing hair from your face, legs, arms, bikini area, underarms, and even ears and nose.
- **Skin-Friendly Blades:** Made with stainless steel to ensure a smooth and gentle shave, even on sensitive skin.
- **Waterproof Design:** Fully washable with an IPX7 rating, use it wet or dry, and clean it under running water.
- **Digital Battery Display:** A clear LED screen lets you know how much power is left, so you're never caught off guard.
- **Compact & Portable:** Slim and lightweight, easy to carry in your purse or bag for grooming on the go.
- **Wet or Dry Use:** Works great with shaving cream or on clean, dry skin.
- **Fast Charging:** Quickly recharges via USB, so it's always ready when you are.
- **Comfortable Grip:** Ergonomic handle fits comfortably in your hand for easy control.
- **Quiet Operation:** Low noise makes it perfect for discreet use at home, work, or while traveling.
- **Easy to Swap Heads:** Attachments snap on and off easily to switch between grooming tasks.
- **Rechargeable Battery:** No need for disposable batteries—just charge it and go.
- **Stylish Gift Packaging:** Comes in a beautiful gift box—perfect for birthdays, holidays, or special occasions.
- **Safe & Painless Hair Removal:** Removes hair gently without nicks, cuts, or pulling.
- **Reliable Customer Support:** Offers 24/7 customer service to help with questions or product concerns.
- **Easy to clean**



- 4-in-1 Rechargeable Power Display Beauty Set

4-in-1 Rechargeable Power Display Beauty Set



SETUP GUIDE

- **Unbox the Razor:** Carefully open the package and take out all parts, including attachments and the charging cable.
- **Check the Accessories:** Make sure all heads and the charger are included and in good condition.
- **Charge Before First Use:** Plug in the USB cable and fully charge the razor. The LED screen will show the battery level.
- **Choose the Right Attachment:** Pick the head you need based on the area you're grooming.
- **Attach the Head:** Snap the selected head onto the razor until it locks into place.
- **Turn It On:** Press the power button to start the razor.
- **Test on a Small Area:** Try it out on a small patch of skin to get used to the feel.
- **Shave on Clean Skin:** Make sure the skin is clean and dry if not using shaving cream.
- **Apply Shaving Foam (Optional):** If you prefer, apply a light layer of foam or gel for a

smoother shave.

- **Hold at an Angle:** Gently glide the razor over your skin at a slight angle.
- **Use Light Pressure:** Let the razor glide—don't press hard.
- **Work in Short Strokes:** Move slowly and gently for the best results.
- **Switch Heads When Needed:** Turn off the razor before removing or changing the head.
- **Watch Battery Level:** Keep an eye on the LED display to monitor the charge.
- **Store Properly After Use:** Keep the razor and heads in a clean, dry place.

CARE & MAINTENANCE

- **Rinse After Every Use:** Remove the head and rinse under warm water to remove hair and residue.
- **Dry Before Storing:** Let all parts air dry completely before putting them away.
- **Use the Cleaning Brush:** If included, use the small brush to sweep away hair from hard-to-reach areas.
- **Don't Soak the Razor:** Rinse attachments only, avoid submerging the whole device in water.
- **Recharge Regularly:** Charge it when the battery runs low to keep it ready.
- **Avoid Harsh Cleaners:** Use mild soap and water only, no alcohol or abrasive products.
- **Store in a Dry Spot:** Keep the device and charger in a cool, dry place, away from moisture.
- **Cover the Blades:** Use the protective cap when not in use to prevent damage.
- **Replace Attachments as Needed:** If a head feels dull or pulls hair, consider replacing it.
- **Don't Drop It:** Handle with care to avoid damaging the blades or motor.
- **Cool Before Cleaning:** Let it cool down before cleaning or switching heads.
- **Avoid Using While Charging:** Only use the razor when it's unplugged.
- **Wipe the Body Clean:** Use a soft cloth to wipe down the outside of the razor.
- **Keep the Charger Dry:** Don't let water get near the charging port or cable.
- **Follow the Manual:** Refer to the instruction guide for any troubleshooting or special care tips.


3-in-1 Shaving Head Whole Body Hair Removal



Curved blade shaves
armpit or bikini area hair



Straight blade shaves
arm or leg hair



3d floating blade shaves
residue or stubble hair



TROUBLESHOOTING

Issue	Possible Cause	Solution
Device not turning on	Low battery or not charged	Recharge fully using the USB cable
Weak motor performance	Battery near depletion	Connect to power until the LED shows full charge
Razor pulling or tugging hair	Blades are dull or clogged	Clean blades or replace the head
LED display is not functioning	The battery is fully drained or the display is fault	Recharge or reset the device
Noisy operation	Hair or debris trapped inside	Detach the head and clean thoroughly

Issue	Possible Cause	Solution
Trimmer heads are not fitting securely	Improper alignment	Align carefully and lock in place
Irritation after use	Sensitive skin or dry shaving only	Use shaving cream or moisturizer post-shave
Water is not draining after the rinse	Clogged internal compartment	Shake out excess water and air dry completely
The device won't charge	Loose cable or port issue	Check the cable connection and try a different USB port
The unit turns off mid-use	Overheating protection or a low battery	Let it cool and recharge before next use

PROS & CONS

PROS

- Includes 4 interchangeable heads for full-body grooming
- LED display ensures real-time battery monitoring
- Skin-safe blades are ideal for sensitive areas
- IPX7 waterproof design for wet or dry shaving
- Lightweight and ergonomic for easy travel use

CONS

- Limited runtime between charges
- Not ideal for thick, coarse hair
- Replacement heads are not widely available
- No adjustable speed settings
- Must be fully dry before charging

WARRANTY

The Beanify LED Display Electric Razor is supported by a 1-year limited warranty. This warranty covers manufacturing defects under normal use conditions. It excludes damage caused by misuse, unauthorized modifications, or water damage due to improper use. Customers are encouraged to retain their proof of purchase and reach out to Beanify's 24/7 customer service team for support or replacement assistance. The brand promises a fast and satisfactory resolution to ensure a smooth shopping experience.

FREQUENTLY ASKED QUESTIONS

What attachments are included with the Beanify LED Display Electric Razor?

The Beanify LED Display Electric Razor comes with 4 interchangeable heads: a body shaver, eyebrow trimmer, nose hair trimmer, and facial hair cutter for complete grooming versatility.

Is the Beanify LED Display Electric Razor suitable for both men and women?

Absolutely. The unisex design and precision trimming heads make the Beanify model ideal for both men and women, covering beard, lip, nose, legs, armpits, and bikini areas.

How is the Beanify LED Display Electric Razor powered and charged?

This model is battery-powered and rechargeable, supporting fast charging through USB for cordless convenience and ease of use at home or on the go.

Why is my Beanify LED Display Electric Razor not turning on?

Ensure the razor is fully charged. If it still won't turn on, check for dirt in the power button or try resetting by disconnecting the charger and holding the power button for 3–5 seconds.

What should I do if the Beanify Electric Razor doesn't charge properly?

Try a different USB charging cable or adapter. Make sure the charging port is dry and free of dust or hair that may block contact.

Why is the Beanify LED Display Electric Razor running slower than usual?

A slow motor may indicate low battery or hair buildup. Fully charge the device and clean all blades and heads before using again.

How do I clean the Beanify LED Display Electric Razor after use?

Rinse the detachable heads under running water. For best results, clean after each use and allow the attachments to air dry completely before storing.

References

- [User Manual](#)

📖 Beanify, Beanify B0F8ZK5JDQ, Led Display Electric Razor, user

📁 Beanify manual

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.