



BEITONG BTP-BD4A Wireless PC Game Controller User Manual

[Home](#) » [BEITONG](#) » BEITONG BTP-BD4A Wireless PC Game Controller User Manual 

BEITONG BTP-BD4A Wireless PC Game Controller User Manual



Contents

- [1 Button Introduction](#)
- [2 Power ON/OFF Procedure](#)
- [3 Connect to Computer/Android TV](#)
- [4 Check the Function of Controller](#)
- [5 Functions Introduction](#)
- [6 Battery Life](#)
- [7 FAQs](#)
- [8 Q: Why doesn't the gamepad vibrate?](#)
- [9 Q: Why is the gamepad not recognized?](#)
- [10 Q: Why doesn't the gamepad work even if the wireless receiver is connected and the indicator is on?](#)
 - [10.1 Product Specification](#)
 - [10.2 Customer Service](#)
 - [10.3 CUSTOMER SERVICE](#)
 - [10.4 Documents / Resources](#)
 - [10.4.1 References](#)
 - [10.5 Related Posts](#)

Button Introduction



Power ON/OFF Procedure

Power ON

Using the receiver/cable to connect the device, short press the **BEITONG LOGO(HOME Button)** to turn the Controller on.

Power OFF

Press and hold the BACK button + B button for about 5 seconds, the Controller will be turned off.

1. When the Controller is connected, without any operation for 10 minutes, the Controller will automatically shut down.
2. When the Controller is not connected, without any operation for 120 seconds, the Controller will automatically.

Connect to Computer/Android TV

Wireless Connection

1. Insert the wireless receiver into the USB interface of the device.
2. Press the **BEITONG Logo (HOME Button)** to turn Controller on.
3. The connection is completed when the Controller vibrates and the indicator light will be on.
4. After connecting, press the **BEITONG Logo (HOME Button)** for 5s to change the mode of the controller.

Wired Connection

Use USB cable to connect the Controller and device together, and then press the **BEITONG Logo (HOME Button)** to turn Controller on. The connection is completed when the Controller vibrates and the indicator light will be on.

Check the Function of Controller

The controller will be switched to the PC360 mode when connected to a computer(the indicator 1 is on)

1. Open the control Panel in computer, click on Devices and Printers.



Credential Manager



Default Programs



Devices and Printers



File Explorer Options

2. Locate your joystick. Right-click on it and select "Game controller settings" from the popup menu.



Game controller settings

Create shortcut





Remove device

Troubleshoot

Properties

3. Click "properties" to open the interface for testing the keys. Use the "X axis/Y axis" to test the left stick, the "Z axis" to test the LT/RT key, the "X rotation/Y rotation" to test the right stick, the "Keys" to test each function key, and the "Point of View Hat" to test the cross key.



Functions Introduction

TURBO Function

Press and hold the Turbo button in the power-on state, and then press any button to set the Turbo function, repeat this operation to cancel the Turbo function.

SHIFT Function

Press the **SHIFT** Button to exchange the key values of the left joystick and D-pad.

Remote Control Function for Android TV



Key of controller	Key of TV	Key Value
Left Joystick	Up, Down, Left, Right	Move
BEITONG LOGO + A	HOME	Back to the desktop of TV
BEITONG LOGO + B	BACK	Back to previous operation
BEITONG LOGO + Y	MENU	Open the menu
BEITONG LOGO + Up	+	Turn up the volume
BEITONG LOGO + Down	-	Turn down the volume
BEITONG LOGO + Right Joystick	/	Move the mouse
BEITONG LOGO + RB	/	Left mouse key

Battery Life

Power Display

When connected to a computer, Computer light shows power display.

When connected to a TV, TV light shows power display.



Charging in Power-on Status

Low battery: Indicator light flash quickly

Charging: Indicator light flash slowly

Full Charge: Indicator light is on

Charging in Power-off Status

Battery is not full: Indicator light 1 and 2 flash slowly

Battery is full: Indicator light 1 and 2 are on.

FAQs

Q: Why doesn't the gamepad vibrate?

1. Make sure that the gamepad has enough power. If the battery is too low, the vibration will be weak or disabled. In this case, please charge the gamepad; 2. Make sure that the gamepad's driver is correctly installed and the game you play supports the vibration feature. You can download the driver from the official website of BEITONG and install it; 3. Some PC games and TV games do not support the vibration feature.

Q: Why is the gamepad not recognized?

1. Make sure that the gamepad has enough power and is already started; 2. Make sure that the wireless receiver is correctly connected to the gaming device; 3. Make sure that the device supports the use of gamepad. Some devices are not suitable for peripherals because their hardware and software are specially customized; 4. If the operating system is Windows XP, make sure that you have downloaded and installed the gamepad's driver correctly.

Q: Why doesn't the gamepad work even if the wireless receiver is connected and the indicator is on?

1. The problem may be caused by an error or hardware conflict when you plug or unplug the receiver. Shut down the computer and try to plug the receiver again; 2. The problem may be caused by the peripheral hardware that interferes with the receiver's signal. Place the gamepad as close to the receiver as possible; 3. The problem may be caused by other software that interferes with the receiver's signal and generates messy code. Press and hold the BEITONG LOGO key for 20 seconds to match the code with the receiver; 4. If the operating system is Windows XP, make sure that you have downloaded and installed the gamepad's driver correctly

Notes:

1. When connecting the device, ensure that the interface is in the correct direction to avoid any port damage caused by brute force or other improper use.
2. Do not use the gamepad in any damp, corrosive, dusty or poorly ventilated environment.
3. Do not operate the gamepad with wet hand. Otherwise, the moisture may enter the product.
4. Do not play the game for a long time. Take Breaks and enjoy a healthy game experience.

Product Specification

Name	BEITONG BAT 4 Wireless Gamepad
Model	BTP-BD4A
Power Supply	Rechargeable Lithium Ion Battery
Connection	2.4G Wireless, USB Cable
Size	150*110*50mm
Weight	About 300G
Adaptation plat form	PC Window 7 and later, Android TV/TV Box
Package Include	Gamepad x 1, Receiver x 1, USB Cable x 1, User Manual x 1

Customer Service

Dear customer,

Thanks for using BEITONG gaming peripheral products. We focus on providing gamer with a better gaming experience, please provide the information through your email for customer service:

- a. Purchasing Channel
- b. Buyer ID
- c. Order Number
- d. Product Model

Please provide the below information for us according to the product situation

1. Please provide service reason
 - a. Function is not good
 - b. Bad appearance
 - c. Can not use in my device
 - d. Can not play the game i want to play
 - e. Other reason
2. Please provide the service you need
 - a. Replacement

- b. Repairing
- c. Return
- d. Other

Customer service contact: beitong-oversea@betop-cn.com

We also welcome our customer to provide suggestion so that to improve and upgrade our product. Any goodideafor our products, please feel free to contact us. It's very grateful. Meanwhile we'll select the customer whoinhigh-quality advice to experience our new products for free opportunity.

Sincerely

BEITONG Customer Service Team

ABOUT BEITONG

Leading brand of smart gaming peripherals in China Been focusing on game controller and software development more than 25 years Sticking on quality, function and innovation Customizing professional control solutions for different types of games Creating the stronger experience of game control for gamers.

CUSTOMER SERVICE

Official website: www.betop-cn.com

Service Email: beitong-oversea@betop-cn.com

More products and game information, please follow **BEITONG** official social media accounts.

Official YouTube




Official Amazon



Official Website



Documents / Resources

	<p>BEITONG BTP-BD4A Wireless PC Game Controller [pdf] User Manual BTP-BD4A BAT4 Wireless PC Game Controller, BTP-BD4A, BAT4 Wireless PC Game Controller, Wireless PC Game Controller, PC Game Controller, Game Controller</p>
---	---

References

- [cn.com](#)
- [-](#)
- [User Manual](#)