

BEMKO
Bemko SL8 LED
Indicator Light



Bemko SL8 LED Indicator Light Instruction Manual

[Home](#) » [BEMKO](#) » Bemko SL8 LED Indicator Light Instruction Manual 

Contents


- [1 Bemko SL8 LED Indicator Light](#)
- [2 Installation Instructions](#)
- [3 Features](#)
- [4 Security](#)
- [5 Maintenance](#)
- [6 Recommendations](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)






Bemko SL8 LED Indicator Light




Installation Instructions





► SL8







Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with Your Local Authority or retailer for recycling advice.

Features

1. Rated voltage.
2. Rated current.
3. Power consumption.
4. Rated insulation voltage.

5. Lifetime.
6. Working temperature.
7. Protection degree.
8. Contamination degree.
9. Caution, risk of electric shock.
10. For internal use.
11. Terminal capacity.

1 230V~ 50/60Hz	2 I_n ≤20mA	3 P 0,6W	4 U_i 500V	5 LED  30000h	6 +40°C -5°C 	7 IP20	8 2
9 	10 	11 max 16mm ²					

Security

Before mounting, read the instructions and disconnect the power supply. Installation should be performed by a qualified user authorized to mount electrical devices depending on the applicable regulations in a given country, under the mounting diagram. Modifications to the product may cause threat and loss of warranty. Use protection against frost when working below 0° C.

Maintenance

All maintenance work should be carried out after disconnecting the power supply. The product temperature may rise to an elevated value. Before commencing maintenance, make sure that the product temperature is safe to make it. Guarantee unrestricted air supply, do not cover the product. Use dry and delicate materials for cleaning. Do not use chemical agents. Product not adapted to work in an environment with unfavorable conditions, i.e. high dustiness/humidity, water, explosive zones, vibrations, and chemical fumes.


Recommendations

Failure to follow the instructions in the manual may result in a fire, electric shock, burns, or other damage. Bemko sp. O.o. is not responsible for failure to comply with the above recommendations. We also reserve the right to make changes to the manual – the current version is available at www.bemko.eu.

Bemko

- **Bemko Sp. z o.o.**
ul. Bocznicowa 13 05-850 Jawczyce
- www.schelinger.eu.

Documents / Resources



[Bemko SL8 LED Indicator Light](#) [pdf] Instruction Manual
2023, SL8 LED Indicator Light, SL8, LED Indicator Light, Indicator Light, Light

References

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.