

BENIDUB DS01E Dub Siren Old School Sound-FX Machine with Inbuilt Echo User Manual

Home » Benidub » BENIDUB DS01E Dub Siren Old School Sound-FX Machine with Inbuilt Echo User Manual



Contents

- 1 BENIDUB DS01E Dub Siren Old School Sound-FX Machine with Inbuilt
- **2 USING INSTRUCTION**
- **3 CONTACTS**
- 4 Documents / Resources
- **5 Related Posts**



BENIDUB DS01E Dub Siren Old School Sound-FX Machine with Inbuilt Echo



POWER INPUT:

• 12VDC, 1A, Center positive, 2.1 mm × 5.5mm barrel connector.

• AUDIO OUTPUT:

- 1/4" bal. or unbal.
- MONO lack

USING INSTRUCTION

1. **TIME:**

Sets the delay time from 50ms to 1 sec.

2. VOLUME:

Sets the echo-section volume.

3. FEEDBACK;

Sets the repetition intensity ranging from one single repetition to continuous oscillation.

4. FILTER:

Combined HP-LP resonant filter to shape the echo tone

5. ECHO CUT:

Temporary button that mutes the echo output. It can be used to rythmically cut the echo loop.

6. MASTER VOLUME:

Master output volume control.

7. **MODE**:

Select between four classic DSO1 dub siren tones.

8. PITCH:


Select between three preset audio oscillator base frequencies.

9. RATE/MANUAL:

Modulation rate selector. In manual mode the push-button triggers the modulation.

10. TRIGGER:

Push upwards to trigger the siren temporarily or downwards for a continuous tone.



Made in Spain

CONTACTS

- Orders@benidub.com
- www.benidub.com

Documents / Resources



BENIDUB DS01E Dub Siren Old School Sound-FX Machine with Inbuilt Echo [pdf] User Manual

DS01E, DS01E Dub Siren Old School Sound-FX Machine with Inbuilt Echo, Dub Siren Old School Sound-FX Machine with Inbuilt Echo, DS01E Dub Siren Old School Sound-FX Machine

Manuals+,