




BENINCA Brainy 24 Coding Control Panel Instructions


[Home](#) » [BENINCA](#) » BENINCA Brainy 24 Coding Control Panel Instructions 

Contents

- [1 BENINCA Brainy 24 Coding Control Panel](#)
- [2 Instructions](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)

BENINCA[®]
TECHNOLOGY TO OPEN

BENINCA Brainy 24 Coding Control Panel




Instructions

1. Press once and immediately release the <PG> button on the control board and the screen will display "PAR".
2. Press the <+> button on the control board to cycle through the menu until the screen shows "rAd".
3. Press the <PG> button on the control board once and immediately let go.
4. The screen should now display "PP". If it does not display this, please press the <+> button until the screen displays "PP" and press the button <PG> button once and immediately release.
5. The screen should now display "PUSH", once this is on the screen you must immediately press and hold the button on the new remote you would like to program into the motor.
6. If the coding has been successful "oH" will be displayed on the screen. If "Err" is displayed this generally indicates an error and the remote has not been programmed.
7. Please wait for 1 to 2 minutes for the motor to exit learn mode, and then test the new remote.



www.remotepro.com

Documents / Resources

	<p>BENINCA Brainy 24 Coding Control Panel [pdf] Instructions Brainy 24 Coding Control Panel</p>
---	---

References

- [R Garage Door Remotes | Car Remotes | Free Shipping AU Wide – Remote Pro](#)

[Manuals+](#)