



BenQ PD05Q-EQ-V1 LCD Monitor User Guide

[Home](#) » [BenQ](#) » BenQ PD05Q-EQ-V1 LCD Monitor User Guide 

Contents



- [1 BenQ PD05Q-EQ-V1 LCD Monitor](#)
- [2 UNPACKING](#)
- [3 INSTALL](#)
- [4 Software installation](#)
- [5 PACKING](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)



BenQ PD05Q-EQ-V1 LCD Monitor



UNPACKING



USB





USB-C™



DP




HDMI
(optional)




INSTALL


1




2




3



4




5




6 Video

7 Audio


8 USB




9




10




11



12




Connecting multiple monitors via MST (Multi-Stream Transport)




Software installation


Display Pilot: for display arrangement & color matching (ICC Sync)




PACKING




1





2




3



4



1



M4 x 10 mm

2



Support: BenQ.com

Online Manual Product Support Software Download

For professional color display

CAD I CAM Mode


Animation Mode

For work efficiency

DualView

KVM Switch

Documents / Resources



[BenQ PD05Q-EQ-V1 LCD Monitor](#) [pdf] User Guide

PD05Q-EQ-V1, LCD Monitor, PD05Q-EQ-V1 LCD Monitor, 210223153415, PD05Q-EQ-V0