



# BenQ TK850i Readme Notice Firmware Upgrade Software Instructions

[Home](#) » [BenQ](#) » BenQ TK850i Readme Notice Firmware Upgrade Software Instructions 



## TK850i Readme Notice Firmware Upgrade Software Instructions

### Contents

- [1 TK850i Readme Notice Firmware Upgrade Software](#)
- [2 Update Changes in Detail](#)
- [3 How to Update Device Firmware](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

## TK850i Readme Notice Firmware Upgrade Software

It is suggested to keep your projector running with up-to-date benefits from features, applications, and bug improvement. For more details about firmware upgrade instruction and improvements, please read through the following:

### Update Changes in Detail

V1.0.3



- Bug fix for garbage content when doing HDR brightness adjustment

## How to Update Device Firmware

Please follow the steps below from user manual to update device firmware.

### Upgrading firmware

1. Go to BenQ Website and enter into Product page > Support > Software to download the latest firmware file.
2. Unzip the download file, find and save the file named "update\_signed.zip" to the USB flash drive. (Suggest to use the USB flash drive with FAT32 format)
3. Insert USB flash drive into USB 3.0 port.
4. Go to SYSTEM SETUP: ADVANCED > Firmware Upgrade menu and press OK.
5. Select Yes to upgrade the firmware version. In the process of upgrading, please keep power on until updating finished.



### Note

- Please restart projector when firmware upgrade is complete.

Documents / Resources

	<p><a href="#">BenQ TK850i Readme Notice Firmware Upgrade Software</a> [pdf] Instructions</p> <p>TK850i Readme Notice Firmware Upgrade Software, TK850i, Readme Notice Firmware Upgra de Software, Notice Firmware Upgrade Software, Firmware Upgrade Software, Upgrade Softw are, Software</p>
---	---