

bentgo Salad Container User Manual

Home » bentgo » bentgo Salad Container User Manual

Contents


- 1 bentgo Salad
- **Container**
- 2 Features
- 3 Using Bentgo Salad
- 4 Stacking Bentgo Salad
- **5 Cleaning Bentgo Salad**
- **6 Product Warranty**
- 7 Specifications
- 8 Materials
- 9 Documents /

Resources

- 9.1 References
- **10 Related Posts**



bentgo Salad Container



Bentgo Salad makes eating healthy on-the-go both easy and convenient. With a large bowl for fresh greens and a generously portioned compartment tray for salad toppings, Bentgo Salad is the perfect size for all appetites.

Features


- · Air-tight lid with locking clips seal in freshness.
- Sauce container with secure lid keeps dressing mess-free.
- Top-rack dishwasher safe*
- Compartment tray holds salad toppings and other snacks.
- Food-grade safe no BPA, PVC, phthalates, lead, or vinyl.
 - *To preserve the airtight silicone seal in the top lid, we recommend hand washing the lid.

Using Bentgo Salad

- 1. Lift the locking clips on the top lid to open.
- 2. Remove the compartment tray and sauce container. Add salad toppings to each compartment and fill sauce container with dressing. Secure the sauce container lid before inserting it back into the compartment tray.
- 3. Fill the salad bowl with greens.
- 4. Stack the compartment tray back inside the salad bowl and secure the top lid with the locking clips.
- 5. Bentgo Salad comes with a reusable fork that is stored in the top compartment. To store the reusable fork, insert it facing down and come in at an angle so it nests under the built-in notch. Place the cutlery cover over the fork for sanitary transport.

Stacking Bentgo Salad

We designed Bentgo Salad to stack easily and securely to keep your salad fixings fresh and in place while on-thego. The illustration below demonstrates how to properly stack each piece.



NOTE: Bentgo Salad is built to be used with all components. The top will only lock with both the salad bowl and compartment tray in place.

Cleaning Bentgo Salad

- · Wash before initial use.
- Salad bowl and compartment tray are top-shelf dishwasher safe.
- Hand wash the top lid and sauce container lid in warm soapy water to preserve their air-tight seal.

Warnings

- Only the salad bowl is microwave safe. However, DO NOT microwave for longer than 3 minutes.
- To ensure mess-free opening and closing of Bentgo Salad, do not overfill sauce container, salad bowl or compartment tray.

Product Warranty

Bentgo offers an industry-leading 2 Year Warranty. If you have warranty or product questions, please contact us directly at:

• Email: support@bentgo.com

• Phone: (657) 275-3738

• (Available Monday-Friday, 8am-5pm PST)

Specifications

Container Dimensions	7.2" x 7" x 4.15"
Capacity	Total Bowl Capacity: 54 oz (1.6 L)
	Bowl Capacity with Tray: 30 oz (900 ml)
	Sauce Container: 2.85 oz (85 ml)
	Tray: 5 oz (150 ml);10 oz (300 ml)
Temperature Threshold	0° to 248°F

Materials

Tray, Bowl & Sauce Container	PP Plastic
Sauce Container Lid	PE Plastic
Top Lid & Reusable Fork	ABS Plastic
Cutlery Cover	Tritan Plastic
Airtight Sealing Ring	Silicone

All materials are food-grade safe and eco-friendly Santa Ana, CA 92704 bentgo.com

Documents / Resources



bentgo Salad Container [pdf] User Manual Salad Container, Container

References

• b Bentgo® Bento Lunch Boxes and Accessories For Kids and Adults

Manuals+.