




Bertazzoni REF24FCIPRL23 Built In Freezer Column Instruction Manual

[Home](#) » [Bertazzoni](#) » Bertazzoni REF24FCIPRL23 Built In Freezer Column Instruction Manual 

Bertazzoni REF24FCIPRL23 Built In Freezer Column




Contents


- [1 PRODUCT DIMENSIONS](#)
- [2 CUTOUT DIMENSIONS](#)
- [3 ELECTRICAL & WATER CONNECTION](#)
- [4 INSTALLATION REQUIREMENTS](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

PRODUCT DIMENSIONS


- SIDE VIEW



- FRONT VIEW



- TOP VIEW




* Maximum Overall Handle Dimension


** Width of 3/4" (19mm) Door Panel

CUTOUT DIMENSIONS


- SIDE VIEW



- FRONT VIEW




- TOP VIEW




- (a) Area to be left clear for the anti-tipping brackets 3"1/2×5" (82x127mm)
- (b) Panel dimensions available on Built-in Food Preservation Design Guide or Installation Manual

ELECTRICAL & WATER CONNECTION



A properly-grounded, horizontally-mounted electrical receptacle should be installed according to this drawing.




To connect to the water supply system, a 1/4" NPT waterline with accessible shut-off valve must be supplied.

Connection(s) placement within the opening may require additional cabinet depth.


A separate circuit breaker servicing only this appliance is recommended.

For installation of multiple products in combination, refer to the Built-in Food Preservation Design Guide. Dimensions in parentheses are millimeters unless otherwise specified.

- TOP VIEW




- FRONT VIEW



INSTALLATION REQUIREMENTS

If the appliance(s) is not connected through the side profile trims to secured cabinetry anti-tip brackets must be installed.

Documents / Resources



[Bertazzoni REF24FCIPRL23 Built In Freezer Column](#) [pdf] Instruction Manual
REF24FCIPRL23 Built In Freezer Column, REF24FCIPRL23, Built In Freezer Column, Freezer Column, Column