



# Bertazzoni REF24RCPRR23 Built In Refrigerator Column Instruction Manual

[Home](#) » [Bertazzoni](#) » Bertazzoni REF24RCPRR23 Built In Refrigerator Column Instruction Manual 



# BERTAZZONI


## Instruction Manual

### Contents


- [1 PRODUCT DIMENSIONS](#)
- [2 CUTOUT DIMENSIONS](#)
- [3 ELECTRICAL CONNECTION](#)
- [4 INSTALLATION REQUIREMENTS](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

## PRODUCT DIMENSIONS


SIDE VIEW



FRONT VIEW



TOP VIEW




\* Maximum Overall Handle Dimension


\*\* Width of 3/4" (19mm) Door Panel

## CUTOUT DIMENSIONS


SIDE VIEW



FRONT VIEW



TOP VIEW



(a) Area to be left clear for the anti-tipping brackets 3"1/2×5" (82x127mm)


(b) Panel dimensions available on Built-in Food Preservation Design Guide or Installation Manual

## ELECTRICAL CONNECTION


**E**

A properly-grounded, horizontally-mounted electrical receptacle should be installed according to this drawing. Connection(s) placement within the opening may require additional cabinet depth.

## TOP VIEW



## FRONT VIEW



## INSTALLATION REQUIREMENTS


If the appliance(s) is not connected through the side profile trims to secured cabinetry anti-tip brackets must be installed.

A separate circuit breaker servicing only this appliance is recommended.

For installation of multiple products in combination, refer to the Built-in Food Preservation Design Guide.

Dimensions in parentheses are millimeters unless otherwise specified.

## Documents / Resources



[Bertazzoni REF24RCPRR23 Built In Refrigerator Column](#) [pdf] Instruction Manual  
REF24RCPRR23 Built In Refrigerator Column, REF24RCPRR23, Built In Refrigerator Column,  
Refrigerator Column