

BEST LEARNING 9201 MY FIRST PIANO BOOK



BEST LEARNING 9201 My First Piano Book Instruction Manual

[Home](#) » [BEST LEARNING](#) » BEST LEARNING 9201 My First Piano Book Instruction Manual 

Contents

- 1 BEST LEARNING 9201 My First Piano Book
- 2 INTRODUCTION
- 3 GETTING STARTED
- 4 FEATURES
- 5 CARE AND MAINTENANCE
- 6 BATTERY SAFETY
- 7 TROUBLESHOOTING
- 8 FREQUENTLY ASKED QUESTIONS
- 9 VIDEO – PRODUCT OVERVIEW
- 10 References
- 11 Related Posts



BEST LEARNING 9201 My First Piano Book



INTRODUCTION

Little music lovers will enjoy this portable book-sized piano. The 20-key piano promotes creative education through playing along with any of the 10 songs and 6 instruments! (3 Years+)

INCLUDED IN THIS PACKAGE

- 1 Musical book
- 1 Twenty-key Piano




BITS OF ADVICES

- For best performance, please make sure to turn the unit OFF before inserting/removing batteries. Otherwise, the unit may malfunction. If this happens, and the unit does not respond when the ON/OFF button is pressed, remove the batteries and reinstall them.
- All packing materials, such as tape, plastic, sheets, packaging locks, wire ties, and tags are not part of this toy and should be discarded for your child's safety.
- Please keep this user's manual as it contains important information.
- Please protect the environment by not disposing of this product with household waste.

GETTING STARTED

Battery Installation



The My First Piano Book operates on 2 AAA (LR03) batteries.


1. Locate the battery cover on the left side of the unit.
2. Open the battery cover with a screwdriver.
3. Insert 2 AAA (LR03) batteries.
4. Close the battery cover securely.

Enjoy It! Just press any button on the board or play with the 20-key piano to play fun!

FEATURES


10 Song Buttons

- Press it once to play a song.
- Press it again while playing to stop.
- Includes 10 popular kid's songs:



1. The Mulberry Bush
2. Twinkle Twinkle Little Star
3. Mary Had A Little Lamb
4. Row Row Row Your Boat
5. Eensy Weency Spider
6. If You're Happy And You Know It Clap Your Hands
7. I've Been Working On The Railroad
8. Old Macdonald Had A Farm
9. The Hokey Cokey
10. The Wheels On The Bus


6 Music Instrument Buttons




- Press any of the music instruments to swap between them.
- Includes 6 classical music instruments: Piano, Flute, Saxophone (top-side) Harp, Accordion, Guitar (bottom-side)

20-key Piano & 20-paged Music Sheets

- Follow the number or alphabet icons on the music sheets.



- Press the same color icons on the piano keyboard.



- Enjoy the delights of music and have fun!
 - **Record Button**
Press it once to start recording.
 - **Playback Button**
To listen to the recording, simply press this button once.

4 Colorful LED Lights



- Flashes with the melody randomly.

CARE AND MAINTENANCE

- Keep product away from foods and beverages.
- Clean with a slightly damp cloth (cold water) and mild soap.
- Never submerge the product in water.
- Remove batteries during prolonged storage.
- Avoid exposing product to extreme temperatures.

BATTERY SAFETY

- Batteries are small parts and choking hazards to children, must be replaced by an adult.
- Follow the polarity (+/-) diagram in the battery compartment.
- Promptly remove dead batteries from the toy.
- Dispose of used batteries properly.
- Remove batteries from prolonged storage.
- Only batteries of the same type as recommended are to be used.
- DO NOT incinerate used batteries.
- DO NOT dispose of batteries in fire, as batteries may explode or leak.
- DO NOT mix old and new batteries.
- DO NOT mix alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH) batteries.
- DO NOT recharge non-rechargeable batteries.
- DO NOT short-circuit the supply terminals.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.

TROUBLESHOOTING

Symptom	Possible Solution
Toy does not turn ON or does not respond.	<ul style="list-style-type: none"> • Make sure batteries are correctly installed. • Make sure battery cover is securely attached. • Remove batteries and put them back in. • Clean battery compartment by rubbing lightly with a soft eraser and then wiping with a clean dry cloth. • Install new batteries.
Toy makes strange sounds, behaves erratically or makes improper responses.	<ul style="list-style-type: none"> • Clean battery contacts per above instructions. • Install new batteries.

Item No. 9201 Printed in China



FREQUENTLY ASKED QUESTIONS

What are the product dimensions of the BEST LEARNING 9201 My First Piano Book?

The BEST LEARNING 9201 My First Piano Book measures 8.46 x 0.91 x 7.09 inches.

What is the weight of the BEST LEARNING 9201 My First Piano Book?

The BEST LEARNING 9201 My First Piano Book weighs 13.4 ounces.

What age range is the BEST LEARNING 9201 My First Piano Book recommended for?

The BEST LEARNING 9201 My First Piano Book is recommended for children aged 36 months to 8 years.

What type of batteries does the BEST LEARNING 9201 My First Piano Book require?

The BEST LEARNING 9201 My First Piano Book requires 2 AAA batteries.

What is the price of the BEST LEARNING 9201 My First Piano Book?

The BEST LEARNING 9201 My First Piano Book is priced at \$23.74.

What should I do if the BEST LEARNING 9201 My First Piano Book does not turn on?

Ensure the 2 AAA batteries are properly installed and not depleted. If the BEST LEARNING 9201 My First Piano Book still does not turn on, try replacing the batteries with new ones.

How can I fix the issue if a key on the BEST LEARNING 9201 My First Piano Book is not responding?

First, turn off the BEST LEARNING 9201 My First Piano Book and remove the batteries. Clean the keys with a dry cloth and ensure there is no debris. Reinsert the batteries and turn the book back on.

What do I do if the sound on the BEST LEARNING 9201 My First Piano Book is too low or distorted?

Check the battery level and replace the batteries if necessary. Low battery power can cause sound issues in the BEST LEARNING 9201 My First Piano Book.

How can I reset the BEST LEARNING 9201 My First Piano Book if it freezes or becomes unresponsive?

Remove the batteries for a few minutes, then reinsert them. This can reset the BEST LEARNING 9201 My First Piano Book and resolve any temporary issues.

What steps should I take if the lights on the BEST LEARNING 9201 My First Piano Book are not working?

Verify that the batteries are correctly installed and have sufficient charge. If the lights still do not work, try replacing the batteries with new ones.

How do I address the issue if the BEST LEARNING 9201 My First Piano Book is producing no sound?

Ensure the volume is turned up. If the volume is set correctly and there is still no sound, check and replace the batteries if needed.

What should I do if the buttons on the BEST LEARNING 9201 My First Piano Book are sticking or hard to press?

Clean around the buttons with a dry cloth to remove any dirt or debris that may be causing them to stick. Avoid using water or liquid cleaners on the BEST LEARNING 9201 My First Piano Book.

How can I resolve issues with the BEST LEARNING 9201 My First Piano Book not recognizing songs or commands?

Make sure that the keys are pressed firmly and accurately. If the problem persists, check the battery power and replace the batteries if they are low.

What should I do if the BEST LEARNING 9201 My First Piano Book is not switching between modes?

Turn off the BEST LEARNING 9201 My First Piano Book, remove the batteries, and wait a few minutes before reinserting them. This can help reset the mode settings.

How do I troubleshoot if the BEST LEARNING 9201 My First Piano Book is intermittently turning off?

Check the battery compartment to ensure the batteries are securely in place. Loose batteries can cause the BEST LEARNING 9201 My First Piano Book to turn off unexpectedly. Replace the batteries if the issue continues.

VIDEO – PRODUCT OVERVIEW



[Download the PDF link: \[BEST LEARNING 9201 My First Piano Book Instruction Manual\]\(https://www.manualslib.com/manual/1000000/BEST-LEARNING-9201-My-First-Piano-Book-Instruction-Manual.html\)](https://www.manualslib.com/manual/1000000/BEST-LEARNING-9201-My-First-Piano-Book-Instruction-Manual.html)
[First-Piano-Book-Instruction-Manual.mp4](#)

REFERENCE: [BEST LEARNING 9201 My First Piano Book Instruction Manual -Device.Report](#)

References

- [User Manual](#)