BLACK JACK EXT-RET Replace Switch





BLACK JACK EXT-RET Replace Switch Instructions

Home » Black Jack » BLACK JACK EXT-RET Replace Switch Instructions



Contents

- 1 BLACK JACK EXT-RET Replace **Switch**
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 How to Replace the EXT\RET Switch
- 5 FAQ
- 6 Documents / Resources
 - **6.1 References**
- **7 Related Posts**

BLACK JACK

BLACK JACK EXT-RET Replace Switch



Product Information

Specifications

· Product Name: Black Jack Trailer Jacks

· Version: V1.0

• Release Date: September 2023

Product Usage Instructions

Replacing the EXTRET Switch

Warning: Before starting, make sure to disconnect the power.

The EXTRET switch can be easily replaced by following these steps:

Removing the Old Switch

- 1. Take a flat blade screwdriver.
- 2. Gently pry the switch out at the top and bottom using the screwdriver.
- 3. Take your time and proceed slowly to avoid damaging the switch or surrounding components.
- 4. The switch will gradually come out as you pry it.

Terminal Configuration

There are 3 rows of 2 terminals on the switch:

- The top and bottom terminals operate the Extend and Retract functions.
- The middle 2 terminals are for the power and negative wire of the 12-volt motor.

Replacing Terminals

- 1. With the old switch removed, use the flat-blade screwdriver to remove one terminal at a time.
- 2. Make sure to place each terminal in the same position on the new switch.
- 3. Repeat this process until all 6 terminals are replaced.

Installing the New Switch

- 1. Gently push the new switch into the housing until it locks in place.
- 2. Make sure the switch is securely fitted.

Testing

Reconnect the power and test the switch operation to ensure it is functioning correctly.

All done! Replacing the EXTRET switch is an easy process.

How to Replace the EXT\RET Switch

Warning: Disconnect power before commencing.

The EXT\RET switch is easy to replace. Just follow these steps.

EXT\RET Switch lugs

The switch has top and bottom plastic lugs that hold it in place.



To remove the switch, take a flat blade screwdriver and gently pry the switch out at the top and the bottom. Take it slowly and the switch will gradually come out.





There are 3 rows of 2 terminals. The top and bottom operate the Extend and Retract functions. The middle 2 terminals are the power and negative wire for the 12-volt motor.



When the switch is out, use the flat-blade screwdriver to remove one terminal at a time. Once the terminal is removed, place it in the same position on the new switch





When all 6 terminals are replaced, gently push the new switch into the housing until it locks in place. Reconnect power and test the switch operation.



All done, easy! Black Jack Trailer Jacks V1 .0 September 2023

FAQ

- Q: Do I need any special tools to replace the EXTRET switch?
- A: No, you only need a flat-blade screwdriver to remove and install the switch.
- Q: What should I do if the new switch does not lock in place?
- A: Ensure that you are aligning the switch correctly and applying enough pressure while pushing it into the housing. If the issue persists, contact customer support for assistance.
- Q: Can I replace individual terminals on the existing switch instead of replacing the entire switch?

A: It is recommended to replace the entire switch with new terminals for optimal performance. Replacing individual terminals may lead to compatibility or reliability issues.

Documents / Resources



BLACK JACK EXT-RET Replace Switch [pdf] Instructions EXT-RET Replace Switch, EXT-RET, Replace Switch, Switch

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.