**BLAUPUNKT** BT25LAMP **SMART** BLUETOOTH SPEAKER WITH LAMP



# **BLAUPUNKT BT25LAMP Smart Bluetooth Speaker with Lamp Owner's Manual**

Home » Blaupunkt » BLAUPUNKT BT25LAMP Smart Bluetooth Speaker with Lamp Owner's Manual



#### Contents

- 1 BLAUPUNKT BT25LAMP Smart Bluetooth Speaker with Lamp
- **2 Product Information**
- **3 Product Usage Instructions**
- **4 Important Notes**
- **5 SAFETY INSTRUCTIONS**
- 6 Bluetooth
- **7 Control locations**
- **8 Power connection**
- 9 Download the App and operation
- 10 Bluetooth operation
- 11 AUX IN/ MP3 link mode
- 12 USB charging
- 13 Specification
- 14 Troubleshooting
- 15 Frequently Asked Questions
- 16 Documents / Resources
  - 16.1 References
- 17 Related Posts



**BLAUPUNKT BT25LAMP Smart Bluetooth Speaker with Lamp** 



# **Product Information**

# **Specifications**

• Name: BT25LAMP

• Type: Smart Bluetooth Speaker with Lamp

Bluetooth Version: 5.0Speaker Output: 10W

• Lamp Power: 5W

• **Dimensions:** 8in x 8in x 12in

• Weight: 2 lbs

# **Product Usage Instructions**

#### Power On/Off

To power on the device, press and hold the power button for 3 seconds. To power off, repeat the same process.

# **Bluetooth Pairing**

Enable Bluetooth on your smartphone or device and search for available devices. Select "BT25LAMP" to pair. Once paired, you can stream music wirelessly.

# **Lamp Control**

The lamp can be controlled by tapping the touch-sensitive panel on the device. Tap once to turn on/off, and slide your finger to adjust the brightness.

# Speaker Usage

Play music from your connected device through the speaker. Adjust the volume using the volume controls on the device or your connected smartphone.

# **Important Notes**

- This safety and operating instruction should be retained for future reference.
- The apparatus should not be exposed to dripping or splashing or placed in a humid atmosphere such as a bathroom.
- Do not install the product in the following areas:
- Places exposed to direct sunlight or close to radiators.
- On top of other stereo equipment that radiate too much heat.
- Blocking ventilation or in a dusty area.
- Areas where there is constant vibration.
- · Humid or moist places.
- Do not place near candles or other naked flames.
- Operate the product only as instructed in this manual.
- Before turning on the power for the first time, make sure the power adaptor is properly connected.

For safety reasons, do not remove any covers or attempt to gain access to the inside of the product. Refer any servicing to qualified personnel. Do not attempt to remove any screws, or open the casing of the unit; there are no user serviceable parts inside. Refer all servicing to qualified service personnel.

### **SAFETY INSTRUCTIONS**

- 1. Read Instructions All the safety and operating instructions must be read before the product is operated.
- 2. Retain Instructions The safety and operating instructions should be kept with the product for future reference.
- 3. Heed warnings All warnings on the product and in the operating instructions should be adhered to.
- 4. Follow instructions All operating and users' instructions should be followed.
- 5. Installation Install in accordance with the manufacturer's instructions.
- 6. Power sources This product should be operated only from the type of power source indicated by the marking adjacent to the power cord entry. If you are not sure of the type of power supply to your home, consult your product dealer or local power company.
- 7. Water and moisture To reduce the risk of fire or electric shock, do not expose the product to train, dripping, splashing, or excessive moisture such as in a sauna or bathroom. Do not use this product near water, for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement or near a swimming pool (or similar).
- 8. Object and Liquid Entry Never push objects of any kind into this product through openings, as they may touch dangerous voltage points or short-circuit parts that could result in a fire or electric shock. Never spill liquid of any kind on the product. Do not place any object containing liquid on top of the product.
- 9. Servicing Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
- 10. Replacement parts When replacement parts are required, ensure that the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

- 11. The highest environmental temperature suitable for this product is 35°C.
- 12. ESD hints If the product maybe reset or not reset to operation of control due to electrostatic discharge, just switch off and reconnect again, or move the product to another location.

# **ERP2 (Energy Related Products) note**

This product with ecodesign complies with the stage 2 requirements of Commission Regulation (EC) NO. 1275/2008 implementing Directive 2009/125/EC regarding standby and off-mode electric power consumption of electronic household and office equipment.

#### WARNING

This appliance is not intended for use by persons (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

- 1. Never use the device unsupervised! Switch off the device whenever you are not using it, even if this only for a short while.
- 2. The appliance is not intended to be operated by means of an external timer or separate remote control system.
- 3. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 4. Before operating this system, check the voltage of this system to see if it is identical to the voltage of your local power supply.
- 5. To prevent fire or shock hazard, do not expose this equipment to hot places, rain, moisture or dust.
- 6. Do not place this unit close to a strong magnetic field.
- 7. Do not place the unit on a amplifier or receiver.
- 8. Do not place this unit in a damp area as the moisture will affect the life of electric components.
- 9. If the system is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may condense on the lens inside the player. If this occurs, the system will not operate properly. Please leave the system turned on for about an hour until the moisture evaporates.
- 10. Do not attempt to clean the unit with chemical solvents as this might damage the finish. Wipe with a clean, dry, or slightly damp cloth.

# **NOTICE Conformity**

Hereby, Blaupunkt Competence Center 2N-Everpol Sp. z o.o., declares that this equipment is in compliance with the essential requirement and other relevant provisions of Directive 2014/53/EU. Declaration of conformity can be obtained from the product page at <a href="https://www.blaupunkt.com">www.blaupunkt.com</a>.

Responsible party: 2N-Everpol Sp. z o.o, Puławska 403A, 02-801 Warsaw, Poland, Phone: +48 22 331 99 59, E-mail: <a href="mailto:info@everpol.pl">info@everpol.pl</a>

Your products is designed a manufactured with high quality materials and components, which can be recycled and reused.

When this crossed-out wheeled bin symbol is attached to a product it means that the product is covered by the European Directive 2002/96/EC. Please inform yourself about the local separate collection system for electrical and electronic products. Please cat according to your local rules and do not dispose of your old products with your normal household waste. Correct disposal of your old product helps to prevent potential negative consequences for the environment and human health.

Your product contains batteries covered by the European Directive 2013/56/EC, which cannot be dispose with normal household waste. Please inform yourself about the local rules on separate collection of batteries because correct disposal helps to prevent negative consequences for the environmental and human health.

#### **Environmental information**


All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box),polystyrene foam(buffer) and poly ethylene (bags, protective foam sheet). Your system consists of material which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment. Recording and playback of material might require consent. See Copyright Act 1956 and The Performer's Protection Acts 1958 to 1972.

### **Bluetooth**

The Bluetooth• word mark and logos are registered trademarks owned by Bluetooth SIG,lnc. and any use of such marks by us is under license. Other trademarks and trade names are those of their respective owners.

Many thanks for purchasing our model, please read and reference this manual carefully before operate the unit. Please keep the manual for future operation reference.

# **Control locations**



#### 1. Volume knob

- a. Short press down the knob to change the LED light color, rotate it within 2 seconds to adjust the brightness of light.
- b. In Bluetooth mode, rotate the knob to adjust the output volume; press and hold it 3 seconds to play/pause the music;

#### **Important**

- a. if you rotate the knob to adjust the output volume level in Bluetooth mode, please break and wait 5 seconds to next
- operation in case that you want to adjust the light brightness etc..
- b. When you press down and hold the volume knob 3 seconds to pause the music playback in Bluetooth mode, there cannot resume the playback by press the play button from your Bluetooth device, but can resume it by press and hold the volume knob again.
- 2. LED lamp shade;

- 3. Microphone hole
- 4. Power button
  - a. Press and hold the button 2 seconds to power on or off the unit.
  - b. Short press the button to turn on or off the light.
- 5. DC power jack; 6-AUX IN jack 7-USB port 8-LED indicator

#### **Power connection**

Insert the female connector of the external power adaptor(DC 12V/1.5A) into the DC jack which is located at the bottom of the unit, then plug the power adaptor into the wall outlet in order to get the power. Please kindly note only the supplied power adaptor is right to use on this device and disconnect the power supply in case of non-use for a long period.

# Download the App and operation


We designed an app(App name: iLink) to work with this unit which can download it on your smartphone or tablet PC. Scan the below QR cord to directly go to the download app depending on iOS or Android system on your device.







(App store)



Before you start the app operation, please make sure the unit has paired with your device via Bluetooth first( reference the operation on Bluetooth part in this menu). Then open the iLink app > select the menu icon (1) > select the Bluetooth menu(2)(reference below photo) to check if the "BP BT25LAMP app" is appeared on the list > click the search icon if not appeared on the device > click "BP BT25LAMP app" to connect the app with the unit. In the app, you can set up the light on/off time, music on/off time, and alarm time; you also can change the light color and brightness, select the light effect, etc.

#### Note

- 1. Depending on the provider, downloading the app may require payment.
- 2. In order to make sure the operation is normal, please double-check the light on/off time, music on/off time, and alarm time setting in case you turn off the app, or disconnect the Bluetooth.
- 3. When the app alarm is activated, short press down the volume knob to cancel the alarm sound.

# **Bluetooth operation**

The speaker includes Bluetooth function which allows you to wireless playback the audio with other Bluetooth device like smart phone etc. Please follow up below for the operation.

- Power on the unit, then the top blue color LED will flare which means the speaker is ready to pair with other device.
- 2. Enable the Bluetooth function on your Bluetooth device, and search the available Bluetooth device (please reference your device manual for the operation).
- 3. Check the available Bluetooth device on the menu list of your device, and select "BP BT25LAMP" in order to start pairing. Please key-in "0000" (4 zero) in case of a POP password required during pairing. The blue LED will become stable when the pairing is successful.
- 4. Select and play the music on your Bluetooth device. Then the sound will output from speaker.
- 5. During Bluetooth playback, you can rotate or press down the volume knob to adjust volume, or get music pause/play operation.

**Phone call hands-free:** when the cell phone was paired with a speaker, and an incoming call is arriving; short press the volume knob can pick up the call; answer the phone call and talk aim to the microphone hole within 30cm(suggested distance) in order get better conversation sound quality; short press the volume knob again can end the phone call and resume the music playback.

#### **Notes**

- a. All Bluetooth devices are not guaranteed to pair successfully due to different design and brand.
- b. Please do not put your cell phone very close to the speaker during phone call hands free conversation, in order to avoid interference which will impact the conversation sound quality.
- c. The Bluetooth best working distance is within 10 meters without any obstacle in between.

### AUX IN/ MP3 link mode

Using the supplied 3.5mm to 3.5mm stereo audio cable connect the AUX IN jack of unit with the line out or headphone jack on any other external audio player like mp3 player etc. Power on the unit, select and play the music from your external audio player, then the sound will output from the speaker.

### **Notes**

- a. In AUX IN mode, the main control is on your external audio player side. But you still can increase or decrease the volume on the speaker side.
- b. Please kindly note the AUX IN mode is only available when the audio cable was plugged in; the unit will switch to AUX IN mode automatically when the unit is connected with the audio cable.

### **USB** charging

Using your USB cable(not included) insert into the USB port of the speaker, and another terminal connect with your device; then the unit will charge your device. The USB rating output power is 5V/1A.

### **Specification**

Power source: DC12V /1.5A;

• Bluetooth version: V4.0, best working distance within 10 meters

USB output: 5V / 1A;

• Rated power: 1 x 10W

• Power consumption: 15W

• Standby power consumption: < 0.5Watt

 Accessory:1 pcs x power adaptor, 1 pcs x 3.5mm to 3.5mm audio cable (The above spec may revise without prior notice)

# **Troubleshooting**

- 1. The unit cannot power on.
  - 1. Please check if the power connection is correct.
  - 2. Please contact the service center in case of issue remains.
- 2. There is no or intermittent sound output in Bluetooth mode.
  - Please turn off the Bluetooth, and repair with the speaker.
    Please put your Bluetooth device closer with the speaker.
- 3. The unit cannot work with app.
  - 1. Please check if the Bluetooth and app connect with the unit properly.
  - 2. Please contact the service center in case of issue remains.

# **Frequently Asked Questions**

# Q: How do I charge the device?

A: The device can be charged using the provided USB cable. Connect it to a power source such as a computer or USB adapter.

# Q: Can I use the lamp and speaker simultaneously?

A: Yes, you can play music through the speaker while using the lamp function at the same time.

### **Documents / Resources**



BLAUPUNKT BT25LAMP Smart Bluetooth Speaker with Lamp [pdf] Owner's Manual BT25LAMP Smart Bluetooth Speaker with Lamp, BT25LAMP, Smart Bluetooth Speaker with Lamp, Bluetooth Speaker with Lamp, Lamp

# References

User Manual

### Manuals+, Privacy Policy