



# blink BAH0410U Mini 2 Support Drone Camera Instruction Manual

[Home](#) » [blink](#) » blink BAH0410U Mini 2 Support Drone Camera Instruction Manual 

## Contents

- 1 [blink BAH0410U Mini 2 Support Drone Camera](#)
- 2 [Product Information](#)
- 3 [Product Usage Instructions](#)
- 4 [SAFETY INFORMATION](#)
- 5 [Documents / Resources](#)
  - 5.1 [References](#)
- 6 [Related Posts](#)

# blink

## blink BAH0410U Mini 2 Support Drone Camera



## Product Information

## Specifications

- Model: Blink Mini 2
- Model Number: BCM00700U
- AC Adapter Model: A726-050150U-US1
- For indoor use only
- Weather Resistant Power Adapter Model: BAH0410U (sold separately)
- Manufacturer: [Amazon.com](https://www.amazon.com) Services LLC

## Product Usage Instructions

### Safety Information

Read all safety information before using the device. Failure to follow these safety instructions could result in fire, electric shock, or other injury or damage.

### Powering the Device

Your device should only be powered using the AC adapter included with the device for indoor use. For outdoor use, use the Blink Weather Resistant Power Adapter (model no. BAH0410U, sold separately). If the adapter or cable appears damaged, discontinue use immediately.

### Handling Moisture

Avoid exposing your device or adapter to liquids. If wet, unplug all cables without getting your hands wet and allow the device and adapter to dry completely before reconnecting.

### Installation

Install your power adapter into an easily accessible socket-outlet located near the equipment that will be plugged into or powered by the adapter.

### Device Care

Protect your device from direct sunlight and do not attempt to dry it with external heat sources. If dropped or damaged, the waterproofing may be compromised.

### Accessories

Use only accessories supplied with the device to power it. Third-party accessories may impact performance and void the warranty.

### Safety Warnings

Be cautious of small parts that may present a choking hazard to small children. Take extra care when using a ladder or similar equipment to mount the product to reduce the risk of falling.

### For More Information

For additional care instructions and information on waterproofing, visit [www.amazon.com/devicesupport](https://www.amazon.com/devicesupport).

## FAQ

### 1. Q: Can I use third-party accessories with the device?

A: It is recommended to use only accessories supplied with the device or specifically marketed for use with your device to ensure optimal performance and warranty coverage.

### 2. Q: What should I do if my device gets wet?

A: Unplug all cables without getting your hands wet and allow the device and adapter to dry completely before reconnecting.

### 3. Q: How do I mount the product safely?

A: Take extra care when using a ladder or similar equipment to avoid the risk of falling while mounting the product.

## IMPORTANT PRODUCT INFORMATION



### SAFETY INFORMATION

READ ALL SAFETY INFORMATION BEFORE USING THE DEVICE. FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS COULD RESULT IN FIRE, ELECTRIC SHOCK, OR OTHER INJURY OR DAMAGE.

Your device is shipped with an AC adapter, model no. A726-050150U-US1 that is intended for indoor use only. Your device should only be powered using the AC adapter included with the device or using the Blink Weather Resistant Power Adapter, model no. BAH0410U (sold separately), for outdoor use. If the adapter or cable appears damaged, discontinue use immediately.

Do not expose your device or adapter to liquids. If your device or adapter gets wet, carefully unplug all cables without getting your hands wet and wait for the device and adapter to dry completely before plugging them in again. Do not attempt to dry your device or adapter with an external heat source, such as a microwave oven or a hair dryer. If the device or adapter appear damaged, discontinue use immediately. Use only accessories supplied with the device to power your device.

Install your power adapter into an easily accessible socket-outlet located near the equipment that will be plugged into or powered by the adapter.

### Other Safety Considerations

Your device can withstand outdoor use and contact with water only when powered using the Blink Weather Resistant Power Adapter, model no. BAH0410U (sold separately). However, your device is not intended for underwater use and may experience temporary effects from exposure to water. Do not intentionally immerse your device in water. Do not spill any food, oil, lotion, or other abrasive substances on your device. Do not expose your device to pressurized water, high velocity water, or extremely humid conditions (such as a steam room). Do not expose your device or batteries to salt water or other conductive liquids. To protect against electric shock, do not place cord, plug, or device in water or other liquids. If your device gets wet from immersion in water or high pressure water, carefully disconnect all cables without getting your hands wet and wait for them to dry completely before powering it on again. Do not attempt to dry your device or batteries (if applicable) with an external heat source, such as a microwave oven or a hair dryer. To avoid risk of electric shock, do not touch your device or batteries or any wires connected to your device during a lightning storm while your device is powered. If your device or batteries appears to be damaged, discontinue use immediately.

If your device is dropped or otherwise damaged, the waterproofing of the device may be compromised.

For more information concerning care instructions and the waterproofing of your device, please see

[www.amazon.com/devicesupport](http://www.amazon.com/devicesupport).

Protect your device from direct sunlight.

Use only accessories supplied with your device, or specifically marketed for use with your device, to power your device. Use of third-party accessories may impact your device's performance. In limited circumstances, use of third-party accessories may void your device's limited warranty. In addition, use of incompatible third-party accessories may cause damage to your device or the third-party accessory. Read all safety instructions for any accessories before using with your device.

**WARNING:** Small parts contained in your device and its accessories may present a choking hazard to small children.

**CAUTION:** To reduce the risk of falling, take extra care when using a ladder or similar equipment to mount the product.

## PRODUCT SPECIFICATIONS

- Model Number: BCM00700U
- Electrical Rating: 5V 1A
- Operating Temperature Range: -20° to 45°C (-5°F to 113°F)

## FOR USA CUSTOMERS

### Supplier's Declaration of Conformity

**Device Name:** Blink Mini 2

**Model:** BCM00700U

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

### Responsible Party and Party issuing Supplier's Declaration of Conformity:

[Amazon.com](https://www.amazon.com) Services LLC, 410 Terry Avenue North, Seattle, WA 98109, U.S.A.

[www.blinkforhome.com/contact-us](https://www.blinkforhome.com/contact-us)

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution, pursuant to Section 15.21 of the FCC rules, user changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with FCC radio frequency radiation exposure limits set forth for an uncontrolled environment. Information is on file with the FCC and can be found by inputting such Product's FCC ID (which can be found on the device) into the FCC ID Search form available at [fcc.gov/oet/ea/fccid](https://fcc.gov/oet/ea/fccid).

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other product antenna or transmitter.

## FOR CANADIAN CUSTOMERS

### Innovation, Science and Economic Development Canada (ISED) Compliance

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

### Information Regarding Exposure to Radio Frequency Energy

This equipment complies with IC RSS-102 RF exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

## RECYCLING YOUR DEVICE PROPERLY

In some areas, the disposal of certain electronic devices is regulated. Make sure you dispose of, or recycle, your device in accordance with your local laws and regulations. For information about recycling your device, go to

[www.amazon.com/devicesupport](https://www.amazon.com/devicesupport).

**Additional Safety and Compliance Information**

For additional safety, compliance, recycling and other important information regarding your device, please refer to the Legal and Compliance section of the About Blink menu in the Settings in your app or on the Blink website at <https://blinkforhome.com/safety-and-compliance>

**TERMS AND POLICIES**

By purchasing or using the product, you agree to the Terms of Service found at <https://blinkforhome.com/terms-of-service>.


**LIMITED WARRANTY**

For information on our warranty and any other applicable policy, visit <https://blinkforhome.com/blink-terms-warranties-and-notices>

ADDITIONAL INFORMATION You can find the Customer Service contact information and other applicable terms and Device information (including in other languages) at <https://support.blinkforhome.com/>

©2024 [Amazon.com](https://www.amazon.com), Inc. or its affiliates. Amazon, Blink, and all related marks are trademarks of [Amazon.com](https://www.amazon.com), Inc. or its affiliates.

**Documents / Resources**

	<a href="#">blink BAH0410U Mini 2 Support Drone Camera</a> [pdf] Instruction Manual BAH0410U Mini 2 Support Drone Camera, Mini 2 Support Drone Camera, Support Drone Camera, Drone Camera, Camera
--	--

**References**

- [a Amazon.com](#)
- [a amazon.com/](#)
- [a Amazon Digital Services and Device Support - Amazon Customer Service](#)
- [b Contact Blink — Blink Smart Security](#)
- [b Terms and Conditions — Blink Smart Security](#)
- [b Terms of Service US — Blink Smart Security](#)
- [b Blink Support](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.