

blink Mini 2 Plug In Smart Security Camera



blink Mini 2 Plug In Smart Security Camera Instructions

[Home](#) » [blink](#) » blink Mini 2 Plug In Smart Security Camera Instructions 

Contents

- 1 [blink Mini 2 Plug In Smart Security Camera](#)
- 2 [Product Information](#)
- 3 [Product Usage Instructions](#)
- 4 [IMPORTANT PRODUCT INFORMATION](#)
- 5 [PRODUCT SPECIFICATIONS](#)
- 6 [LIMITED WARRANTY](#)
- 7 [Documents / Resources](#)
 - 7.1 [References](#)

Blink

blink Mini 2 Plug In Smart Security Camera



Product Information

Specifications:

- Wireless Feature: WiFi
- Maximum Power: 2412 – 2472 MHz xx dBm EIRP

Product Usage Instructions

Safety Information:

Read all safety information before using the device. Failure to follow these safety instructions could result in fire, electric shock, or other injury or damage.

Powering the Device:

Your device is shipped with an AC adapter A726-050150U-US1 for indoor use only. Use the provided AC adapter or the Blink Weather Resistant Power Adapter (model no. BAH0410U, sold separately) for outdoor use. Do not use damaged adapters or cables.

Handling Liquids:

Avoid exposing the device or adapter to liquids. If wet, unplug all cables without getting your hands wet and let them dry completely before use. Do not use external heat sources for drying.

Facility:

Install the power adapter into an easily accessible socket outlet near the equipment to be powered.

Device Care:

If the device is dropped or damaged, the waterproofing may be compromised. Visit www.amazon.com/devicesupport for care instructions and waterproofing details.

Accessory Usage:

Use only supplied accessories to power your device. Third-party accessories may impact performance and void

warranty. Check accessory safety instructions.

Additional Safety Tips:

- Protect device from direct sunlight.
- Avoid using incompatible third-party accessories.
- Small parts may pose a shocking hazard to children.
- Securely mount the device in elevated locations to prevent falls.

FAQs

- Q: Where can I find information about device compatibility?

A: For device compatibility, visit the detail page for your accessory on

<https://support.blinkforhome.com/indoor-outdoor-accessories>.

- Q: How can I ensure proper installation of the device?

A: Install the device with at least 20 cm between the radiator and your body to comply with electromagnetic field exposure guidelines.

IMPORTANT PRODUCT INFORMATION

SAFETY INFORMATION

- READ ALL SAFETY INFORMATION BEFORE USING THE DEVICE. FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS COULD RESULT IN FIRE, ELECTRIC SHOCK, OR OTHER INJURY OR DAMAGE.
- Your device is shipped with an AC adapter A726-050150U-US1 that is intended for indoor use only. Your device should only be powered using the AC adapter included with the device or using the Blink
- Weather Resistant Power Adapter, model no. BAH0410U (sold separately), for outdoor use. If the adapter or cable appears damaged, discontinue use immediately.
- Do not expose your device or adapter to liquids. If your device or adapter gets wet, carefully unplug all cables without getting your hands wet and wait for the device and adapter to dry completely before plugging them in again. Do not attempt to dry your device or adapter with an external heat source, such as a microwave oven or a hair dryer. If the device or adapter appears damaged, discontinue use immediately. Use only accessories supplied with the device to power your device.
- Install your power adapter into an easily accessible socket outlet located near the equipment that will be plugged into or powered by the adapter.

Other Safety Considerations

- Your device can withstand outdoor use and contact with water only when powered using the Blink Weather Resistant Power Adapter, model no. BAH0410U (sold separately). However, your device is not intended for underwater use and may experience temporary effects from exposure to water. Do not intentionally immerse your device in water. Do not spill any food, oil, lotion, or other abrasive substances on your device. Do not expose your device to pressurized water, high-velocity water, or extremely humid conditions (such as a steam room). Do not expose your device or batteries to salt water or other conductive liquids. To protect against electric shock, do not place a cord, plug, or device in water or other liquids. If your device gets wet from

immersion in water or high-pressure water, carefully disconnect all cables without getting your hands wet and wait for them to dry completely before powering it on again. Do not attempt to dry your device or batteries (if applicable) with an external heat source, such as a microwave oven or a hair dryer. To avoid risk of electric shock, do not touch your device or batteries or any wires connected to your device during a lightning storm while your device is powered. If your device or batteries appear to be damaged, discontinue use immediately.

- If your device is dropped or otherwise damaged, the waterproofing of the device may be compromised.
- For more information concerning care instructions and the waterproofing of your device, please see www.amazon.com/devicesupport.
- Protect your device from direct sunlight.
- Use only accessories supplied with your device, or specifically marketed for use with your device, to power your device. Use of third-party accessories may impact your device's performance. In limited circumstances, the use of third-party accessories may void your device's limited warranty. In addition, use of incompatible third-party accessories may cause damage to your device or the third-party accessory.
- Read all safety instructions for any accessories before using with your device

For device compatibility, please see the detail page for your accessory on

<https://support.blinkforhome.com/indoor-outdoor-accessories>.

WARNING: Small parts contained in your device and its accessories may present a choking hazard to small children.

CAUTION: When mounting this device in elevated locations, use precautions to ensure that the device does not fall and harm bystanders.

Protection Against Water

To reduce the risk of damage to your device, follow these instructions:

- Do not intentionally immerse your device in water or expose it to seawater, salt water, chlorinated water or other liquids (such as beverages).
- Do not spill any food, oil, lotion or abrasive substances on your device.
- Do not expose your device to pressurized water, high-velocity water or extremely humid conditions (such as a steam room).

If your device is dropped or otherwise damaged, the waterproofing of the device may be compromised.

For more information concerning care instructions and the waterproofing of your device, please see

www.amazon.com/devicesupport.

PRODUCT SPECIFICATIONS

- Mini 2
- Model Number: BCM00700U
- Electrical Rating: 5V 1.0A
- Operating Temperature Range: -20° to 45°C (-5°F to 113°F)

FOR CUSTOMERS IN EUROPE AND THE UNITED KINGDOM

Conformity Statement

Hereby, Amazon.com Services LLC declares that the radio equipment type BCM00700U complies with Directive 2014/53/EU and UK Radio Equipment Regulation, RER 2017(SI 2017/1206), including currently valid amendment(s). The full texts of the declarations of conformity and other applicable statements of compliance for

this product are available at the following internet address: blink.com/safety-and-compliance

- Wireless Feature: WiFi
- Maximum Power: 2412 – 2472 MHz xx dBm EIRP

Electromagnetic Field Exposure

In order to protect human health, this device meets the thresholds for exposure of the general public to electromagnetic fields according to Council Recommendation 1999/519/EC.

This device should be installed and operated with at least 20 cm between the radiator and your body.

RECYCLING YOUR DEVICE PROPERLY

In some areas, the disposal of certain electronic devices is regulated. Make sure you dispose of or recycle, your device by your local laws and regulations. For information about recycling your device, go to

www.amazon.com/devicesupport.

Additional Safety and Compliance Information

For additional safety, compliance, recycling and other important information regarding your device, please refer to the Legal and Compliance section of the About Blink menu in the Settings in your app or the Blink website at

<https://blinkforhome.com/safety-and-compliance>

TERMS AND POLICIES

By purchasing or using the product, you agree to the Terms of Service found at <https://blinkforhome.com/terms-of-service>.

Before using the Blink device ("Device"), please read the terms and policies for the Device located in your Blink Home Monitor App in About Blink > Legal Notices (collectively, the "Agreement"). By using your Device, you agree to be bound by the Agreement. In the same sections, you can find the Privacy Policy which is not part of the Agreement.

BY PURCHASING OR USING THE PRODUCT, YOU AGREE TO BE BOUND BY THE TERMS OF THE AGREEMENT.

LIMITED WARRANTY

For information on our warranty and any other applicable policy, visit <https://blinkforhome.com/blinkterms-warranties-and-notices>

This warranty for the Blink device ("Device") is provided by the entity set forth below. The provider of this warranty is sometimes referred to herein as "We". We warrant the Device against defects in materials and workmanship under ordinary consumer use for two years from the date of original retail purchase. During this warranty period, if a defect arises in the Device, and you follow the instructions for returning the Device, we will, at our option, to the extent permitted by law, either (i) repair the Device using either new or refurbished parts, (ii) replace the Device with a new or refurbished Device that is equivalent to the Device that is to be replaced, or (iii) refund to you all or part of the purchase price of the Device. This limited warranty applies, to the extent permitted by law, to any repair, replacement part or replacement device for the remainder of the original warranty period or ninety days, whichever period is longer. All replaced parts and Devices for which a refund is given shall become our property. This limited warranty applies only to hardware components of the Device that are not subject to accident, misuse, neglect, fire or other external causes, alterations, repair or commercial use.

Instructions

For specific instructions about how to obtain warranty service for your Device, please contact Customer Service using the contact information found at www.blinkforhome.co.uk under the 'Support' tab. In general, you will need to deliver your Device in either its original packaging or in equally protective packaging to the address specified by Customer Service. Before you deliver your Device for warranty service, it is your responsibility to back up any data,

software or other materials you may have stored or preserved on your Device. It is possible that such data, software or other materials will be lost or reformatted during service, and we will not be responsible for any such damage or loss. This limited warranty gives you specific rights. If you are a consumer, you may have additional rights under applicable law, and this limited warranty is provided in addition to, and without prejudice to, your consumer rights.


WARRANTY PROVIDER

If you purchased your Device from [Amazon.co.uk](#), [Amazon.de](#), [Amazon.fr](#), [Amazon.it](#), [Amazon.es](#), [Amazon.nl](#) or from authorized resellers located in Europe, this warranty is provided by Amazon EU S.à r.l., 38, avenue John F. Kennedy, L-1855 Luxembourg.

ADDITIONAL INFORMATION

You can find the Customer Service contact information and other applicable terms and Device information (including in other languages) at <https://support.blinkforhome.com/>.
©2024 [Amazon.com](#), Inc. or its affiliates, Amazon, Alexa, Blink, and all related marks are trademarks of [Amazon.com](#), Inc. or its affiliates

Documents / Resources

	blink Mini 2 Plug In Smart Security Camera [pdf] Instructions Mini 2, Mini 2 Plug In Smart Security Camera, Plug In Smart Security Camera, Smart Security Camera, Security Camera, Camera
--	--

References

- [a Low Prices in Electronics, Books, Sports Equipment & more](#)
- [a Amazon.de: Günstige Preise für Elektronik & Foto, Filme, Musik, Bücher, Games, Spielzeug & mehr](#)
- [a Amazon.es: compra online de electrónica, libros, deporte, hogar, moda y mucho más.](#)
- [a Amazon.fr : livres, DVD, jeux vidéo, musique, high-tech, informatique, jouets, vêtements, chaussures, sport, bricolage, maison, beauté, puériculture, épicerie et plus encore !](#)
- [a Amazon.it: elettronica, libri, musica, fashion, videogiochi, DVD e tanto altro](#)
- [a Amazon.nl: Groot aanbod, kleine prijzen in o.a. Elektronica, boeken, sport en meer](#)
- [a Amazon Digital Services and Device Support - Amazon Customer Service](#)
- [b Blink Support](#)
- [b Accessories — Blink Support](#)
- [User Manual](#)