

blink
home Mini2ANZ
Weatherproof
Power Adapter



blinkfor home Mini2ANZ Weatherproof Power Adapter Instructions

[Home](#) » [blinkfor home](#) » blinkfor home Mini2ANZ Weatherproof Power Adapter Instructions 

Contents

- [1 Blink for home Mini2ANZ Weatherproof Power Adapter](#)
- [2 PRODUCT SPECIFICATIONS](#)
- [3 Other Safety considerations](#)
- [4 LIMITED WARRANTY](#)
- [5 Installation](#)
- [6 Maintenance and Disposal](#)
- [7 FAQs](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)

blink

Blink for home Mini2ANZ Weatherproof Power Adapter



PRODUCT SPECIFICATIONS

- Model Number: BAH0410U
- Adaptor Made By: Dongguan Aohai Technology Co. Ltd.
- Input RaYng: 100-240Vac, 50/60Hz, 0.35W
- Output RaYng: 5.0Vdc, 2.0A, 10.0W
- Average AcYve Efficiency: 81.94% @230Vac
- No-load Power ConsumpYon: 0.071W @230Vac
- OperaYng Temperature Range: -20°C to 50°C (-4°F to 122°F)

SAFETY INFORMATION

READ ALL SAFETY INFORMATION BEFORE USING THE DEVICE. FAILURE TO FOLLOW THESE SAFETY INSTRUCTIONS COULD RESULT IN FIRE, ELECTRIC SHOCK, OR OTHER INJURY OR DAMAGE. DANGER — TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, FOLLOW THESE INSTRUCTIONS CAREFULLY.

- DO NOT force the adaptor into a power outlet.
- DO NOT expose the adaptor, metal connectors, or cable to liquids.
- If the adaptor or cable appears damaged, discontinue use immediately.
- Be sure to hold the plug, not the cable, when plugging in or out. Grabbing the cable may damage the wire or cause problems.
- DO NOT install when it is raining.
- DO NOT install on a hot surface or metal surface (one that stores heat).
- Ensure the cable is securely fastened along its length and be aware of hazards from a weed whacker, hedge trimmer, or similar equipment.
- DO NOT expose the adaptor to corrosive materials.
- Use only with compatible Blink devices.

- For device compatibility, please see the detail page for your accessory at <https://support.blinkforhome.com/indoor-outdooraccessories>.
- **WARNING:** Strangulation Hazard. Children have been strangled in cables. Keep out of reach of young children.
- **WARNING:** Small parts contained in your device and its accessories may present a choking hazard to small children.
- **CAUTION:** HOT SURFACE.

The surface of the power adaptor may get hot to the touch during operation. To protect against possible burn hazards, wait one-half hour before unplugging from the mains before handling.

WARNING: Risk of Electric Shock. Your adaptor is rated to meet IP67 test conditions under IEC 60529 and can withstand outdoor use and contact with water under certain conditions. When used with compatible Blink devices, refer to the IP rating of the device into which the adaptor is plugged. Do not plug the power adaptor into an outdoor socket without first ensuring it has appropriate weather resistance for outdoor use.

Always ensure the socket is easily accessible and located near the Blink device that it is powering. Install only to a covered Class A GFCI electrical socket that has an enclosure that is weatherproof with the attachment plug cap inserted or removed. Not for use with electrical sockets that are weatherproof only when the socket is covered (attachment plug cap not inserted and electrical socket cover closed).

Your adaptor is not intended for underwater use and may experience temporary effects from exposure to water. Do not intentionally immerse your adaptor in water. Do not spill any food, oil, lotion, or other abrasive substances on your adaptor. Do not expose your adaptor to pressurized water, high-velocity water, or extremely humid conditions (such as a steam room). Do not expose your adaptor to salt water or other conductive liquids. To protect against electric shock, do not place a cord, plug, or adaptor in water or other liquids.

If your adaptor gets wet from immersion in water or high-pressure water, carefully disconnect all cables without getting your hands wet and wait for them to dry completely before powering it on again. Do not attempt to dry your adaptor with an external heat source, such as a microwave oven or a hair dryer. To avoid the risk of electric shock, do not touch your adaptor or any wires connected to your device during a lightning storm while your device is powered. If your adaptor is dropped or otherwise appears damaged, discontinue use immediately, as the waterproofing of the adaptor may be compromised.

Other Safety considerations

Your device does not have an on/off button. If you wish to stop power from flowing into your device, unplug the power cord. Do not plug multiple electric devices into the same wall socket. Overloading a socket can cause it to overheat and may result in a fire.

CAUTION: When using this device in elevated locations, use precautions to ensure that the device does not fall and harm bystanders.

RECYCLING YOUR DEVICE PROPERLY

In some areas, the disposal of certain electronic devices is regulated. Make sure you dispose of or recycle your device by your local laws and regulations. For information about recycling your device, go to www.amazon.com/devicesupport.

Additional Safety and information

For additional safety, compliance, recycling, and other important information regarding your device, please refer to the Legal and Compliance section of the About Blink menu in the Settings in your app or on the Blink website at <https://blinkforhome.com/safetyand-compliance>.

TERMS AND POLICIES

Before using the Blink device ("Device"), please read the terms and policies for the Device located in your Blink Home Monitor App in About Blink > Legal Notices (collectively, the "Agreement"). By using your Device, you agree to be bound by the Agreement. In the same sections, you can find the Privacy Notice which is not part of the Agreement. BY PURCHASING OR USING THE PRODUCT, YOU AGREE TO BE BOUND BY THE TERMS AGREEMENTS.

LIMITED WARRANTY

If you purchased your Blink devices or accessories (the "Device") from Amazon.com. From authorized resellers located in Australia or New Zealand, the warranty for the Device is provided by Amazon Commercial Services Pty Ltd, Level 37, Citigroup Tower, 2 Park Street Sydney, NSW 2000. The provider of this warranty is sometimes referred to herein as "we". When you purchase a new or Certified Refurbished Device (which, for clarity, excludes Devices sold as "Used" & Used Devices sold as Warehouse Deals), we warrant the Device against defects in materials and workmanship under ordinary consumer use for one year from the date of original retail purchase.

During this warranty period, if a defect arises in the Device, and you follow the instructions for returning the Device, we will at our option, to the extent permitted by law, either (i) repair the Device using either new or refurbished parts, (ii) replace the Device with a new or refurbished Device that is equivalent to the Device to be replaced, or (iii) refund to you all or part of the purchase price of the Device. This limited warranty applies, to the extent permitted by law, to any repair, replacement part, or replacement device for the remainder of the original warranty period or ninety days, whichever period is longer.

All replaced parts and Devices for which a refund is given shall become our property. This limited warranty applies only to hardware components of the Device that are not subject to (a) accident, misuse, neglect, fire, alteration, or (b) damage from any third-party repair, third-party parts, or other external causes.

Instructions

For specific instructions about how to obtain warranty service for your Device, please contact Blink Support using the contact information provided below in 'Contact information.' In general, you will need to deliver your Device in either its original packaging or in equal protective packaging to the address specified by Customer Service. Before you deliver your Device for warranty service, it is your responsibility to remove any removable storage media and back up any data, software, or other materials you may have stored or preserved on your Device. Such storage media, software, e-aware, or other materials may be destroyed, or reformatted or damaged during service, and we will not be responsible for any such damage or loss.

Limitations: TO THE EXTENT PERMITTED BY LAW, THE WARRANTY AND REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND instead of ALL OTHER WARRANTIES AND REMEDIES, AND WE SPECIFICALLY DISCLAIM ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND AGAINST HIDDEN OR LATENT DEFECTS. IF WE CAN NOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS LIMITED WARRANTY AND TO REPAIR OR REPLACEMENT SERVICE.

SOME JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG A STATUTORY OR IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. WE ARE NOT RESPONSIBLE FOR DIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR UNDER ANY OTHER LEGAL THEORY. IN SOME JURISDICTIONS THE FOREGOING LIMITATION DOES NOT APPLY TO DEATH OR PERSONAL INJURY CLAIMS, OR ANY STATUTORY LIABILITY FOR INTENTIONAL AND GROSSLY NEGLIGENT ACTS AND/OR OMISSIONS, SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU. SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF DIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSION OR LIMITATION MAY NOT APPLY TO YOU. This limited warranty gives you specific rights. You may have additional rights under applicable law, and this limited warranty does not affect such rights.

Contact information

For help with your Device, please contact Blink Support in Australia (Toll-Free) at 1800 595 447 or in New

Zealand (Toll-Free) at 800 780 635. FOR AUSTRALIAN CUSTOMERS: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure, provided repair facilities and parts for the goods are available. Subject to any rights that you may have under the Australian Consumer Law, you may be required to bear the expense of claiming under this limited warranty, including the cost of returning the Device.

FOR NEW ZEALAND CUSTOMERS: Our goods come with guarantees that cannot be excluded under the Consumer Guarantees Act 1993. You are entitled to a repair, replacement, or refund if the goods we provide to you are not of acceptable quality, are not fit for a particular purpose made known by you the consumer, or are represented by us, or do not correspond with what is advertised by us. We do not undertake that repair facilities and parts will be available for our goods. You are entitled to reject the goods and receive a refund or replacement from us if the failure of the goods to comply with guarantees in the Consumer Guarantees Act cannot be remedied, or the failure is in substantial character. Additionally, you are entitled to compensation for reasonably foreseeable loss or damage. The above terms do not apply to goods purchased for commercial use.

Safety Information

It is essential to read and understand all safety information before using the Weatherproof Power Adapter. Failure to follow safety instructions could result in fire, electric shock, or injury.

Please follow these safety guidelines.

- Use only with compatible Blink devices.
- Avoid strangulation hazards by keeping cables out of reach of children.
- Do not overload wall sockets to prevent overheating.
- Ensure the power adaptor is not damaged before use.

Installation

Install the Weatherproof Power Adapter to a covered Class A GFCI electrical socket that is weatherproof. Follow these steps:

1. Ensure the electrical socket has a weatherproof enclosure.
2. Insert or remove the attachment plug cap as needed.
3. Avoid using sockets that are weatherproof only when covered.

Maintenance and Disposal

Proper maintenance and disposal are crucial for the longevity of the Weatherproof Power Adapter. Follow these guidelines:

- If the adaptor appears damaged, discontinue use immediately.
- Recycle according to device by local laws and regulations.

FAQs

Q: Can I use the Weatherproof Power Adapter with non-blink devices?

A: No, the adapter is designed only for use with compatible Blink devices.


Q: What should I do if the power adaptor gets hot during operation?

A: If the power adaptor gets hot, unplug it from the mains and wait for it to cool down before handling it.

Q: How do I dispose of the Weatherproof Power Adapter?

A: Follow your local laws and regulations for electronic device disposal. Visit www.amazon.com/devicesupport for recycling information.

Documents / Resources

	<p>blinkfor home Mini2ANZ Weatherproof Power Adapter [pdf] Instructions</p> <p>Mini2ANZ, WSL, Mini2ANZ Weatherproof Power Adapter, Mini2ANZ, Weatherproof Power Adapter, Power Adapter, Adapter</p>
---	---

References

- [a Shop online for Electronics, Apparel, Toys, Books, DVDs & more](#)
- [a Shop online for Electronics, Apparel, Toys, Books, DVDs & more](#)
- [a Amazon Digital Services and Device Support - Amazon Customer Service](#)
- [b Blink Support Contact Information — Blink Support](#)
- [b Accessories — Blink Support](#)
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.