

# **BLNAN LS-CL-K24W-Dim-WYRGB RGB Flush Mount Ceiling Light with Remote Control User Manual**

Home » BLNAN » BLNAN LS-CL-K24W-Dim-WYRGB RGB Flush Mount Ceiling Light with Remote Control User

Manual ™

#### **Contents**

- 1 BLNAN LS-CL-K24W-Dim-WYRGB RGB Flush Mount Ceiling Light with Remote Control
- **2 PRODUCT INFORMATION**
- **3 INTRODUCTION**
- **4 SPECIFICATIONS**
- **5 INSTALLATION STEPS**
- 6 Documents / Resources
  - **6.1 References**
- **7 Related Posts**




BLNAN LS-CL-K24W-Dim-WYRGB RGB Flush Mount Ceiling Light with Remote Control



# **PRODUCT INFORMATION**

Product Type: LS-CL-K24W-Dim-WYRGB



# **INTRODUCTION**

# Dear customer,

Thank you for purchasing our RGB ceiling light. In order to use this product correctly, please read and keep this instruction for future reference. We are dedicated to the customers to bring a convenient and comfortable experience.

Email address: <a href="mailto:support@blnan.net">support@blnan.net</a>

# PRODUCT INTRODUCTION


You could directly use the remote control to set the functions.

- 1. Adjust the brightness and color temperature.
- 2. Change different RGB colors as an atmosphere light. Annaror RGB led flush mount ceiling light with remote, ideal for bedroom, living room, study room, balcony, home movie theater, party, festival, etc.

# **SPECIFICATIONS**

LS-CL-K24W-Dim-WYRGB
<b>φ</b> 300*60mm / <b>12</b> *2.36inch
24W+RGB 8W
AC120V 60Hz
2400LM
3000K-6500K
7 RGB colors + RGB cycle mode
344pcs beads + 80pcs RGB beads
90
PC
IP40
2.4G
10M
30000H

# 2.4G REMOTE CONTROL INSTRUCTION



- 1. ON/ OFF
- 2. Turn off the light after 30 seconds
- 3. Steplessly up to 100% brightness (Not applicable for RGB)
- 4. Steplessly down to 10% brightness (Not applicable for RGB
- 5. Steplessly down to 3000k

- 6. Steplessly up to 6500k
- 7. Night light mode
- 8. 7 RGB colors
- 9. RGB cycle mode fast/ slow
- 10. Different color temperatures (3000k/ 4000k/ 6500k)

11. Warm white: 3000k12. Cold white: 6500k

#### **NOTE**

- · Batteries are not included
- It doesn't fit for dimmer switch.
- The remote control distance is 10 meters.
- The brightness of RGB colors can not be adjusted.
- The brightness only can be adjusted by a remote control, not a wall switch.


## **MEMORY FUNCTION**

- 1. Keep the current color temperature and brightness for 1 minute and turn off the ceiling light for more than 5 seconds, the light will remember the light setting when it is turned back on.
- 2. Remote control: memory function does not include RGB cycle mode.

## **WALL SWITCH OPERATION INSTRUCTIONS**


Change the 6500K  $\rightarrow$  3000K  $\rightarrow$  4000K  $\rightarrow$  night light mode $\rightarrow$  RGB cycle mode in turn. (Do not fit for home dimmer!)


# **ACCESSORIES LIST**




## **INSTALLATION STEPS**


- 1. Please switch off the power to the entire house. Kindly press the " on the cover and take it off the cover.
- 2. Secure the ceiling light's bottom to the junction box using the screws provided. Ensure the junction box used is of the correct size. The distance between screw holes on the junction box should be 2.75-4.33 inches.





- 3. Join the wires of the corresponding colors. Ensure all wires are properly placed. (Supply terminal description: Black: Live Wire; White: Neutral Wire; Green: Ground Wire)
- 4. After connecting the wires, align the 2 protruding corners on the light cover with the holes and press the " to fix it in place.





### **QUESTION & ANSWER**

- 1. Why does the remote control not work?
  - A: Try to replace the new batteries.
  - B: Try to pair the remote control and the light.
  - C: If you have any questions, please contact the following email address: support@blnan.net
- 2. How to pair the remote control and the light?
  - First step: power off for 10-20 seconds,
  - · Second step: power on again,
  - Third step: Long press of 5 seconds to match the code, the ceiling light flashes once and the pairing is successful.
- 3. How to cancel the pairing between the remote control and the light?
  - First step: power off for 10-20 seconds,
  - · Second step: power on again,
  - Third step: long press for 5 seconds, the ceiling light flashes twice, and the pairing is canceled successfully.

### **PRECAUTIONS**

## **Precautions Before Installation**

- 1. Power off before installation.
- 2. Do not exceed the rated voltage.
- 3. Do not install it on surfaces that are not stable or deformed.
- 4. Do not install it on or above the surface with high temperatures.
- 5. Please make sure that no gas, water, or electricity pipes and wires can be drilled through or damaged in your chosen mounting location.

## **Precautions During Installation**

- 1. There must be no corrosive, explosive, or flammable materials around the lamp.
- 2. The user should connect the cable correctly, and the lamp should be installed by a qualified electrician.
- 3. Please pay attention to connecting the wires correctly, and make sure the cable connection complies with national regulations.
- 4. Please make sure that the lampshade is clear in case of low luminous efficiency.
- 5. Please make sure that illuminants are securely fixed during the installation.

#### **Precautions About the Product**

- 1. It is not suitable for dimmers and electronic switches.
- 2. The LED light source inside the lamp body can not be replaceable.
- 3. The lampshade cannot be opened.
- 4. Do not touch the light when it is running.
- 5. Do not look straight into the light source (illuminant, LED, etc.).
- 6. Do not let the children touch this light and packaging to avoid danger.



MADE IN CHINA

## **Documents / Resources**

BLNAN LS-CL-K24W-Dim-WYRGB RGB Flush Mount Ceiling Light with Remote Control [pdf] User Manual

LS-CL-K24W-Dim-WYRGB RGB Flush Mount Ceiling Light with Remote Control, LS-CL-K24W-Dim-WYRGB, RGB Flush Mount Ceiling Light with Remote Control, Mount Ceiling Light with Remote Control, Control, Ceiling Light with Remote Control, Control

## References

User Manual